Below 1G (H6143)




The EUT is Placed at the center of the Turntable.



The EUT is Placed at the center of the Turntable.

Below 1G (H6144)



The EUT is Placed at the center of the Turntable.




The EUT is Placed at the center of the Turntable.

Above 1G (H6143)



The EUT is Placed at the center of the Turntable.




The EUT is Placed at the center of the Turntable.

Above 1G (H6144)



The EUT is Placed at the center of the Turntable.



The EUT is Placed at the center of the Turntable.