

billboard®

Wireless Microphone



Model # BB2735

Instruction Manual
Instrucciones en español incluidas

CAUTION :

Before connecting, operating or adjusting this product, please read this user's manual carefully and completely.

Intensive Metal Cover

Metal cover, anti-dropping and reduce noise, built in cotton filter, effectively filter out wind noise, tooth noise and other noise.

High Fidelity Microphone Core

Using advanced guide noise suppression can effectively prevent the frequency. Smart frequency uses the first low phase noise signal source to receive signals and more stable Perfect microphone core and good sound quality

Receiver with built-in rechargeable battery

Plug the receiver into microphone input on your device Turn it on and turn the microphone on.
Use the charging cable to charge the receiver

Microphone

Unscrew the bottom part of the microphone and insert 2xAA batteries (not included)
Turn on microphone with the power button. Microphone is ready to use

Change the frequencies.


10 Selectable frequencies for interference free performance
If there is any interferences when using the microphone try changing the frequency. Please unscrew the lower section of microphone and find the small button to push to change the frequency.

Fully compatible

3.5mm microphone input standard interface, compatible with all kinds of digital devices, including desktop, one machine, laptop, smart phone, external sound card etc. 6.5mm microphone input standard interface, compatible with all kinds of outdoor audio, home theater, amplifier, TV, mixer, etc

Adjust the frequency:

Press the button, this will change the frequency. Pick the frequency that you want, and has no interference. Screw back the lower cover on the microphone, continue using the microphone



Specification	
RF carrier frequency range.....	657.3-660.8 MHz
Distance.....	Open area 30-50 meters
Frequency stability.....	± 0.005%
S/N ratio.....	>100dB
RF output power.....	5.07dBm
Maximum output sound pressure.....	130dB
Microphone core.....	Dynamic type

FCC Information FCC ID: 2AQB-E-BB2735

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation
Federal Communications Commission (FCC) Statement
This Equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV/technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment. Tested to comply with FCC standard.

FOR HOME OR OFFICE USE

Warning: This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or conjunction with any other antenna or transmitter

Wireless microphone users shall rely on the white space databases in part 15, Subpart H to determine that their intended operating frequencies are available for unlicensed wireless microphone operation at the location where they will be used. Wireless microphone users must register with and check a white space database to determine available channels prior to beginning operation at a given location. A user must re-check the database for available channels if it moves to another location.

Manufactured by ESI Cases & Accessories
44 East 32nd Street New York, NY 10016
All other trademarks are property of the respective companies

LIMITED WARRANTY

ESI Cases & Accessories, Inc., warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser will be free from defective workmanship and materials for one year and agrees that it will, at its option, either repair the defect and replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.
This warranty does not apply to any appearance items of the product nor to the additional excluded item(s) set forth below nor at which design or construction. The limited warranty described herein is in addition to an applicable law
ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases & Accessories, Inc.

The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases & Accessories, Inc. and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases & Accessories, Inc. to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liabilities and responsibilities of ESI Cases & Accessories, Inc. be liable or in any way responsible, for any incidental or consequential damages, so the above exclusion may not apply to you.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE

Return Instructions

If your product malfunctions during the warranty period of one calendar year (90 days for battery), contact our customer service department at (212) 883-8838 to obtain troubleshooting information. If troubleshooting assistance fails to remedy the problem, you will receive a return authorization # and instructions for sending your unit to our Service Center. Your return authorization number must be clearly visible and placed on the outside of box when the unit is returned.

Enclose a copy of your original proof of purchase showing the original purchase date, along with detailed information describing the exact nature of your problem. Be sure to include your complete name, address, email address, daytime and evening contact numbers. In addition, please send a check or money order made payable to "ESI Cases & Accessories," for return freight amount (given to you by our service agents). All of the above must be included with your return, or your package will not be eligible for service under our warranty. The customer is responsible for packing the product in its original carton or equivalent, and for insuring, and shipping the unit to our service center. Please make sure to pack all accessories included with your product so that we can properly identify any issues. All freight cost to return the unit to ESI Cases & Accessories, are the responsibility of the customer. If your speaker is under warranty then ESI Cases & Accessories, will at its sole discretion, exchange or repair the speaker without charge for parts and labor. The customer is responsible for return freight and should include a check or money order payable to "ESI Cases & Accessories," with your return for the return freight amount. Any shipments received without a Return Authorization number will be refused. For more details please contact our customer service department

Send product:
ESI Cases & Accessories
44 East 32nd Street
New York, NY 10016
Tech Support: (212) 883-8838
TechSupport@ESICellular.com

© 2020 Billboard IP Holdings, LLC. All rights reserved. Billboard®, the Billboard logo, HOT 100 and associated characters, trademarks and design elements are owned and licensed by Billboard IP Holdings, LLC. All other trademarks are property of their respective companies

BATTERY CAUTION: Do not disassemble, short circuit, or expose to fire or high temperature. Properly connect specified devices. Recycle battery according to local, state and national regulations.