135.58 mm

175.35 mm

Stereo RGB Desktop Gaming Speakers

Contents
Speaker Set
USB-C to USB-A Cable
3.5mm AUX Cable
User Manual

Power on/off
&Volume control

Long press — Switch between Bluetooth mode and Aux mode

Mode switch button

Short press — Switch between lighting modes

3.5MM AUX port

TYPE C port

Bluetooth Mode & Pairing
1. Connect the USB-C cable to the speaker and the USB-A connection to either a computer or a charging adapter that provides at least 5V/2A.
2. Turn on the speaker using the power on/off control.
3. Push the mode button for a few seconds until you hear "Bluetooth Mode". Switch between wireless (Bluetooth) and wired modes by holding the mode button for a few seconds as needed.
4. Select "Verbatim RGB Speaker" on the Bluetooth device you are pairing with the speakers.

Wired Mode
1. Connect the AUX cable to the speaker and the other end into the computer AUX port.
2. Turn on the speaker using the power on/off control.
3. Push the mode button for a few seconds until you hear "AUX mode". Switch between modes by holding the mode button for a few seconds as needed.

Lighting Modes
1. Rotate between RGB light modes with a short push of the Mode Switch Button

Speaker Specifications:

Speaker Output	10W (5W*2)
Power Supply	USB 5V/2A
Ports	AUX Port, USB-C port
Frequency Response Range	100Hz - 20KHz
S/N Ratio	≥ 75dB
Sensitivity	750mV ±50mV
Charging Voltage	5V DC
Charging Current	2A

FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.