

User Operating Manual
Dthera DS-001
Tablet Computer

About This User Guide

Some of the contents of this guide may appear differently on your device. Your actual device may differ from the illustration, depending on the software and your service provider. All information in this document is subject to change without prior notice. Your device's applications and their functions may vary by region, or hardware specifications. Dthera cannot be held liable for performance or incompatibility issues resulting from edited registry settings being edited or operating system software being modified. Any attempt to customize your operating system may cause the device or its applications to not work as they should.

Important

We do not suggest that you reinstall the system. You may contact Dthera support if reinstallation is necessary.

Do not disassemble the device in any circumstance.

Please keep your device away from fire, water or any extreme weather conditions.

Please avoid placing heavy objects or hard presses on front face of your device.

Disclaimer of Warranties

Dthera shall not be liable for any damages of any kind resulting from the purchase or use the product or arising from the breach of the express warranty, including incidental, special or consequential damages, or loss of anticipated profits or benefits. Dthera is not liable for performance issues or incompatibilities caused by editing, adding or deleting registry settings, or modification of operating system software. Using custom operating system software may cause your device and applications to work improperly.

Getting started

Press the power button to start the device. Connect to WIFI and add your family code. Your family Coe has been provided to you via email by Dthera Sciences. You may also call customer support.

Wi-Fi Connection

Tap when start the device, you can tag the "get started" , your Wi-Fi network nearby will be listed. If you need to rescan for available networks, Tap the network you have access to, enter password, and tap 'Connect'.

Dthera user

After connect WIFI successfully, can go to Dthera user menu. You can clip "QR code" to scan the code. Or enter the family code from Dthera provided to play the video.

Device factory mode

You may reset your tablet when necessary. This will clear all info in your tablet and get your device back to factory mode.

WARNING!

If you perform factory mode, all user applications, user data will be deleted. You will have to log back in with your family code

Troubleshooting

Device crash

- Long press the power button and restart.

Error message during operation

Delete and clear the system to factory mode with a system reset..

Device can't be connected with Wi-Fi

Unplug Wi-Fi router, wait for 2 minutes and plug to connect again.

Check and make sure there is no filtering setting or device connection limit in your router settings.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AQI4-DS001