
Mare 8000 mAh Suction Wireless Power Bank

Instruction Manual AST-WR070



- 1. Wireless Charging Surface Suction Pad
- USB Output 1
- 4. Type-C Input Port
- USB Output 2
- 6. Micro-USB Input Port
- ON/OFF Button
- 8. LFD Indicators
- What's included:
- 1 x 8000 mAh Wireless Powerbank 1 x USB to Micro-USB Cable
- 1 x Instruction Manual

Tech Specifications

- Battery: 8000mAh/3.7V/29.6Wh
- USB Output 1/2: 5V/2A Max
- · Wireless Output: 5W
- Type-C input: 5V/2A
- Micro-USB Input: 5V/2A

. ON/OFF Button: Press once to view the remaining power capacity.

Number of LEDs 0000 0000 0000 Capacity Remaining about 100% about 75% about 50% about 25%

INSTRUCTIONS:

- 1. Charging the Powerbank: . Charge the powerbank fully before usage.
- . Connect the provided charging cable to a power source and to the micro USB port on the powerbank(6). Or your own Type C · cable to the Type Input Port (4). Once connected the LED Indicator will begin to flash WHITE when charging, once fully charged LED will turn WHITE.
- 2. Charging mobile phones and other electronic devices:
- . Connect the charging cable to your mobile phone/device using the appropriate connector. Connect the USB part of the cable into either USB Output(3 or 5). LED Indicator will illuminate when charging.
- · Remove the USB cable from your mobile device when it is fully charged.
- 3. Wireless Charging Function:
- . Press the Powerbank ON/OFF button(7) to turn on the wireless charging function, LED indicator near power button will flash green for one time and turn on.
- · Place wireless charging supported mobile device on the charging surface/suction pad, the green LED will be blinking flash when device is charging.
- · Phone will begin to charge automatically.
- ** Note: When wireless charging, if the LED indicator will flashes the device is either NOT a wireless charging device or there is an object between the device and charging surface interfering with the charging.

SAFETY PRECAUTIONS:

- · WARNING-When using this product, basic precautions should always be followed: 1 Read all the instructions before use
- 2. Never store or use this product in temperatures below 32°F (0°C) or above
- 115°F (45°C). 3. Do not overcharge your phone. The unit may become hot under excessive use. Remove your phone once it is fully charged. Never charge your phone for
- more than 7 hours at a time 4. The unit will only achieve full performance after 2 or 3 completed charge and discharge cycles.
- 5. To reduce the risk of injury, close supervision is required when the product is used near children
- 6. Do not expose the device to moisture.
- 7 Do not use the device in excess of its output rating. Overload outputs above the rating may result in a risk of fire or injury.
- 8. Do not use the device if damaged or modified.
- 9. Damaged or modified batteries may exhibit unpredictable behaviour resulting in fire. explosion or risk of injury.
- 10. Do not disassemble the device. For repairs, seek a qualified service professional. Incorrect reassembly may result in a risk of fire or injury.
- 11. Do not expose the device to fire or excessive temperatures. Exposure to fire or temperatures above 104°F (40°C) may result in explosion.
- 12. To ensure product safety, ensure that qualified service professionals use only identical replacement parts.
- 13. Attachments on the back of your phone

can impede the effectiveness of the wireless charger, and lead to overheating. Please remove attachments from the phone before charging on this device.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The distance between user and products should be no less than 20cm

