

Manual

Instructions:

1. Thank you very much for purchasing the wireless controller.
2. The product is mainly used for game operation when the Android/iOS/Win 7/8/10 system and P3 game host are connected wirelessly.
3. Suitable for smart phone/tablet/smart TV, set-top box /PC /P3 game console.
4. LT/RT is the analog function, which pays more attention to the details of the experience, making the game precise and controllable.
5. Can be equipped with receivers to achieve PC/P3 and other devices to use.

*Due to the official or the third party of game platform software upgrades or source code changes and other not resist factors caused some of the game can not be played or connected with our Gamepad, Our company does not take any responsibility. Our company reserves the right of final interpretation.

Android device instructions:

1. Press and hold the A+HOME button for 2 seconds at the same time, the LED1 indicator will flash rapidly (if it has been connected, you can directly press the HOME button to connect);
2. Turn on the Bluetooth on the Android device and search for the device name with the Bluetooth name "GamepadPlus V3". Select the pairing connection.
3. The connection is successful, the LED1 indicator is always on;
4. Can play directly: King Glory, Peace Elite (except game changes);
5. After entering the game, press the corresponding button to adjust to the basic key preset of the game;
6. You can change the configuration or download other key bits using the ShootingPlus V3 APP tool.
 - A. Install the Android version of ShootingPlus V3 App to the Google Play Store.
Search for "ShootingPlus V3" download, or scan code:



- B. Android ShootingPlus V3 App how to customize the key:
 - a) Connect to Bluetooth, install the ShootingPlus V3 App, and push the app to the background after launch.
 - b) After launching the game directly, click the "V3" floating ball icon on the screen or press the "START" button on the handle to enter the app's change interface.
 - c) Drag the key icon in the changed interface to the desired operating position on the game. (Click the key icon to select the key attribute)
 - d) Click "Save" on the menu bar and then "Confirm" to save.
 - e) Click "Close" on the menu or press the "START" button again (or click the "V3" floating ball icon again) to exit the change button interface.
 - f) In the game, you can press the "SELECT" button on the handle to call up the set key prompt.
 - C. You can directly download the set game key in the "V3" main interface by clicking "Cloud Key List" under the game icon.
7. If it is an MTK mobile phone, please press the X+HOME button to enter the standard Android mode for use in the game hall.

Note: If you have entered the wrong Apple mode, please cancel the Bluetooth pairing and reconnect to enter Android

mode.

IOS Apple device instructions:

1. Support IOS mobile device 11.3 to 12.3.1 system;
2. Press and hold the Y+HOME button for 2 seconds at the same time, the LED2 indicator will flash rapidly (if it has been connected, you can directly press the HOME button to connect);
3. Open the Bluetooth on the Apple device and search for the device name with the Bluetooth name "GamepadPlus V3". Select the pairing connection.
4. The connection is successful, the LED2 indicator is always on;
5. Can play directly: King Glory, Peace Elite (except game changes);
6. After entering the game, press the corresponding button to adjust to the basic key preset of the game;
 - A. Apple version of ShootingPlus V3 App, please go to the App Store to search for "ShootingPlus V3" download, (or scan the QR code above);
 - B. How does Apple ShootingPlus V3 customize the keys;
 - a) Connect Bluetooth and install the ShootingPlus V3 App.
 - b) Start the game and take a screenshot of the game screen within the game.
 - c) Open "V3", click "V3" to float the ball or press the "START" button to enter the App to change the interface.
 - d) After long press the blank space to pop up the option, click on Select Picture to select the game screenshot (screenshot of step b).
(In the process of selecting a picture, there will be access to the album reminder, please allow access, ie click: OK)
 - e) Drag the key icon in the changed interface to the desired operating position on the game. (Click the key icon to select the key attribute)
 - f) Click "Save" on the menu and then "Confirm" to save.
 - C. You can directly download the set game key in the "V3" main interface by clicking "Cloud Key List" under the game icon.

Note: If you enter the wrong Android mode, please cancel the Bluetooth pairing and reconnect to enter IOS mode.

wireless connection operation method:

1. Plug the dongle into the PC device/smart TV/TV box or the USB interface of the P3 host;
2. After pressing the LB+HOME button at the same time, the handle enters the wireless pairing mode, and the LED1 and LED2 indicators flash rapidly;
3. After the wireless connection is OK, the LED1 and LED2 indicators are always on; (this mode is 360 mode and supports the steam platform)
4. Press and hold the SELECT+START button to switch to PC mode and the indicator light will not change.
(The handle connection defaults to 360 mode. Because the game is different, you can switch to the corresponding mode as needed.)

Handle charging / sleep / wake up function:

1. When the handle is turned off (press and hold the HOME button to turn off), the LED4 indicator flashes slowly, and it is always on after being fully charged. When charging in the Bluetooth connection state, the LED4 indicator light flashes slowly, and it is long after being fully charged.
 2. Sleep/Wake-up: The gamepad automatically sleeps without any action for 5 minutes. Re-use you need to press HOME button to wake up to connect back;
 3. When the battery is low, the LED4 indicator flashes quickly.
-

Electrical parameters:

Operating Voltage: DC 5V

Precautions:

1. Please do not store this product in a humid or hot place;
2. Do not strike, beat, hit, pierce, or attempt to disassemble the product to avoid unnecessary damage to the product;
3. Built-in battery, do not throw it away with garbage;
4. Do not charge the handle near fire or other heat sources;
5. Non-professionals should not disassemble this product, otherwise it will not be included in the after-sales warranty service

common problem:

Q: Can't I find the handle when I open the phone?

A: Undo the Bluetooth pairing device name before the handle and the phone, and turn on the phone Bluetooth search pair again.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the

user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The device can be used in portable exposure condition without restriction.