
# MOTORCYCLE BLUETOOTH INTERCOM



## **T60R** User Manual

### QUICK START GUIDE




### INSTALLATION INSTRUCTIONS

First fix the screws on the base, insert the installed base into the left side of the helmet, use the socket head cap screws Tighten the screws with the knife, and install the main unit on the base.



If there are any problems with mounting the bracket, you may use the 3M tape bracket.peel off the protective backing sheet of the 3M tape and adhere the bracket onto the helmet.Pressfor15 seconds and glue dry for 24 hours.



Tear off the rough surface of the left and right speaker Velcro on the headset, and paste them on the left and right ears of the helmet, then After attaching the speaker to the Velcro surface in the helmet, the speaker with short headphone cable is installed in the left ear. The long horn is mounted on the right ear.

Paste the microphone Velcro on the rough surface of the helmet, and then paste the microphone on the on the Velcro.

| TYPE               | OPERATION                       | BUTTON CO                               | MMANDS                  |
|--------------------|---------------------------------|---|-------------------------|
| Basic<br>Operation | Power On                        | <b>(</b> )+                             | press for<br>one second |
|                    | Power Off                       | <u>ل</u> +                              | press for<br>one second |
|                    | Volume Up                       | <b>[+]</b>                              | press for<br>one second |
|                    | Volume Down                     | [-]                                     | press for<br>one second |
|                    | Check the battery               | <u> </u>                                | press for<br>8 second   |
| Mobile<br>Photo    | Moblle Phone pairing            | ତ                                       | press for<br>5 second   |
|                    | Voice Command<br>(Siri/S-Voice) | ${f egin{array}{c} {f eta} \end{array}$ | quick press<br>twice    |
|                    | Answer the call                 | 6                                       | short press<br>once     |
|                    | End phone call                  | 6                                       | short press<br>once     |
|                    | Reject phone call               | 6                                       | quick press<br>twice    |
|                    | Answer third party call         | ୰                                       | quick press<br>twice    |
|                    | Reject third party call         | / <b>+</b> /                            | quick press<br>twice    |

| TYPE                  | OPERATION  | BUTTON (   | COMMANDS   |
|-----------------------|--|--|--|
| Pairing<br>With Phone | Moblle Phone Pairing   | C  | press for<br>5 seconds   |
|                       | When the "T60R "is power off ,hold down the<br>"center key" for 5 seconds.after "T60R"the paring<br>state,the red and blue lights flashing alternately .<br>turn on the bluetooth of the mobile phone ,search<br>for new devices,and select the connection when<br>"T60R"is found. |  |  |
| MESH<br>Intercom      | Mesh interphone enabl  | ed 🦳   | short press<br>once  |
|                       | Mesh interphone close  | d  | short press<br>once  |
|                       | Volume Up  | <b>[+</b> ]  | short press<br>once  |
|                       | Volume Down  | -  | short press<br>once  |
|                       | Reset the MESH Interc  | om   | press for<br>8 seconds   |
|                       | While Mesh intercom r<br>atically connect to nea<br>them to support up to 3<br>through open intercom<br>When the headset Mes<br>ing informationand auto<br>channel 4.  | rby "T60R" us<br>2 rider onlino<br>free conversa<br>h is reset,it cl | sers and allow<br>at the same time<br>ation.<br>ears all network |

| TYPE                          | OPERATION  | BUTTON C             | OMMANDS               |
|-------------------------------|--|----------------------|-----------------------|
| Setting<br>Frequency<br>Range | Enter channel setting  |                      | press for<br>2 second |
|                               | surfing the channels   |                      | quick press<br>twice  |
|                               | Save channel and exit  |                      | press for<br>2 second |
|                               | If another team is using channel 4(the default<br>channel)and the network intercom is being interfered<br>with,it can be changed to another channels 1 to 10 |                      |                       |
| Bluetooth<br>Intercom         | Intercom No1 and No<br>enter into pairing mod  | (0) + (-1)           | press for<br>2 second |
|                               | Short press one of the intercom is "power"key  | 6                    | short press<br>once   |
|                               | Bluetooth Intercom   | U                    | press for<br>2 second |
|                               | hang up the<br>Bluetooth intercom  | C                    | short press<br>once   |
| FM Radio                      | FM Rideo on  | <b>+</b> + <b>-</b>  | press for<br>2 second |
|                               | FM Rideo off   | <b>_+</b> /+ <b></b> | press for<br>2 second |
|                               | Scan up  | / <b>+</b> /         | quick press<br>twice  |
|                               | Scan down  | <u> </u>             | quick press<br>twice  |

| TYPE                          | OPERATION  | BUTTON CC             | MMANDS                 |
|-------------------------------|--|-----------------------|------------------------|
| Universal                     | Intercom No1 and No 2<br>enter into pairing mode   | ////+/-/              | press for<br>2 second  |
|                               | Short press one of the intercom is "power"key  | to search             | short press<br>once    |
| Bluetooth<br>Intercom         | Bluetooth Intercom   | +-                    | short press<br>once    |
|                               | hang up the<br>Bluetooth intercom  | <b>_+</b> /+ <b>_</b> | short press<br>once    |
| Music                         | Music play   | 0                     | short press<br>once    |
|                               | Music pause  | C                     | short press<br>once    |
|                               | Last song  | <b>[+</b> ]           | quick press<br>twice   |
|                               | Next song  | -                     | quick press<br>twice   |
|                               | share the music that is playing  | 0                     | quick press<br>twice   |
| Restore<br>factory<br>setting | power off, clear set   | <b>()</b> +           | press for<br>5 seconds |
| Technical<br>specifications   | Bluetooth suppport:HSP,HFP,A2DP,AVRCP,AGHSP<br>Battery:lithium battery,800mA,3.7v<br>Dimensions:92mm*48mm*26mm<br>Certification:CE/FCC/TELEC/ROHS<br>Charging time:3hours<br>Working time:12-18hours |                       |                        |

#### WARRANTY CARD

| Purchase Date:   |            |
|------------------|------------|
| Dealer/retailer: |            |
| Iten No:         |            |
| customer Name:   |            |
| customer Tel:    | 06         |
| customer E-mail: | $\bigcirc$ |

**Product Failure Description** 

(Please be sure to fill in your related information so that we can better | serve you intime)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio

frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and

on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference

that may cause undesired operation.



