**35cm**

正面

10cm

MINI FOLDABLE KEYBOARD MANUAL

Introduction:

BT21 MINI Wireless Foldable Keyboard, with full-size alphanumeric keys, middle low and high round structure keycap brings you wonderful typing feeling. Compatible with iOS / Android / Windows system.

Micro USB Recharging

SIDE VIEW

Power/Bluetooth indicator light
Caps indicator light

FRONT VIEW

Keyboard ON/OFF:

Keyboard adopts sensitive induction feature, ie. keyboard automatically wake up at opening and shut down at closing.

Keyboard opening-Power On

Keyboard closing-Power Off

Pairing connection:

First, when keyboard opened, blue LED on, Press FN+C key, then blue LED flashing,keyboard under pairing.

Second, ON Bluetooth on your device (tablet) and searching for device, and find BT21 keyboard, then select and connect. If connection successful, blue LED ON.

LED indication

1. **Pairing**: When keyboard switch on, blue LED will be turned off after 3s. When keyboard pairing, blue LED flashing.
Charging: Red LED flashing if battery flat, Red LED ON while charging. Red LED off after full charging.

2. Caps Lock LED- Press "CAPS lock" key to toggle between "Uppercase" and "Lowercase", LED on if Uppercase.

Keyboard Operation System:

Keyboard and target device well paired, For some purpose functional keys it needs to press FN+Multi-purpose keys to match its Operation System, ie. if target Android device, select FN+Android column Key, otherwise, some function keys won't work.

FN -Function Key:

FN key must correspond to keys that has the same color of FN key (Table below is Android system functions matching Samsung tablets, however, there's little difference for other brands)

FN+ Multi-purpose key	iOS	Android	Windows
C	Pairing	Pairing	Pairing
Q	iOS	-	-
W	-	Android	-
E	-	-	Windows
~	Home page	Home page	ESC
1	All selection	All selection	F1
2	Copy	Copy	F2
3	Cut	Cut	F3
4	Paste	Paste	F4
5	Search	Search	F5
6	Shift input method	Shift input method	F6
7	On/off keyboard	On/off keyboard	F7
8	Previous	Previous	F8
9	Play/Pause	Play/Pause	F9

反面

FN+ Multi-purpose key	iOS	Android	Windows
0	Next	Next	F10
-	Volume down	Volume down	F11
=	Volume up	Volume up	F12
←	Delete	Delete	Delete
Enter	Lock	Lock	Lock
↑	Page up	Page up	Page up
↓	Page down	Page down	Page down
←	Begin Line	Begin Line	Begin Line
→	End of Line	End of Line	End of Line

Specification

Model: BT21
Name: Mini Foldable Keyboard
Pair Name: BT21 keyboard
Size: 296.2×94.5×5.3mm
Operation Time: 85 hr
Operation Temperature: -10 ~ +60℃
Storage Temperature: -40 ~ +65 ℃
Battery capacity: 120mAh/3.7V/0.444Wh

Input: 5V⎓100mA
Bluetooth: 4.2 Class 2
Recharging Time: 2hr
Effective range: 10 m
Standby Time: 120 days

POWER Energy-saving mode

Keyboard idle 10 minutes, it enters Sleeping mode, Blue LED off. When press any key in 3s, wake up and Blue LED on.

Recharging:

When battery flat, Red LED flashing and waiting for recharging.
First, Connect MICRO USB to keyboard and other end to USB power adaptor.
Second, Red LED on while recharging and off at full.

NOTE:

Here you're some hints that to avoid risk of electric shock, fire and keyboard device damage.
1. Stay away from sharp objects
2. Do not put heavy objects on keyboard
3. Do not put in microwave oven
4. Do not hard press or twist the keyboard
5.Stay away from oil, chemicals, or other dangerous liquids
6. Clean keyboard case by water or alcohol .

FAQ

(A) If not be connected or intermittent at using, please try:
1. Ensure keyboard is within 10 meters to the target device.
2. Make sure it is paired. If not, pair it.
3. If keyboard pairing unsuccessful, delete name of the connected device and pair it.
4. Check battery not flat, or recharge it.

(B) Keyboard not be charged.
1. Make sure USB charging cable is properly connected to keyboard and USB power adaptor.
2. And USB power adaptor is well connected to the power supply.

(C) Caps Lock iOS system malfunction: iOS 10 or after, Caps Lock malfunction, Input Method instead. It's ok if iOS 9.

Ans: iOS10 or after, it's Input Method by default, here is step to have it uppercase/lowercase function: Setting(iOS) > General> Keyboard> Enable Caps lock (off)

(D) Multimedia function keys not be used after iOS 10 but ok iOS 9 .
Ans: To have multimedia functions iOS 10 or after, open music player first, then press correspond multimedia key. (Previous , Playback Pause, Next, Stop, are multimedia keys.)