


SUPERNOTE


Mode:A6 X2-W

Battery capacity: 2700mAh

input: 5.0 V $\overline{\text{---}}$ 2.0 A



IC: 24370-A6X2
HVIN: A6-X2




R 211-230909



YU10674-23006
R-R-QNY-A6X2-W



FCC ID: 2AQZ9-A6-X2



株式会社社会成洋

Made in China
5 GHz band (W52): Indoor use only.



Activate your Supernote

- 1 Power on**
Long press the power button to power on your Supernote device.
- 2 Setup**
Follow the on-screen instructions to start your first note.

To view the complete User Guide, visit: support.supernote.com

Other items included: USB cable, screw driver

Check product certifications:

Settings > My device > Product Certification

