

Model:H1010

1. INTRODUCTION

Congratulations on your purchase of the Paww SoulSound 2 Bluetooth headphones! Please read the instructions and warnings carefully before use to ensure safe and satisfactory enjoyment of this product.

SAFETY PRECAUTIONS

1. To ensure your safety, please follow the instructions in this manual carefully before operating the headset.
2. Keep the device away from edges, uneven surfaces, unstable locations, metal parts, accessories and packaging to prevent any possible damage or malfunction of the device
3. Do not dismantle, disassemble, modify, or attempt to repair at your own discretion, especially battery mismatch or mishandling, as this may cause fire or explosion, electric shock, or complete damage to the unit. Doing so will void the warranty of the device.
4. Keep the device away from water, any liquid, moisture, rain, very humid areas or places with excessive dust environment. Do not use diluents or volatile liquid when cleaning the Bluetooth stereo headphone.
5. If the device is exposed to water, moisture, oil, or other liquids, do not operate to avoid electrical shock or possibly damage and injury to the device and to yourself.
6. Keep the headset away from fire, heat source, or flammables.
7. Avoid using the headphone in unsafe and dangerous locations.

USAGE WARNING

Listening to high volumes can lead to permanent hearing damage.

2. PACKAGE CONTENT

- 1 Paww SoulSound 2 Headphones
- 1 Custom Carry Bag
- 1 USB Charger Cable
- 1 Aux-in Cable
- 1 User Manual

3. CONNECTION DIAGRAM

1. MFB Buttons

- Turn on / Turn off
- Pairing Mode
- Answer Call
- Reject Call
- End Call
- Activate Siri or other Voice system
- Play / Pause

2. Charging
3. 3.5mm Audio Jack

4. Volume Down / Previous Track
5. Volume Up / Next Track
6. Microphone
7. Notification LED Light
8. Bass Boost Function

4. HOW TO USE

4.1. Quick Usage Guide

Desired Result	Required Action
Turn On & Entering Pairing Mode	Press the "MFB" button for 3 second while the device is off. The LED will flash blue and red alternatively and you will hear one beep.
Volume Up	Short press the "+" button for volume up
Volume Down	Short press the "-" button for volume down
Play Previous Track	Long press the "-" button for previous music.
Play Next Track	Long press the "+" button for next music.
Turn Off	Press the "MFB" for 3 seconds while the device is on. The LED will turn off and you will hear a beep.
Play / Pause	Press the "MFB" button to play music when the device is connected and to pause when the device is already playing music.
Low Battery Warning	The LED will flash continuously in red.
Charging	Plug the charger into the micro-USB port. The LED will light up in red indicating that the headset is charging.
Answer Call	Short press the "MFB" button to answer an incoming call.
End Call	Short press the "MFB" button to end a call.
Transfer Voice Call	Press the "MFB" button for 1 second to transfer a voice call between the mobile phone and the headphones during an ongoing call.
Reject Call	Press the "MFB" button for 2 seconds to reject a call.
Activate Siri or other Voice assistant	Double press the "MFB" button to activate Siri or other Voice assistant.

Turn off Siri or other Voice assistant	Double press the "MFB" button to turn off Siri or other Voice assistant.
--	--

4.2. Pairing to a Mobile Phone or Other Device

To pair your SoulSound 2 headphones with a phone or a computer, please follow the steps below. Once your device is paired to a specific device they will remain paired and will automatically recognize each other whenever they are within range and Bluetooth is switched on.

Steps for pairing to a Bluetooth-enabled device

1. Turn on your device and activate the Bluetooth mode.
2. Turn on the Paww SoulSound 2 headphones and enter Pairing Mode by pressing the "MFB" button for 3 seconds.
3. On your Bluetooth-enabled device, scan or search for new devices. Please refer to the device's user guide for more information on how to do this.
4. Select SoulSound 2 from the list of new devices available.
5. If asked for a Pass Key or PIN, enter 0000.
6. If asked to confirm the pairing, press Yes.

4.3. Connecting to Two Devices Simultaneously

1. Pair the PureSound headphones to your first device using the steps described in section 4.2.
2. Once paired successfully, turn the headphones and Bluetooth function on the first device off.
3. Turn on the headphones.
4. Now pair the headphones to your second device using the steps described in section 4.2.
5. Once pairing is successful with the second device, turn Bluetooth on in the first device.
6. Click "SoulSound 2" on the first device, now two devices are connected to the same headphones.

Note:

1. When reconnecting, the headphones will automatically connect to one of the two devices automatically. To connect the second device, you will have to go to Bluetooth settings and select SoulSound 2 from the list of available devices.
2. To switch sources when listening to music, press pause on the device playing the music, and press play on the second device. There may be a few second gap before the switchover happens.

4.3. Charging your device

A USB cable is needed to charge the headset and a 5V output DC adapter. Before using the device, make sure to charge for at least 6 hours prior to initial use. When charging, the LED indicator will show a solid red light. When the device is fully charged, the LED indicator turns to blue. Headphones will automatically turn off when charging.



5. Technical Specifications

Parameter	Value
Bluetooth Specification	Bluetooth 4.1
Supported Bluetooth Profiles	A2DP1.2/ AVRCP1.4/ HSP1.2 /HFP1.6
Battery Capacity	500 mAh
Operating Distance	10 m
Frequency Response	20Hz-20KHz
Impedance	32Ω±15%(at 1KHz)
Sensitivity	112dB ±3
Speaker Dimension	40mm
Playback Time	about 17 hours
Charging Time	about 2.5 hours
Dimension (L×W×H)	203×170×94mm
Weight	270g

6. Warranty

The Paww SoulSound 2 headphones ship with a 1-year warranty. If you do encounter any issues during this time, you can initiate a warranty claim by contacting us via email on support@mypaww.com or through the Contact Us page on our website (<https://www.mypaww.com/pages/contact-us>).

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.