


# SM-LF-EJ-T12-V1, 材质:105g哑粉纸, 双面彩印, 骑马钉, 成品尺寸: 63\*85mm

英

SM-LF-EJ-T12-V1



Thank you for purchasing our products. This manual addresses the safety guidelines, warranty and operating instructions. Please review this manual thoroughly before operating your device.

**EU REP** Business name: AMZLAB GmbH  
Business address: Laubenhof 23/45326 Essen

**FCC Statement:**  
This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.  
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.  
This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
--Reorient or relocate the receiving antenna.  
--Increase the separation between the equipment and receiver.  
--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
--Consult the dealer or an experienced radio/TV technician for help.  
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
FCC Radiation Exposure Statement  
This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.  
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**English Version**

Package Contents.....1  
At a Glance.....1  
How to Wear.....2  
Earbuds LED Indicator Guide.....3  
Charging Case Indicator Guide.....4  
Using Your T12.....5  
FAQS.....12  
Specifications.....15  
Safety And Warranty.....16


**Deutsche Version**

Verpackungsinhalt.....21  
Auf einen Blick.....21  
Tragweise.....22  
Anleitung Ohrstöpsel LED Anzeige.....23  
Anleitung Ladebehälter-Anzeige.....24  
Benutzung Ihrer T12.....25  
FAQS.....32  
Spezifikationen.....36  
Sicherheit Und Garantie.....37

**Package Contents**


- Wireless Earbuds × 1 pair (Left and Right)
- Charging Case × 1
- Micro USB cable × 1
- User Manual × 1

**At a Glance**



MFB button, LED Indicator, Microphone, Charging Contacts

**Charging Case**



Earbud Placement Indicator, Charging Case Indicator, Charging Pins, Micro USB Port

**How to Wear**

Insert the earbuds into your ear and rotate to fit comfortably.

**Earbuds LED Indicator Guide**

System State	Indicator Activity
Power On	The LED indicator flashes white once.
Power Off	The LED indicator flashes orange once.
Pairing Mode	The LED indicator flashes white and orange alternately.
Connected	The LED indicator goes out.
Charging	The LED indicator stays orange.

**Charging Case Indicator Guide**

Charging case is being charged:

Charging Percentage	Indicator Activity
0-25%	The charging case indicator flashes orange once every 2 seconds.
25-50%	The charging case indicator flashes orange twice every 2 seconds.
50-75%	The charging case indicator flashes orange three times every 2 seconds.
75-99%	The charging case indicator flashes orange four times every 2 seconds.
100%	The charging case indicator stays orange.

**Disconnect the charging case from power source/put earbuds back into the charging case:**

System State	Indicator Activity
Earbuds are being charged	The charging case indicator stays orange.
Earbuds are fully charged	The charging case indicator will not show.

**Using Your T12**

**Charge the earbuds**

- 1) Put the earbuds into the charging case. When they are being charged, the charging case indicator stays orange. When they are fully charged, the charging case indicator will turn off.
- 2) Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.

**Notes:**


- If you don't close the charging case cover, the earbuds will not be off. Please remember to close the cover to avoid unwanted power consumption.

When the earbuds are in low battery, you will hear a voice reminder prompt every 20 seconds until the earbuds turn off automatically.

- It takes approximately 1.5 hours to fully charge your earbuds.
- When you put the earbuds into the charging case and close the cover, the earbuds turn off automatically. Once you open the charging case cover, they turn on automatically. When you take them out, they will enter into pairing mode automatically.

**Charge the charging case**

- 1) Plug the small end of the USB cable into the Micro USB port of the charging case.
- 2) Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.



**Notes:**

- It takes approximately 2 hours to fully charge the charging case. A fully charged charging case can charge the earbuds 5 times.
- The earbuds and the charging case are charged simultaneously. The charging case can also be used as a standalone charger.
- When the charging case battery life is low, the earbud placement indicator will flash slowly for 30 seconds when you open the charging case.

**Power On & Off**

**Automatic Operation**  
**Power On:** Open the cover of the charging case and take the earbuds out.  
**Power Off:** Put the earbuds back to the charging case and close the cover.

**Manual Operation**  
**Power On:** Press and hold the MFB buttons on both earbuds for 2 seconds.  
**Power Off:** Press and hold the MFB buttons for 6 seconds.

**Note:**

- When both earbuds are paired with your phone, turn off

either the left or right earbud manually, the other earbud will be turned off at the same time.

**Pairing & Connectivity**

**Pairing Both Earbuds (Standard Use)**

- 1) Turn on the Bluetooth of your Bluetooth device.
- 2) Take out both of the earbuds from the charging case and they will enter into pairing mode.
- 3) Choose "T12" from the list of found Bluetooth devices on your Bluetooth device to pair.

**Pairing One Earbud (Mono use)**

When the earbuds have not paired with a Bluetooth device:

- 1) Turn on the Bluetooth of your Bluetooth device.
- 2) Turn off either of the earbuds from the charging case.
- 3) Turn off the earbud manually.
- 4) Long press the MFB button of the earbud for 6 seconds in the shutdown state and the earbud will enter into pairing mode.
- 5) Choose "T12" from the list of found Bluetooth devices on your Bluetooth device to pair.

When the earbuds have paired with a Bluetooth device:

- 1) Turn on the Bluetooth of your Bluetooth device.
- 2) Take out either of the earbuds from the charging case.
- 3) Wait the earbud to reconnect to the last paired Bluetooth device and then close the charging case cover.

**Notes:**

- Make sure the earbuds and your Bluetooth device are next to each other within 10 meters (32.8 feet) and there are no obstacles between.
- The earbuds will connect to the last paired Bluetooth device automatically when they are turned on. Please turn on the Bluetooth of your Bluetooth device before turning on the earbuds.
- If pairing fails, put the earbuds back into the charging case, close the cover and make sure that they have been turned off. Then take them out of the charging case and pair the earbuds with your Bluetooth device again following the steps in the previous part "Pairing & Connectivity".
- When the earbuds are on but not paired with a Bluetooth device they will exit the pairing mode and automatically turn off in 10 minutes.

**Headphone Functions**

Function	What to do
Play/Pause	Press the MFB button
Next Track	Long press MFB button of the right earbud for 2 seconds
Previous Track	Long press MFB button of the left earbud for 2 seconds

**Call functions**

Function	What to do
Answer/end a Call	Press the MFB button
Decline an incoming Call	Long press the MFB button of the left/right earbud for 2 seconds

**Activate Voice Control**

Double press the MFB button when the earbuds are in the standby/music playing state. Double press the MFB button again to exit. (This function works only when your phone has voice control activated; please refer to the instructions of your phone for details.)

**Master/Slave mode**

These earbuds have master-slave switch function.

- When the earbuds have been connected to a Bluetooth device, take out either of the two earbuds, it can be connected and used normally. During this period, you can take out the other one and they will pair with each other so you can use both of the earbuds.
- When both earbuds are connected to your phone, no matter which one is put back to the charging case, you can use the other one without interruption.

**Clean the earbuds pairing list**

- 1) Turn off the earbuds.
- 2) Long press the MFB button for 15 seconds until the LED indicator flashes white and orange twice.

**Clean the earbuds and charging case**

Clean the earbuds and charging case only with a dry, soft cotton swab or equivalent.

**FAQS**

**Q1: Pairing failed?**

**A:** 1) Put the earbuds back to the charging case and make sure that they are off.  
2) Take the earbuds out of the case and they are automatically on.  
3) Wait that the indicator on the earbuds flash white and orange alternately and earbuds enter pairing mode.  
4) Choose "T12" in your phone to pair.

If the pairing still fails, check the following points:

- Make sure the earbuds and your Bluetooth device are next to each other or within 10 meters (32.8 feet) and there are no obstacles between.
- There are no signal interferences nearby (check the question "Connection is not stable" for signal interference conditions).
- Try to reboot your Bluetooth device.

**Q2: Earbuds are connected to phone A, but I want to pair earbuds with phone B when I am not able to disconnect earbuds from phone A?**

**A:** 1) Turn off the Bluetooth of phone A, and the earbuds enter into pairing mode.  
2) Choose "T12" in phone B to pair.

**Q3: I paired the earbuds with my phone before, but I failed to pair them to my phone again?**

**A:** Turn on the Bluetooth of your phone and in "My Devices", choose "T12" and tap "O" → "Forget This Device". Then pair the earbuds with your phone again following the steps in the previous part "Pairing & Connectivity".

**Q4: Connection is not stable?**

**A:** Make sure that the Bluetooth connection distance is within 10 meters (32.8 feet) and there is no object between the earbuds and your Bluetooth device, no radio or WiFi interference nearby.

**Q5: Power runs out fast?**

**A:** The earbuds playtime varies according to the volume level and audio content. The following conditions may cause fast power consumption:

- When charging the earbuds, make sure you close the charging case cover to avoid unwanted power consumption. (If you don't close the charging case cover, the earbuds will not be off.)

- When the charging case is out of power, you put the earbuds back into the case and close the case, the earbuds will not turn off automatically. To avoid unwanted power consumption, turn off the earbuds manually.
- When the charging case is out of power while charging the earbuds, the earbuds will turn on automatically. To avoid unwanted power consumption, turn off the earbuds manually.

**Specifications**

Model	T12
Bluetooth Version	V5.0
Battery	30mAh (each earbud), 500mAh (charging case)
Charging Time	1.5 hours (earbuds), 2 hours (charging case)
Adapter	DC 5V/1A
Music Playing/Call Time	Approx. 4 hours per charge (approx. 24 hours (with charging case))
Bluetooth Connection Distance	Up to 10 meters (32.8 feet)
Supporting Protocols	A2DP/HFP/HSP/AVRCP/SPP
Working Temperature	-10°C ~ 40°C

**Safety And Warranty**

**Important Safety Instructions**

- Use of earbuds will impair your ability to hear other sounds. Use caution while using your earbuds when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy – never allow children to play with this product. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.

- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- Keep all products, cords, and cables away from operating machinery.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact us.
- Do not use in areas where there are explosive hazards.
- Do not submerge the earbuds in water. Do NOT expose the earbuds to moving water (e.g., from a faucet, etc.).
- Do not wear the earbuds while showering or bathing, or when participating in water sports, e.g., swimming, waterskiing, surfing, etc.
- This product contains magnetic material. Consult your physician on whether this might affect your implantable medical device.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the earbuds.
- Dispose of the product according to local standards and regulations.

**Note:** Always drive safely, avoid distractions and follow local laws!

- Using the earbuds while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of the earbuds with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws.
- Use caution while using your earbuds when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the earbuds from your ear or turning off your earbuds will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.
- When using and charging this product, basic precautions should always be followed, including the following:
  - Read all the instructions before using the charging case.
  - To reduce the risk of injury, close supervision is necessary when the charging case is used near children.
  - Do not expose charging case to water, rain, liquids or snow.
  - Use of a power supply or charger that is not recommended or sold by power pack manufacturer may result in a risk of fire or injury.

- Do not use the charging case in excess of its output range.
- Do not use a charging case that is damaged or modified. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion or risk of injury.
- Do not disassemble the charging case. Incorrect reassembly may result in risk of fire or injury.
- Do not open, crush or expose a charging case to fire or excessive temperature. Exposure to fire or extreme temperature may cause explosion.
- Have servicing performed by a qualified repair person using only identical replacement parts.

**Warranty**

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of defect.

We are happy to offer a one-year hassle-free warranty to support our customers as we continue to make amazing wireless products. Please contact us if you have any questions about our devices.





Letsfit®

Echte Funk-Ohrhörer Bedienungsanweisung


T12

Vielen Dank für den Kauf unserer Produkte. Dieses Handbuch richtet sich an die Sicherheitsrichtlinien, Garantie und Bedienungsanleitung. Bitte lesen Sie diese Anleitung sorgfältig durch, bevor Sie Ihr Gerät in Betrieb nehmen.


Verpackungsinhalt

- Funk-Ohrhörer x 1 Paar (Links und Rechts)
Ladebehälter x 1
Mikro-USB Kabel x 1
Bedienungsanweisung x 1

Auf einen Blick



Ladebehälter-Anzeige



Tragweise

Führen Sie die Ohrstöpsel in Ihren Ohren ein und drehen Sie sie, um sie komfortabel anzupassen.



Anleitung Ohrstöpsel LED Anzeige

Table with 2 columns: Status des Systems, Aktivitätsanzeige. Rows include Einschalten, Ausschalten, Kopplungs-Modus, Verbunden, Wird aufgeladen.

Anleitung Ladebehälter-Anzeige

Table with 2 columns: Ladeprozent, Aktivitätsanzeige. Rows show battery levels from 0-25% to 100%.

Trennen des Ladebehälters von der Stromversorgung/Einsetzen der Ohrhörer im Ladebehälter:

Table with 2 columns: Status des Systems, Aktivitätsanzeige. Rows show earbuds being removed or fully charged.

Benutzung Ihrer T12


- Aufladen der Ohrhörer
1) Legen Sie die Ohrhörer im Ladebehälter ab...
2) Schließen Sie den Ladebehälter, wenn die LED Anzeige orange bleibt.

- Hinweis: Wenn Sie den Ladebehälter nicht schließen, werden die Ohrhörer nicht ausgeschaltet sein.

- Wenn der Akkustand der Ohrhörer niedrig ist, werden Sie eine Stimme, die Sie jede 20 Sekunden zum Laden anleitet hören...

- Es ist ungefähr 1,5 Stunde notwendig, um die Ohrhörer komplett aufzuladen.
Wenn Sie die Ohrhörer im Ladebehälter ablegen und Sie den Deckel schließen...

- Laden des Ladebehälters
1) Stecken Sie das kleine Ende des USB Kabels im Mikro-USB Anschluss des Ladebehälters.



Hinweis:

- Es dauert ungefähr 2 Stunden, bis die Ohrhörer komplett aufgeladen sind.
Die Ohrhörer und der Ladebehälter werden gleichzeitig geladen.

Ein-/Ausschalten

Automatischer Betrieb
Einschalten: Öffnen Sie die Abdeckung des Ladebehälters und nehmen Sie die Ohrhörer heraus.

Manueller Betrieb
Einschalten: Drücken und halten Sie die MFB Tasten oder beide Ohrhörer 2 Sekunden lang.

Hinweis:

Wenn beide Ohrhörer mit Ihrem Telefon verbunden sind, schalten Sie entweder den linken oder rechten Ohrhörer, und der andere wird ebenfalls ausgeschaltet.

Verbindung und Anschluss

- Verbinden Sie beide Ohrhörer (Paar Nutzung)
1) Schalten Sie die Bluetooth Verbindung Ihres Bluetooth-Geräts ein.
2) Nehmen Sie beide Ohrhörer aus dem Ladebehälter...

Verbinden Sie EIN Ohrhörer (einzelne Nutzung)
Wenn die Ohrhörer nicht mit einem Bluetooth Gerät verbunden wurden:

- 1) Schalten Sie die Bluetooth Verbindung Ihres Bluetooth-Geräts ein.
2) Entnehmen Sie eines der Ohrhörer aus dem Ladebehälter.

Sekunden lang, im Ausschaltmodus und die Ohrhörer gehen im Verbindungsmodus.

- Wählen Sie „T12“ aus der Liste der gefundenen Bluetooth Geräte, mit denen sich Ihr Bluetooth Gerät verbinden kann.

Wenn die Ohrhörer mit einem Bluetooth Gerät verbunden wurden:

- 1) Schalten Sie die Bluetooth Verbindung Ihres Bluetooth-Geräts ein.
2) Entnehmen Sie eines der Ohrhörer aus dem Ladebehälter.

Hinweis:

- Verriegeln Sie sich, dass die Ohrhörer und Ihr Bluetooth Geräte höchstens 10 Meter (32,8 Fuß), ohne Hindernisse, voneinander entfernt sind.
Die Ohrhörer werden sich automatisch mit dem letzten gekoppelten Gerät verbinden...

- Falls die Verbindung fehlergeschlagen ist, legen Sie die Ohrhörer zurück im Ladebehälter, schließen Sie den Deckel und vergewissern Sie sich, dass sie ausgeschaltet wurden.

- Falls die Ohrhörer eingeschaltet, aber mit einem Bluetooth-Gerät nicht verbunden sind, werden Sie den Kopplungs-Modus verlassen und sich automatisch innerhalb von 10 Minuten ausschalten.

Funktionen der Kopfhörer

Table with 2 columns: Funktion, Was zu tun ist. Rows include Wieder-gabe/Pause, Nächster Titel, Voriger Titel.

Anruf-Funktionen

Table with 2 columns: Funktion, Was zu tun ist. Rows include Einen Anruf annehmen/beenden, Einen eingehenden Anruf abweisen.

Die Sprachsteuerung des Telefons aktivieren

Drücken Sie die MFB Taste zwei Mal, wenn die Ohrhörer im Standby-/Wiedergabe-Modus sind. Und drücken Sie die MFB Taste erneut zwei Mal, um zu beenden.

Master-/Slave-Modus

Diese Ohrhörer haben eine Master-Slave Schaltfunktion. Wenn die Ohrhörer am Bluetooth Gerät angeschlossen sind, entnehmen Sie eines von ihnen und sie können ihn normal verbinden und hören.

- Wenn beide Ihrer Ohrhörer am Telefon angeschlossen sind, können Sie eines davon entnehmen, es im Ladebehälter legen, und Sie können den anderen ohne Unterbrechung nutzen.

Löschen der Verbindungsliste der Ohrhörer

- 1) Schalten Sie den Ohrhörer aus.
2) Drücken Sie bitte die MFB-Taste 15 Sekunden lang, bis die LED Anzeige weiß und orange 2 mal blinkt.

Reinigung der Ohrhörer und des Ladebehälters

Reinigen Sie die Ohrhörer und den Ladebehälter nur mit einem trockenen, weichen Wattestäbchen oder Ähnlichem.

FAQS

F1: Verbindung fehlergeschlagen

- A:1) Legen Sie die Ohrhörer zurück im Ladebehälter und vergewissern Sie sich, dass sie ausgeschaltet sind.
2) Nehmen Sie die Ohrhörer aus dem Ladebehälter und sie sind automatisch eingeschaltet.
3) Warten Sie, bis die Anzeige der Ohrhörer abwechselnd weiß und orange blinkt und die Ohrhörer im Verbindungsmodus gehen.

- 4) Wählen Sie „T12“ in der Verbindungsliste des Telefons.
Falls die Verbindung trotzdem nicht klappt, versuchen Sie folgendes:

- Vergewissern Sie sich, dass die Ohrhörer und Ihr Bluetooth Geräte nebeneinander oder höchstens 10 Meter (32,8 Fuß), ohne Hindernisse, voneinander entfernt sind.
• Das es keine Signalinterferenzen in der Nähe gibt (prüfen Sie die Frage „Die Verbindung ist nicht stabil“ bezüglich den Interferenzbedingungen).
• Versuchen Sie Ihr Bluetooth Gerät neu zu starten.

F2: Die Ohrhörer sind mit dem Telefon A verbunden, aber Sie möchten Sie mit dem Telefon B verbinden, aber diese können von Telefon A nicht getrennt werden.

A:1) Schalten Sie die Bluetooth Verbindung des Telefons A aus, und die Ohrhörer gehen im Verbindungsmodus über.

- 2) Wählen Sie „T12“ im Telefon B, um zu verbinden.

F3: Ich habe die Ohrhörer mit meinem Telefon gekoppelt, aber die Neuverbindung ist fehlergeschlagen.

A: Schalten sie die Bluetooth-Verbindung Ihres Telefons ein und wählen Sie in „MEINE GERÄTE“, „T12“ und drücken Sie „D“ -> „Gerät vergessen“. Koppeln Sie danach die Ohrhörer erneut zu Ihrem Telefon und befolgen Sie die Schritte des vorigen Kapitels „Verbindung und Anschluss“.

F4: Die Verbindung ist nicht stabil.

A: Vergewissern Sie sich, dass die Entfernung zwischen den Bluetooth Geräten nicht größer ist als 10 Meter (32,8 Fuß) und dass sich kein Gegenstand zwischen den Ohrhörer und den Bluetooth-Gerät befindet, keine Radio- oder WLAN-Interferenzen in der Nähe bestehen.

F5: Die Ohrhörer entladen sich schnell.

A: Die Spieldauer der Ohrhörer ist unterschiedlich, entsprechend der Lautstärke und des Audio-Inhalts. Folgende Bedingungen können einen erhöhten Verbrauch hervorrufen:
• Wenn Sie die Ohrhörer aufladen, vergewissern Sie sich, dass Sie den Ladebehälter geschlossen haben, um einen unnötigen Stromverbrauch auszuschließen.
• Wenn Sie den Ladebehälter nicht schließen, werden die Ohrhörer nicht ausgeschaltet sein.

- Falls der Ladebehälter entladen ist, und Sie die Ohrhörer darin einsetzen und den Behälter schließen, werden die Ohrhörer nicht automatisch ausgeschaltet.
• Wenn der Ladebehälter sich während des Aufladens der Ohrhörer entlädt, werden die Ohrhörer automatisch eingeschaltet.
• Wenn Sie den Ladebehälter manuell aus.

Spezifikationen

Table with 2 columns: Modell, Bluetooth Version, Batterie, Ladedauer, Adapter, Musikwiedergabe/Anrufdauer, Bluetooth Verbindungsenfernung, Unterstützende Protokolle, Betriebstemperatur.

Sicherheit Und Garantie

Wichtige Sicherheitsanweisungen

- Die Verwendung von Kopfhörer beeinträchtigt die Fähigkeit, andere Geräusche zu hören.
• Setzen Sie Ihr Produkt nicht Regen, Feuchtigkeit oder anderen Flüssigkeiten aus.
• Halten Sie alle Produkte, Kabel und Kabel von den Maschinen fern.
• Wenn das Produkt überhitzt, wenn das Produkt heruntergefallen oder beschädigt wurde, wenn das Produkt ein beschädigtes Kabel oder einen beschädigten Stecker aufweist...
• Versuchen Sie niemals, das Produkt selbst zu zerlegen oder Gegenstände jeglicher Art in das Produkt zu stecken...

Wenn Teile Ihres Produkts aus irgendeinem Grund zerstört werden müssen, einschließlich normaler Abnutzung oder Bruch kontaktieren Sie uns bitte.

- Setzen Sie Ihr Produkt nicht Regen, Feuchtigkeit oder anderen Flüssigkeiten aus.
• Halten Sie alle Produkte, Kabel und Kabel von den Maschinen fern.
• Wenn das Produkt überhitzt, wenn das Produkt heruntergefallen oder beschädigt wurde...

aufbewahren, z. B. in einem geschlossenen Auto unter Sommer- und Winterbedingungen, verringern sich die Kapazität und die Lebensdauer der Kopfhörer.

- Entsorgen Sie das Produkt gemäß den örtlichen Normen und Vorschriften.

Merkmale:

- Fahren Sie immer sicher, vermeiden Sie Ablenkungen und befolgen Sie die örtlichen Gesetze.
• Die Verwendung der Kopfhörer beim Bedienen eines Kraftfahrzeuges, Motorrads, Wasserfahrzeugs oder Fahrrads kann gefährlich sein.
• Überprüfen Sie Ihre örtlichen Gesetze. Seien Sie vorsichtig, wenn Sie Ihre Ohrstöpsel verwenden, wenn Sie an Aktivitäten teilnehmen...

beachtet werden, einschließlich der folgenden:

- Lesen Sie alle Anweisungen, bevor Sie den Ladebox verwenden.
• Um das Verletzungsrisiko zu verringern, ist eine genaue Überwachung erforderlich, wenn das Ladegerät in der Nähe von Kindern verwendet wird.
• Setzen Sie den Ladekoffer nicht Wasser, Regen, Flüssigkeiten oder Schnee aus.
• Verwenden Sie ein Netzteil oder ein Ladegerät, das nicht empfohlen wird oder vom Hersteller des Netzteils verkauft werden, kann dies zu Feuer oder Verletzungen führen.
• Verwenden Sie keinen Ladekoffer, der außerhalb seines Leistungsbereichs liegt.
• Verwenden Sie kein Ladegerät, das beschädigt oder modifiziert ist.

Reparaturen werden nur von qualifiziertem Servicepersonal unter Verwendung der gleichen Ersatzteile ausgeführt.

Garantie

Wir bemühen uns darum, das Produkt mit Sorgfalt und fortgeschrittenen Technologien herzustellen. Wenn Sie das defekte Produkt erhalten haben, wir bieten Ihnen eine einjährige, problemlose Garantie für alle unsere Produkte.

- Verwenden Sie kein Ladegerät, das beschädigt oder modifiziert ist.
• Zerlegen Sie den Ladekoffer nicht.
• Öffnen oder zerquetschen Sie den Ladekoffer nicht und setzen Sie ihn nicht Feuer oder übermäßiger Temperatur aus.

FCC ID: 2AR5E-T12

NOTE: This equipment has been tested and found to comply with the limits for Class B digital devices, in alignment with section 15 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception...