

品名:	T19说明书 (中性通用)	材料 工艺:	成品尺寸: 52*82mm 双面单黑印刷, 骑马钉 85g哑粉纸
时间:	2020-03-20		
制作:	王润婷		
料号:	WH-EJ-T19-V1		

封底

封面


英

FCC ID: 2A8674T

NOTE: The equipment has been tested and found to comply with the limits for Class B digital devices, as defined in part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to other wireless devices. This equipment generates uses and can be affected by radio frequency interference and its operation may be limited by the conditions of a license agreement with the FCC. This equipment does not emit radio frequency interference that exceeds the limits specified in part 15 of the FCC Rules, provided that the operating instructions are followed. If you are experiencing interference problems, you should attempt to correct the interference by reorienting the equipment, using a different power outlet, or using a different power outlet. If the interference persists, contact the manufacturer for assistance. The manufacturer is not responsible for any interference caused by unauthorized modifications to this equipment. Any such modifications could void the warranty and may affect the operation of the equipment. This device may not be used in all countries. Please refer to the instructions for use for more information. © 2020 Shenzhen Hengsheng Technology Co., Ltd. All rights reserved. Shenzhen Hengsheng Technology Co., Ltd. is not responsible for any interference caused by unauthorized modifications to this equipment. Any such modifications could void the warranty and may affect the operation of the equipment. This device may not be used in all countries. Please refer to the instructions for use for more information.

T19
True Wireless Stereo
ANC Earbuds

User Manual



Thank you for purchasing our product. This manual addresses the safety guidelines, warnings, and operating instructions. Please review this manual thoroughly before operating your device.


English Version	Deutsche Version
Package Contents.....1	Paaketin sisältö.....21
At a Glance.....1	Überblick.....21
How to Wear.....2	Wie trägt man.....22
Earbuds LED Indicator Guide.....3	Earbuds LED-Anzeiger des Herstellers.....22
Charging Case Indicator Guide.....3	Aktivierung der Ladestation.....22
Using Your T19.....5	Verwendung Ihres T19.....22
FAQs.....11	Fragen und Antworten.....23
Specifications.....14	Spezifikationen.....24
Safety and Warranty.....15	Sicherheit und Garantie.....25

Package Contents

- Wireless Earbuds × 1 pair (left and right)
- Charging Case × 1
- USB Type-C Cable × 1
- Ear Tips × 3 pairs (S/M/L)
- User Manual × 1


At a Glance

Earbuds




Charging Case

Charging Case Indicator



How to Wear



Earbuds LED Indicator Guide

System State	Indicator Activity
Power on	● ● ● ●
Pairing mode	● ● ● ●
Charging	● ● ● ●
Fully Charged	● ● ● ●

When the charging case is being charged, you can see the charging case indicator activity every time you open the lid.

Charging Case Indicator Guide

System State	Indicator Activity
0-3%	● ● ● ●
3-60%	● ● ● ●
60-100%	● ● ● ●
Fully Charged	● ● ● ●

Battery Percentage	Indicator Activity
60-100%	● ● ● ●
3-60%	● ● ● ●
0-3%	● ● ● ●
Low Battery	● ● ● ●

When the charging case is being charged, you can see the charging case indicator activity every time you open the lid.

Using Your T19

Charge the earbuds
Put the earbuds into the charging case and close the lid.

Notes:

- When the charging case with the lid open does not detect the earbuds within 10 minutes, it enters into sleep mode and cannot charge the earbuds. Please close the lid and open it again to activate the charging case.
- When your earbud battery life is low, you will hear a voice reminder prompts every 5 minutes until the earbuds turn off automatically.

Charge the charging case

- 1) Plug the small end of the USB cable into the Type-C port of the charging case.
- 2) Plug the other end into a USB wall charger or computer (DC 5V) that is powered on.

Power on & off

Power on: Take the earbuds out of the charging case.

Power off: Put the earbuds back into the charging case.

Pairing & Connectivity

- 1) Turn on the Bluetooth of your Bluetooth device.
- 2) Open the lid of the charging case and take the earbuds out of the Bluetooth device. The two earbuds will first pair.

with each other. Then they will enter pairing mode automatically (the LED indicator on the earbuds will flash red and green alternately).

3) Choose "T19" from the list of found Bluetooth devices on your Bluetooth device to pair.

Notes:

- Make sure the earbuds and your Bluetooth device are next to each other within 33 feet or 10 meters and there are no obstacles between.
- If pairing failed, put the earbuds back into the charging case and make sure that they have been turned off. Then pair the earbuds with your Bluetooth device again.
- When the earbuds are on but not paired with a Bluetooth device, they will be automatically off after 10 minutes.
- The earbuds will connect to the last paired Bluetooth device automatically when they are turned on. Please turn on the Bluetooth of your Bluetooth device before turning on the earbuds.

Headphone functions

Function	What to do
Play / Pause	Double-tap the touch button of the left / right earbud.
Next track	Triple-tap the touch button of the right earbud.
Previous track	Triple-tap the touch button of the left earbud.
Volume up	Tap the touch button of the right earbud once to increase one level.
Volume down	Tap the touch button of the left earbud once to decrease one level.

Call functions

Function	What to do
Answer a call	Tap the touch button of the left / right earbud.
End a call	Double-tap the touch button of the left / right earbud.
Check an incoming call	Tap and hold the touch button of the left / right earbud for 2 seconds.

ANC function

When the two earbuds are connected to your phone, tap and hold the touch button of the right earbud for 2 seconds and you will hear a "beep" sound. Tap and hold the touch button of the right earbud again to exit the ANC mode.

Single earbud mode (right earbud only)

When the phone, you can put the left earbud back into the charging case and use the right earbud alone.

Clear the earbuds pairing list

Put the earbuds back into the charging case and make sure they are being charged (the LED indicator on the earbuds stops red).

Then tap and hold the touch buttons of both earbuds for about 10 seconds simultaneously until you see the LED indicator on the earbud flashes red three times.

Note:

When using the right earbud alone, you can play / pause music to activate the phone's voice control, but you cannot switch songs or adjust the volume.

FAQs

Q1: Pairing fails

- 1) Put the earbuds back into the charging case and make sure that they are off.
- 2) Take the earbuds out of the charging case and the earbuds will enter pairing mode automatically.
- 3) Choose "T19" as your phone to pair.

If the pairing still fails, check the following points:

- Make sure the earbuds and your Bluetooth device are next to each other or within 33 feet or 10 meters and there are no obstacles between.
- There are no signal interference nearby (check the question "Connection not stable" for signal interference conditions).
- Try to reboot your Bluetooth device.

Q2: I paired the earbuds with my phone before, but failed to pair them with my phone again.

- 1) Turn on the Bluetooth of your phone and go to "MY DEVICES", choose "T19" and tap "GT" → "Forget This Device". Then pair the earbuds with your phone again.

Q3: Connection is not stable.

- 1) Make sure that the Bluetooth connection distance is within 33 feet or 10 meters and there is no object between the earbuds and your Bluetooth device, no radio or WiFi interference nearby.

Q4: When playing music, the left and right earbuds cannot be synchronized.

- 1) Please try to put the earbuds back into the charging case. If your earbuds still can not work, please contact us.

Q5: Power runs out fast.

- 1) The earbuds' playtime varies according to the volume level and audio content. In addition, if the ANC mode is turned on for a long time, the power consumption will be faster than in a normal mode.
- 2) Please try to put the earbuds back into the charging case, close the lid, wait for about 10 seconds, then use them to reboot them. If your earbuds still can not work, please contact us.

My earbuds do not work.

- 1) If you have a pedometer or other electrical medical device, you should consult your physician before using this product.
- 2) This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy—never allow children to play with the product. Always store the product out of reach from children. The small items or the many small parts they contain may cause choking if ingested.
- 3) Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.

Specifications

Model	T19
Bluetooth Version	V5.0
Battery	20mAh (each earbud), 200mAh (charging case)
Charging Time	Approximately 1 hour (earbuds), 2 hours (charging case)
Waterproof Rate	IPX7
Input Rating	DC 5V 1mA
Music Playing / Call Time	Up to 5.5 hours per charge (ANC off) Up to 3.5 hours per charge (ANC on) Up to 20 hours per charge (ANC off) Up to 7 hours per charge (ANC on)
Bluetooth Connection Distance	Up to 33 feet or 10 meters (no obstacle between)
Support Protocol	A2DP/HSP/HFP/HWMP
Working Temperature	-10°C to 40°C

Safety and Warranty

Important safety instructions

- Use of earbuds will impair your ability to hear other sounds. Use caution while using your earbuds when you are engaging in any activity that requires your full attention.
- If you have a pedometer or other electrical medical device, you should consult your physician before using this product.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy—never allow children to play with the product. Always store the product out of reach from children. The small items or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.

• None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact us.

• Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.

• Keep all products, cords, and cables away from operating machinery.

• If the product overheat, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact us.

• Do NOT use in areas where there are explosive hazards.

• Do NOT submerge the earbuds in water. Do NOT expose the earbuds to moving water (e.g., from a faucet, etc.).

• Do NOT wear the earbuds while swimming or bathing, or when participating in water sports, e.g., swimming, water skiing, surfing, etc.

• This product contains magnetic material. Consult your physician on whether the magnet effect your medicine/medical devices.

• Leaving the product in hot or cold places, such as in a disposal car in the summer and winter conditions, will reduce the capacity and lifetime of the earbuds.

• Dispose of the product according to local standards and regulations.

Note: Always drive safely, avoid distractions and keep your focus!

• Using the earbuds while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and it might in some jurisdictions, just as use of the earbuds with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws.

• Use with caution while using your earbuds when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the earbuds from your ear or turning off your earbuds will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.

• When using and charging this product, basic precautions should always be followed, including the following:


- 1) Read all the instructions before using the charging case.
- 2) To reduce the risk of injury, close suspension is necessary when the charging case is used near children.
- 3) Do not open, crush or expose a charging case to fire or excessive temperature. Exposure to fire or extreme temperature may cause explosion.
- 4) Have servicing performed by a qualified repair person using only original replacement parts.

Warranty

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of defects.

We are happy to offer a one-year hassle-free warranty to all our products. We are confident to make amazing products. Please contact us if you have any questions about our devices.

T19
Echtes Wireless Stereo
ANC Ohrhörer
Bedienungsanleitung



• Do not use a charging case that is damaged or modified. Damaged or modified batteries may result in unpredictable behavior resulting in fire, explosion or risk of injury.

• Do not disassemble the charging case. Incorrect assembly may result in risk of fire or injury.

• Do not open, crush or expose a charging case to fire or excessive temperature. Exposure to fire or extreme temperature may cause explosion.

• Have servicing performed by a qualified repair person using only original replacement parts.

Warranty

We strive to build our products with the highest attention to detail and craftsmanship. However, sometimes there are occurrences of defects.

We are happy to offer a one-year hassle-free warranty to all our products. We are confident to make amazing products. Please contact us if you have any questions about our devices.

德

Paketinhalt

- Bluetooth Kopfhörer x 1 Paar (links und rechts)
- Ladestecker x 1
- USB-Type-C-Kabel x 1
- Ohrstöpsel x 3 Paare (L / M / S)
- Benutzerhandbuch x 1

Übersicht

Wie trägt man

Setzen Sie den Ohrhörer in Ihr Ohr ein und drehen Sie ihn, um bequem zu passen.

Anleitung zu den LED-Anzeigen (Die Halbkreise)

Systemstatus	Indikatoraktivität
Einstecktast	Das LED-Anzeige am Ohrhörer blinkt einmal grün.
Paarung-Modus	Das LED-Anzeige auf dem rechten Ohrhörer blinkt automatisch rot und grün.
Aufladen	Das LED-Anzeige blinkt rot.
Vollladen	The LED indicator goes off.

Anleitung für Ladestecker

Wenn die Ladestecker nicht aufgeladen wird, können Sie die Aktivität der Ladesteckergänge jedes Mal sehen, wenn Sie den Deckel öffnen.

- der Anzeiger blinkt an
- der Anzeiger erloscht

Batterienormale	Indikatoraktivität
60-100%	● ● ● ●
3-60%	● ● ● ●
6-3%	● ● ● ●
Niedrige Batterie	● ● ● ●

Wenn der Ladestecker aufgeladen wird,

Systemstatus	Indikatoraktivität
0-3%	● ● ● ●
3-60%	● ● ● ●
60-100%	● ● ● ●
Volll aufgeladen	● ● ● ●

Verwenden Ihres T10

Laden Sie die Ohrhörer auf

Legen Sie die Ohrhörer in den Ladestecker und schließen Sie den Deckel.

Hinweise:

- Wenn die Ladesteckung geöffnet ist, und legen Sie die Kopfhörer nicht in der Box für mehr als 10 Minuten, geht es in den Schlafmodus über und kann die Kopfhörer nicht aufladen. Bitte schließen Sie den Deckel und öffnen Sie ihn wieder, um die Ladesteckung zu aktivieren.
- Wenn die Aktivität Ihres Ohrhörers niedrig ist, hören Sie jede 5 Minute eine Soundchime, Sie sich die Ohrhörer automatisch ausschalten.

Laden Sie den Ladestecker auf

- 1) Schließen Sie das kleine Ende des USB-Kabels an den Typ-C-Anschluss des Ladesteckers an.
- 2) Öffnen Sie den Deckel des Ladesteckers und nehmen Sie die Ohrhörer aus dem Ladestecker. Die beiden Ohrhörer paaren sich zuerst miteinander. Dann werden sie automatisch in den Kopplungsmodus eingeschaltet.

Ein- und Ausschalten

Ein-/Ausfunktion

Drücken Sie die Ohrhörer aus dem Ladestecker, wenn Sie die Ohrhörer wieder in den Ladestecker.

Paarung & Konnektivität

- 1) Schließen Sie das Bluetooth Ihres Bluetooth-Geräts an.
- 2) Öffnen Sie den Deckel des Ladesteckers und nehmen Sie die Ohrhörer aus dem Ladestecker. Die beiden Ohrhörer paaren sich zuerst miteinander. Dann werden sie automatisch in den Kopplungsmodus eingeschaltet.

wird die LED-Anzeige auf dem rechten Ohrhörer blinkt automatisch rot und grün.

- 3) Wählen Sie „T10“ aus der Liste der verfügbaren Bluetooth-Geräte auf Ihrem Bluetooth-Gerät zu koppeln.

Hinweise:

- Stellen Sie sicher, dass sich die Ohrhörer und Ihr Bluetooth-Gerät innerhalb von 33 Fuß oder 10 Metern nebeneinander befinden und die kleine Hindernisse dazwischen gibt.
- Wenn die Kopplung fehlergeschlagen ist, legen Sie die Ohrhörer wieder in den Ladestecker, stellen Sie sicher, dass sie eingeschaltet werden. Koppeln Sie dann die Ohrhörer erneut mit Ihrem Bluetooth-Gerät.
- Wenn die Ohrhörer eingeschaltet, aber nicht mit einem Bluetooth-Gerät gekoppelt sind, werden sie nach 10 Minuten automatisch ausgeschaltet.
- Öffnen Sie die Ohrhörer sich automatisch mit dem zuletzt gekoppelten Bluetooth-Gerät, wenn sie eingeschaltet sind. Bitte schließen Sie das Bluetooth Ihres Bluetooth-Geräts an, bevor Sie die Ohrhörer einschalten.

Funktionen des Headsets

Funktion	Was ist zu tun
Aufladen / Pause	Tippen Sie zweimal auf die Touch-Taste des linken Ohrhörers.
Nachfrage / Lied	Tippen Sie einmal auf die Touch-Taste des linken Ohrhörers.
Vorwärtssprung / Lied	Tippen Sie zweimal auf die Touch-Taste des linken Ohrhörers.
Ladesteckung an/aus	Tippen Sie einmal auf die Touch-Taste des rechten Ohrhörers, um eine Seite zu erfassen.
Ladesteckung verringern	Tippen Sie einmal auf die Touch-Taste des linken Ohrhörers, um eine Seite zu verringern.

Außerfunktions

Funktion	Was ist zu tun
Annehmen eines Anrufs	Tippen Sie auf die Touch-Taste des linken / rechten Ohrhörers.
Beenden eines Anrufs	Drücken Sie auf die Touch-Taste des linken / rechten Ohrhörers.
Einmal annehmen	Tippen und halten Sie den Touch-Taste des linken / rechten Ohrhörers 2 Sekunden lang gedrückt.

ANC-Funktion

Wenn die beiden Ohrhörer mit Ihrem Telefon verbunden sind, tippen und halten Sie die Touch-Taste des linken Ohrhörers für 2 Sekunden, und Sie werden ein „off“ -Ton hören. Tippen und halten Sie die Touch-Taste des linken Ohrhörers für 3-3 Sekunden wieder, um die ANC-Funktion des rechten Ohrhörers einzuschalten.

Einzelohrer-Modus (nur rechter Ohrhörer)

Wenn beide Ohrhörer mit Ihrem Telefon verbunden sind, können Sie den linken Ohrhörer wieder in den Ladestecker stecken und den rechten Ohrhörer allein verwenden.

Hinweise:

Wenn Sie den richtigen Ohrhörer allein verwenden, können Sie Musik abspielen / anhören oder die Sprachsteuerung des Telefons aktivieren, aber Sie können keine Songs wechseln oder die Lautstärke anpassen.

Sprachsteuerung des Telefons aktivieren

Wenn die Ohrhörer mit Ihrem Telefon verbunden sind, tippen und halten Sie die Touch-Taste des linken Ohrhörers für 2-3 Sekunden, und Sie werden ein „off“ -Ton hören. Tippen und halten Sie die Touch-Taste des linken Ohrhörers für 3-3 Sekunden wieder, um die Sprachsteuerung des rechten Ohrhörers einzuschalten.

Löschen Sie die Ohrhörer-Paarungsliste

Legen Sie die Ohrhörer wieder in den Ladestecker und stellen Sie sicher, dass sie geladen werden (Die LED-Anzeige am Ohrhörer blinkt rot). Tippen und halten Sie dann die Touch-Taste beider Ohrhörer für etwa 10 Sekunden gedrückt. Sie Sie sehen, dass die LED-Anzeige auf dem Ohrhörer einmal rot blinkt.

Reinigen Sie die Ohrhörer und den Ladestecker

Reinigen Sie die Ohrhörer und den Ladestecker nur mit einem trockenen, weichen Weichbroschen oder Ähnlichem.

Fragen und Antworten

F1: Die Kopplung schlägt fehl.

- 1) Legen Sie die Ohrhörer wieder auf den Ladestecker und stellen Sie sicher, dass sie ausgeschaltet sind.
- 2) Nehmen Sie die Ohrhörer aus dem Ladestecker und verbinden Sie sie mit Ihrem Bluetooth-Gerät.
- 3) Wählen Sie „T10“ in Ihrem Telefon zu koppeln.

Wenn die Kopplung immer noch fehlerhaft, überprüfen Sie die folgenden Punkte:

- Stellen Sie sicher, dass sich die Ohrhörer und Ihr Bluetooth-Gerät nebeneinander oder innerhalb von 33 Fuß oder 10 Metern befinden und sich kein Gegenstand zwischen den Ohrhörern und Ihrem Bluetooth-Gerät befindet, kein Radio oder WiFi-Signale in der Nähe.
- Es gibt keine Signalstörungen in der Nähe (überprüfen Sie die Frage „Verbindung ist nicht stabil“ für Signalstörungen Bedingungen).
- Versuchen Sie, Ihr Bluetooth-Gerät neu zu starten.

F2: Ich habe die Ohrhörer zuvor mit meinem Telefon gekoppelt, aber ich konnte sie jedoch nicht erneut mit meinem Telefon koppeln.

A: Schalten Sie das Bluetooth Ihres Telefons ein und wählen Sie unter „MEINE GERÄTE“ die Option „T10“ und koppeln Sie auf „Ja“ – „Zuletzt gekoppelt“ vorzuziehen.“ Dann koppeln Sie die Ohrhörer wieder mit Ihrem Telefon.

F3: Die Verbindung ist nicht stabil.

A: Stellen Sie sicher, dass die Bluetooth-Verbindungsentfernung innerhalb von 33 Fuß oder 10 Metern liegt und sich kein Gegenstand zwischen den Ohrhörern und Ihrem Bluetooth-Gerät befindet, kein Radio oder WiFi-Signale in der Nähe.

F4: Wenn Sie die Musik hören, aber der Ton und der rechte Kopfhörer synchronisieren nicht.

A: Versuchen Sie bitte, die Kopfhörer wieder in die Ladesteckung zu stecken, und nehmen Sie sie dann heraus, um sie neu zu starten.

F5: Die Stromversorgung geht schnell aus.

A: Die Wartezeit der Ohrhörer variiert je nach Lautstärke und Audioprofil. Wenn der ANC-Modus längere Zeit eingeschaltet ist, ist der Stromverbrauch außerdem schneller als im normalen Modus.

F6: Meine Ohrhörer funktionieren nicht.

A: 1) Bitte überprüfen Sie, ob die Ohrhörer nicht mehr mit Strom versorgt sind, und legen Sie sie wieder in einen voll aufgeladenen Ladestecker. Wenn Sie den Ohrhörer nicht richtig aufladen können, versuchen Sie, die Ladesteckung an den Ohrhörern und die Ladestecke im Ladestecker zu reinigen.

2) Bitte versuchen Sie, die Ohrhörer wieder in den Ladestecker zu legen, schließen Sie den Deckel, warten Sie etwa 10 Sekunden, und nehmen Sie sie dann heraus, um sie neu zu stecken. Wenn Ihre Ohrhörer immer noch nicht funktionieren können, kontaktieren Sie uns bitte.

Spezifikationen

Modell	T10
Bluetooth-Version	V5.2
Batterie	Rechts (links Ohrhörer), 30mAh (Ladestecker)
Ladesteckung	C2, 3-Banden (Ohrhörer), 2-Banden (Ladestecker)
Wasserdichte Rate	IPX7
Eingangsleistung	DC 3V, 20mA
Musikwiedergabe / Antwortzeit	10 bis 33 Sekunden (je nach ANC) (ANC aus) 10 bis 33 Sekunden (je nach ANC) (ANC ein) 10 bis 33 Sekunden (je nach ANC) (ANC aus)
Bluetooth-Verbindungsreichweite	10 bis 33 Fuß oder 10 Meter (je nach Hindernissen)
Unterstützte Protokolle	A2DP, AVRCP, HSP, HFP
Ambienttemperatur	14°F bis 95°F
	1-31

Sicherheit Und Garantie

Wichtige Sicherheitsanweisungen

- Die Verwendung von Kopfhörern beeinträchtigt die Fähigkeit, andere Geräusche zu hören. Seien Sie vorsichtig, wenn Sie Ihre Ohrstöpsel verwenden, die Ihre volle Aufmerksamkeit erfordern.
- Wenn Sie einen Schrittmacher oder andere elektrische medizinische Geräte besitzen, stellen Sie Ihren Arzt konsultieren, bevor Sie dieses Produkt verwenden.
- Dieses Produkt enthält Materialien, die für Kinder gefährlich sein können und von Kindern unzugänglich aufbewahren. Dieses Produkt ist kein Spielzeug. Lassen Sie niemals Kinder mit diesem Produkt spielen. Bewahren Sie das Produkt immer außerhalb der Reichweite von Kindern auf. Die Töne sind laut und die vielen Minuten Ton. Sie enthalten Wörter, wenn sie verwendet werden.

- Versuchen Sie niemals, das Produkt selbst zu zerlegen oder Gegenstände jeglicher Art in das Produkt zu stecken, da dies zu Kurzschluss führen kann, die einen Brand oder elektrischen Schlag verursachen können.
- Keine der Komponenten kann von Benutzern ausgetauscht oder repariert werden. Nur autorisierte Händler oder Servicecenter dürfen das Produkt öffnen. Wenn Teile Ihres Produkts aus irgendeinem Grund ersetzt werden müssen, einschließlich normaler Abnutzung oder Beschädigung, kontaktieren Sie uns bitte.
- Setzen Sie Ihr Produkt nicht Regen, Feuchtigkeit oder anderen Flüssigkeiten aus, um es vor Schäden am Produkt oder vor Verletzungen zu schützen.
- Halten Sie alle Proctas, Kabel und Kabel von den Maschinen fern.

- Wenn das Produkt überhitzt, wenn das Produkt feuergefährlich oder beschädigt wurde, wenn das Produkt ein beschädigtes Kabel oder einen beschädigten Stecker aufweist, oder wenn das Produkt in eine Flüssigkeit gefallen ist, stellen Sie den Gebrauch ein und kontaktieren Sie uns.
- NICHT in explosionsgefährdeten Bereichen verwenden.
- Die Verwendung von Kopfhörern kann Bedenken eines Kraftfahrzeuges, Motorrads, Wasserrettung oder Patente kann gefährlich sein, und ist in einigen Ländern verboten, aber eine die Verwendung der Kopfhörer mit beiden Ohren während des Fahrens in bestimmten Ländern nicht zulässig ist. Überprüfen Sie Ihre örtlichen Gesetze.
- Tragen Sie die Kopfhörer NICHT beim Schwimmen oder Baden oder beim Wassersport, z. B. beim Schwimmen, Wasserfahren, Surfen usw.
- Dieses Produkt enthält magnetisches Material. Bitte fragen Sie Ihren Arzt, ob dies Auswirkungen auf Ihr implantiertes medizinisches Gerät haben könnte.
- Wenn Sie das Produkt an heißen oder kalten Orten aufbewahren, z. B. in einem geschlossenen Auto unter Sonnen- und Winterbedingungen, verringern sich die Kapazität und die Lebensdauer der Kopfhörer.

- Erörtern Sie das Produkt gemäß den örtlichen Normen und Vorschriften.
- **Merken:** Fahren Sie immer sicher, vermeiden Sie Änderungen und betreiben Sie die Ohrhörer Gesetzt!
- Die Verwendung von Kopfhörern kann Bedenken eines Kraftfahrzeuges, Motorrads, Wasserrettung oder Patente kann gefährlich sein, und ist in einigen Ländern verboten, aber eine die Verwendung der Kopfhörer mit beiden Ohren während des Fahrens in bestimmten Ländern nicht zulässig ist. Überprüfen Sie Ihre örtlichen Gesetze.
- Beizen Sie vorsichtig, wenn Sie Ihre Ohrstöpsel verwenden, wenn Sie an Aktivitäten teilnehmen, die Ihre volle Aufmerksamkeit erfordern. Wenn Sie sich an einer solchen Aktivität beteiligen, werden Sie durch das Entfernen der Ohrstöpsel von Ohr oder den Ausschalen der Ohrstöpsel durch abgeben, abgeben zu werden, um Unfälle oder Verletzungen zu vermeiden. Machen Sie während des Fahrens keine Notizen oder Benen Sie keine Dokumente.

- Beim Verwenden und Aufladen dieses Produkts sollten stets grundlegende Vorsichtsmaßnahmen beachtet werden, einschließlich der folgenden:
- Lassen Sie alle Anwendungen, bevor Sie den Ladesteck verwenden.
- Um das Verletzungsrisiko zu verringern, ist eine genaue Beobachtung erforderlich, wenn das Ladegerät in der Nähe von Kindern verwendet wird.
- Setzen Sie den Ladestecker nicht Wasser, Regen, Flüssigkeiten oder Schmutz aus.
- Verwenden Sie ein Netzteil oder ein Ladegerät, das nicht empfohlen wird oder vom Hersteller des Netzteils verkauft werden, kann dies zu Feuer oder Verletzungen führen.
- Verwenden Sie keinen Ladestecker, der außerhalb seines Leistungsbereichs liegt, beschädigt oder modifiziert ist.
- Verwenden Sie kein Ladestecker, das beschädigt oder modifiziert. Reparaturen werden nur von qualifiziertem Servicepersonal unter Verwendung der gleichen Ersatzteile ausgeführt.

Garantie

Wir bemühen uns darum, das Produkt mit Sorgfalt und fortschrittlichen Technologien herzustellen.

Wenn Sie das neueste Produkt erhalten haben, wird Ihnen Ihnen eine einjährige, problemlose Garantie für alle unsere Produkte. Bitte kontaktieren Sie uns und, falls Sie die Fragen zu unseren Produkten haben, Wir werden weiterhin die bessere Sportprodukte für Sie herstellen.

EU **CE** **RoHS** **REACH** **WEEE** **EN60529** **EN60950** **EN60335**

- Zu Beginn Sie den Ladestecker richtig. Ein falscher Zusammenbau kann zu Feuer oder Verletzungen führen.
- Öffnen oder zerlegen Sie den Ladestecker nicht, wenn Sie ihn nicht Feuer oder übermäßiger Temperatur aus, Feuer oder extreme Temperaturen können eine Explosion verursachen.
- Reparaturen werden nur von qualifiziertem Servicepersonal unter Verwendung der gleichen Ersatzteile ausgeführt.

RF exposure statement:

The transmitter must not be colocated or operated in conjunction with any other antenna or transmitter. This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 5mm between the radiator and any part of your body.