Cloud BBQ

USER MANUAL Smart BBQ

Smart Wireless BBQ Thermometer



200 Hour Battery Life



32°F-482°F 0°C-250°C Range



Mounting



Wireless Range 30M or 100ft(in door) 60M or 196ft(out door)



Temperature LED Indicator



2 Viewing Positions



6 channel 6 probes



1.5V AAA battery*2

Download the APP

Search the keyword CloudBBQ in App Store or Google Play.

Download and install it for free

Make sure your phone meets the requirements; iPhone 4S. and later models:

iPod touch 5th, iPad 3rd generations and later models. all ipad mini:

Android devices running version 4.3 or later, with BT 40 module





Put in the Battery

Make sure the batteries are put in the right direction by following the icons on the unit







Install the probes

CloudBBQ thermometer works well only when the right probe is plugged in. Do not use probes from different sellers.

The device will keep scanning the sockets when its power is switched on, the probe number and its temperature value will be displayed on LCD one by one.

Plug the probes into the food, make sure the front tip of the probe is in the center of the food to get accurate temperature.

Power ON/OFF

Press and hold the button for more than 3 seconds when it is in OFF mode. it will be powered on. And the LCD display will show "ON".

If you do the same when it is in ON mode, it will be powered off.

When there is no probe plugged in the device, it will powered off automatically.

Pair with your phone

- Switch on your device and keep the BT switch of your phone on.
- 2 Launch the app, and follow the instrucions in the app to pair and activate the device:
 - Press the Pairing / Stop Alarm Button (on the top of the device).
- 3 Connected successfully.

Once paired the device with your phone, you don't need to do it again, unless you change to other phones.

Enjoy your barbecue time

Choose food type and preference for the food where each probe is inserted, the app and the device will display its current and tagert temperature.

When the food is ready, the app and the device will alarm.




WARNING

The heat resistance varies in different components of the probe, DO NOT put the probes directly in fire flame.

DO NOT put the plastic wrap into oven, or it will melt!

And probes are NOT dishwasher safe.




^{*} Accuracy: ±1%(1-200°C) ±2%(200-300°C)

Operation Is Subject To The Following Two Conditions:

(1) This device may not cause interference, and (2) This device must accept an interference, including interference that may cause undesired operation of this device.

App Store is a service mark of Apple Inc. Google Play is a service mark of Google Inc.

The user interface of the app may be changed when upgrade. Please follow the instructions in the app.



Probe color configuration

It's getting difficult for you to distinguish different probes when you have several probes in use.

The app provides 6 colors for each channel, which enable users set them to be identical to the color of the probes.

The probes come in 6 colors as well.













FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

* RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.