



Remote controller



How to use the remote controller

The remote controller and the WalkingPad are pre-paired before delivery by default. If the remote controller does not work or you change a new remote controller, please re-pair by pressing and holding the Mode Switch button or the remote controller while turning on the WalkingPad. When you hear a “beep” sound, it proves a successful pairing.



- Press the Start/Stop button while the machine is switched on.
After a 3-second countdown, the machine starts running slowly at 1 km/h by default.
- + Press + while the machine is running.
The speed switches among 1/1.5/2/2.5/3/3.5/4/4.5/5/5.5/6 km/h.
- Press - while the machine is running.
The speed switches among 6/5.5/5/4.5/4/3.5/3/2.5/2/1.5/1 km/h.
- Press the Start/Stop button while the machine is running.
The machine slowly speeds down and pauses. Then if no-load operation lasts for 10 minutes, the machine stops and enters Sleep mode.
- ⌚ Press and hold the Mode Switch button when the machine pauses.
The machine sleeps. To wake up the machine, press any button on the remote controller.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

C

IC STATEMENT

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS)d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes :

- (1) Cet appareil ne doit pas causer d'interférences.
- (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

avertissements radio pour les appareils portables :

L' équipement a été évalué et satisfait aux exigences générales d'exposition par radiofréquence. L'appareil peut être utilisé sans restriction dans des conditions d'exposition portables.