

CHARGING YOUR EARPHONE

Your Bluetooth earphones come with a built-in rechargeable battery and a Micro-USB charging cable

Charge fully before use

Using the charging cable through the corresponding port to charge the battery, the LED indicator will show red while charging, and show red once fully charged. Charging time is approximately 2hrs, providing up to

GETTING STARTED

To use your Bluetooth earphones, please follow the

- 1. Ensure your Bluetooth earphones are fully charged.
- 2. Pair your Bluetooth earphones to a Bluetooth-enabled device prior to use.(See Pairing instructions)

Powering On the Earphone

Press and hold the Multi-Function Button for 3 seconds until blue lights on

(2)

Powering Off the Earphone

Once powered on, press and hold the Multi-Function Button for 3 seconds until red lights on and out.

PAIRING YOUR EARPHONE

- 1. Power on your Bluetooth earphones
- 2. Press and hold the Multi-Function Button for approximately 9-10 seconds until the indicator flashes blue and red alternatively, your earphones are now in
- 3. Activate the Bluetooth function of your devices and start to search.
- 4. Select "Bymuse Fit" from the listed devices and
- 5 The indicator will flash blue twice every 7 seconds once successfully paired/connected.

- Bluetooth devices while pairing/playing.
- 2. Once paired, you don't have to pair the earphones with your Bluetooth devices for future use. Just power on the earphones and enable the Bluetooth function and they will automatically detect and connect with each other.

3. The earphones will automatically power off without

MUSIC MODE

Adjust Volume:

Short press the Volume+ to raise the volume or Volume- to lower the volume. You can also adjust the volume by your Bluetooth devices

- Play/Pause Music:
- Once connected, short press the Multi-Function Button to play or pause music.
- Previous Track: Press and hold the Volume- 1 second to
- the previous track
- Next Track: Press and hold the volume+ 1 second to the next track.

CALL MODE

Answering a Call:

Short press the Multi-Function Button to answer an incoming call, or answer the call normally via your mobile phone.

(4)

Rejecting a Call:

Press and hold the Multi-Function Button for 2 seconds to reject the incoming call.

- Ending a Call:
- Short press the Multi-Function Button to end the call or end the call directly from your mobile phone.
- Redialing a Call:
- Double click the Multi-Function Button to redial the last dialed phone number on your mobile phone. Voice Assistant:
- Once connected, press and hold the Multi-Function Button for 1 second to access voice assistant of your smart phone

SPECIFICATIONS

Dimensions	580×31×23mm		
Weight	20g		
Bluetooth	V4.1		
Profile	A2DP, AVRCP, HSP, HFP		
Bluetooth range	10m		
Battery	rechargeable lithium-ion		
Charging time	about 2 hours		
Playtime	up to 8 hours		
Speaker driver	2 * 6mm		
Frequency response	20Hz~20KHz		
Impedance	16Ω ±15%		
Sensibility	96dB+/-3dB at 1KHz		
MIC type	MEMS MIC		

(6)

LED INDICATOR

STATUS	INDICATOR		
Power On	Blue(slow flash)		
Power Off	Red(solid and out)		
Charging	Red(solid)		
Fully Charged	Blue(solid)		
Pairing	Blue/Red(quick flash)		
Connected	Blue(slow flash)		
Low Power	Red(quick flash)		

Model name: BT-535A

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, includir interference that may cause undesired operation NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or mor of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receive -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help

NOTE 2: Any changes or modifications to this unit not expressly pproved by the party responsible for compliance could void the user's authority to operate the equipment.

9

尺寸:300*80mm 成品尺寸:60*80mm/材质: 105g双铜/四色双面印刷/正反折叠

TM TM

东莞市库珀电子有限公司 DONGGUAN KOPPO ELECTRONICS CO., LTD.

客户	名/型号	ZSH FIT(5	35A)	物料	编码	40525350100
物米	斗名 称	说明书		比	例	1:1
制	作	农艳红		月	期	19-4-18
审	核			批	准	
単	位: MM	\oplus	A3	未标注	 E公差 :	参照 GB/T1804-V