



NOMADIC AUDIO SB1

TWS Pairing Instructions:

1. Make sure the Master* Nomadic Audio SB1 unit is in BT mode and paired to an audio device.
2. Short-press (1second) the "Phone" button on the Master unit. The "Source" LED indicator will blink slowly in Blue.
3. Make sure the Slave Nomadic Audio SB1 unit is in BT mode.
4. Short-press (1second) the "Phone" button on the Slave unit to pair with Master unit.

* Master unit plays the Left audio channel

MODEL: Nomadic Audio SB1

MAX POWER OUTPUT: 60W

FCC ID: 2ARHZ-NOMADICSB1



WARNING: READ THE
USER MANUAL BEFORE
OPERATING THE DEVICE



NOMADIC AUDIO IS A TRADEMARK OF MOREL PERMISSION GRANTED. DESIGN OF THE
PRODUCT AND PACKAGING ARE PROTECTED INTELLECTUAL PROPERTIES OF MOREL.



www.nomadic.audio



SERIAL No.

USE ONLY POWER SUPPLY
LISTED IN THE USER MANUAL



PRODUCED IN CHINA



68.10mm x 66.20mm

