

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

MOBILEEDGE
Bring It On.

Wireless Optical Rechargeable Mouse
6 Buttons 1600DPI

Manual



PART # MEAM06

Manual

MEAM06 Optical 6 Button 1600DPI
Wireless Mouse
USB - Rechargeable

Included in Package:
Mouse
USB Receiver
Charging Cable
Instruction Manual


ADVANCE FUNCTIONS

Functions:
a. Left button
b. Scroll wheel
c. Right button
d. DPI option
(1600 / 1200 / 800DPI Cycle)
e. Backward
f. Forward



CONNECTING

Charge Mouse
Plug USB Receiver into PC USB Port Press Left or Right Mouse Button for 5 Seconds.



RECHARGING METHOD



FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.