
Bluetooth Speaker

# **User Manual**

# 1. Safety instructions

- Never dissemble the Bluetooth Speaker in an attempt to make any repairs as this could result in electrical shock, burns or product failure;
- Adhere extra caution when using the Bluetooth Speaker around children;
- Use extra caution in high temperatures;
- Product is not waterproof;
- Product is not covered under warranty when the product has metal rust, surface spalling and any other natural oxidation;
- Damage, shock, and/or injury can occur if these warnings are not heeded properly.

#### 2.Button index



① Power key: Long press 3 seconds to Power ON/OF the speaker.

Quick press for pause or resume to play. Answer/reject phone phone call button

- 2 Micro USB interface for charging: 5V 1A
- ③LED Indicator: blue LED when playing, red LED when charging, the LED will be off when fully charged.

### 3. Function Introduction

1. TWS Paring: when first time use the 2 speakers, power on 2 speakers, double click power

button of any one speaker for paring two speakers, they will do auto paring since second time. When need only one speaker to play, double click power button for disconnecting.

#### **Wireless Connection**

**Computer Connection:** Your computer must have built-in wireless, with an updated wireless driver. Turn on the speaker, run a computer search for wireless audio device name, once connected, you can start using the speaker.

**Mobile Phone Connection**: Open the phone's wireless function search the wireless audio device name, once connected successfully you can start using the speaker.

## 2. Handsfree Call Operation

- When phone device is connected to wireless speaker, phone will ring through speaker (voice prompts incoming phone call)
- To answer phone using the speaker quick press the Power button or answer phone as usual, speaker phone will be active with hands free operation. To end call by pressing quickly the Power button.

#### 4. Note

- 1. Machine may work abnormally due to wrong operation or low power, you can power on again or do the charging.
- 2. If not play, speaker will power off in 5 minutes. Please power ON the speaker again when you want to listen to music.
- 3. Due to the 2.4G radio interference, if the speaker can not pair or play music well, please turn on the speaker again or reconnected the Bluetooth device again.

## 5. FAQ

1. Can not power on:

Please check if the battery is in low power. Please recharge and then try to open again.

2. Cannot charge:

Please check if the power supply is working for input charging.

Please check if the USB cable is working properly.

## 6. Specifications

Functions: Bluetooth + Handfree TWS
Support profile:A2DP AVRCP HFP AVCTP

Material: Aluminium
 Bluetooth: V5.0
 Bluetooth Range: 10m

4. Speaker: 3W\*2

5. Frequency Response: 80Hz-20KHz

6. Signal Noise Rate: >85dB

7. Battery: 400mAh 8. Play time:2-3Hours 9. Size: 49\*46MM

10. Color:Black, Silver, Gold, Red, Pink

# 7. Packing Component List

2 Bluetooth Speaker

1 Micro USB Charging Cable

1 Charging Plate

1 User Manual

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help Changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following

two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.