



SE**TTING**S Restore Pactory Settings: Reset default factory settings on your headset.

Caution: This feature erases all device pairing information stored on the headset.

Nultipoint: Connect your headset to two d

COMFORT				
what feels best on you				
Choose your most comfortable fit ear tip				
Earhook				
Right Ear Left Ear				
Eartip Wear				
je i la				
EN	5			

Safety instructions for use 🙈

To avoid hearing damage, keep the volume at a moderate level. Avoid listening to music at load volume levels for prolonged periods of time as this may cause permanent hearing damage or hearing loss. Your so please listen to your music responsibly. For please listen to your music responsibly. Rom rover information visit the Deathenes. Research Foundation www.drf.org.

Don't use HK500/HK500+ when it is unsafe to do so. For example, while operating a vehicle, cycling, crossing a road, or any activity which requires your attention and ability to hear.

You should be aware of your surroundings and use HK500/HK500+ responsibly.

п

BASICS		To	To	
standard fea	tures, advanced quality	pause/play	press MFB once to pause and press again to play.	
То		pairing mode	press MFB 5 seconds to	
answer a call	short press MFB.		enter into pairing mode	
reject a call	press volume down 2 seconds.		when headset is in on mo	
end a call	short press MFB	reset	press MFB and volume down 5 seconds.	
on	boom open (on)	3-way call ongoing		
off	boom close (off)	pick incoming	press MEB once	
change call volume	press the volume up and volume down button	call, put ongoing call on hold.		
mute or	press volume down 2 seconds during the call and press	reject incoming, continue ongoing	press and hold volume do	
unmute a call	volume up 2s to unmute.	end ongoing,	double press MFB	
last track	press volume down 2 seconds when headset is in music state.	resume waiting call		
		switch calls	press MFB once	
next track	press volume up 2 seconds	end current call	double press MFB	

• U: driv illeg	Note: Some features are phone/network dependent • Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely. STATUS LIGHT	
If lig	ht shows	your headset is
pow	er on	blue flashes 1 second.
pow	er off	red flashes 2 seconds.
pairi	ng	red & blue flashes alternately.
on s	tandby	blue flashes once every 5 seconds.
		steady red.
char	ging	steady red.
	ging -charged	steady blue.

Notes: After one minute on a call or 20 mir inactivity, the light stops flashing to power, but the headset remains on. Boom also saves battery life. ites of ADVANCED SECOND DEVICE

Do you use two phones? Or maybe a phone and a tablet? Connect with both of them. 1. Pair the first device with your headset as normal (see "CONNECT & GO" on page 4). 2. Turn off the Bluetooth" feature on the first device. device. 3. Now pair the second device with your headset as normal. 4. Once paired, to connect with both devices simply turn them on.

EN 9

Help & more	General Information	equivalent reconditioned/ refurbished/ pre-own new Products. Accessories or parts.
Net pictre usedhig vide vide vide pictre todox you and vide big big big big big big Mandaelunet. Bief big	Concerned Products and Accessories Limited Warnshop Datases John Frankenski handrensk handrensk handrensk markenski og handre Strander Strander Strander Markenski og handre Strander Strander Strander Strander Strander Strander Strander Handre Strander Strander Strander Handre Strander Strander Strander Handre Strander Strander Strander Handre Strander Strander Handre Strander Strander Handre Strander Strander Handre Strander Strander Handre Strander Strander Handre Strander	What Other Limitation Are There? Any reverse the watabarties functioned any Historical Area and Area and Area and Area and Area Historical Area and Area and Area and Area Area and Area and Area and Area and Area and Area Area and Area and Area and Area and Area and Area Area and Area and Area and Area and Area and Area Area and Area and Area and Area and Area and Area and Area Area and Area a
12 EN	EN 13	14
		I L



Exclusions Normal Wear and Tear, Periodic maintenance, repair and replacement of parts due to normal wear and tear are Abuse & Misuse. Defects or damage that result from (a) improper operations, storage, misuse or abuse, accident or neglect, such as physical damage (oracle, scratches, etc.) to brack with indust parts, and the pointed with the other with indust parts, and without pointed with the to brack with indust parts, and without pointed with the	Attered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or transmorting (c) memory and the series of the series of the neocofferming or non-Motorial branded heurings, or parts, are excluded from overrage. Communication Services, Directs, damages, or the failure service or taginy or may subscribe to or use with the	
heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of MOTOROLA or MZGW, are avoluted from coverage.	Products or Accessories is excluded from coverage. How to Obtain Warranty Service or Other Information? To obtain service or information, please visit:	
	motorolasound.com/support You will receive instructions on how to ship the Products	
Use of Non-Motorola branded Products and Accessories. Defects or damage that result from the use of Non-	or Accessories at your expense and risk, to a MZGW Authorized Repair Center.	
Motorola branded or certified Products or Accessories or other peripheral equipment are excluded from coverage.	To obtain service, you must include: (a) the Product or Accessory; (b) the original proof of purchase (receipt) which includes the date, place and seller of the Product	
Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than MOTOROLA, MZGW or its authorized service contexs, are excluded from coverage.	which includes the date, place and seller of the Product (c) if a warranty card wais included in your box, a completed warranty card showing the serial number of the Product; (d) a written description of the problem; a most importantly; (e) your address and telephone num	
16 EN	EN 17	

EN EN





## SIZE:65X80MM