


	3 Quick Start Guide					
er Cover	STEP1 Power on STEP2 Connect to Bluetooth Please press the power button about 3 seconds. To connect to Bluetooth, please search the printer on the setting of your smartphone. Ex) NailPOP XX:XX Please select the nail pop printer re the nearth list	STEP3 App Please choose a nail look design	on the application.	STEP 4 Printing You can print out by pressing 'Print' button on the app after choosing a nail look design.	STEP5 Attaching sticker Please clean your nails by the prep pad enclosed in the cartridge box. And then, please attach the nail sticker printed on your nail and trim it by the nail file.	STEP 6 How to power off Please press the power butt about 3 seconds.
p Rubber for paper	on the search list.	C Prist Overview ①	Print Description	Vict Overview Image: Constraint of the constraint of t		
	Precautions	© Check points bef	Fore complaints about failure	Print Print Specification		
	Precautions on Please use 5V-1A charger.	Cases	Solutions	Model name: NP100 Product name: NAILPOP		
	charging Please use the suitable charger and cable with the correct voltage. If you charge the product with the unofficial cable and charger for a long time, the product can be damaged. The manufacturer has no responsibility on the issue	The printer doesn't work well.	 Please check if the power button is turned on. Please check the color of LED light. (Red light: On charging / Green light: Charging finished) 	 Dimension: 39.5mm x 148mm x 10 Rated voltage: 5Vm1A Optimal temperature: 5~40°C Optimal humidity: Under 70% 	1mm	
lication	General precautions The sticker is printed by moving back and forth in the slot for 6 times. • Please don't touch the paper during printing. • Please don't pull out the paper during printing. • Please don't put something on slot for paper.	The power is not turned on.	 Please check if the battery is charged. Please connect the charger to the USB port. Please check if the charger operating well. Please check if the voltage on your state is matched with the product's voltage. 	Contact Point TEL: 070 - 5117 - 4717 Homepage: http://www.nailpop.biz/		
n Nail POP App QR code.	 Please use the newest app version fir the best printing quality. Please check the newest version of the app on the Google Play Store and Apple App store. The printer has an inner battery. Please charge it before using it. Please don't disassemble or deform it. Please avoid too high temperature and humidity. Proper temperature: 5~40°C 	The paper is jammed. * If you can't solve the issue wit CS center(+82) 070-5117-4717	 Please turn on printer again after turning it off. The paper is printed automatically. Please reset the printer by putting the reset hole by a sharp thing. 		ΟΝΑΙΓΦΟΡ	
						1



90mm