

ESC SOUNDS SERIES 3




User Manual

GETTING STARTED:

Power on:


Remove the Series3 earbuds from the charging case and they will automatically power on.

When the Series3 are powered off and outside of the charging case, press down the Multi Function Button for two seconds until you hear an ascending tone to indicate the earbud has powered on.



Volume up & down:


Quickly press and release the "+" on the Series3 to increase the volume and quickly press and release the "-" to decrease the volume.



Skip track:


Press and hold the "-" for one second to skip back to the previous track.

Press and hold the "+" for one second to skip forward to the next track.




Play/Pause: >||

When music is playing, press and quickly release the Multi Function Button once to pause the song and then repeat the action to resume playing.



SIRI function/ Voice Assistant:



Press and quickly release the Multi Function Button twice to activate Siri / Voice Assistant.



Fitting and Wearing:


Gently insert the Series3 into your ears and then rotate them until they feel most comfortable and secure in your ears.

Three sizes of removable earcaps:



Factory reset:

When the earbuds are powered off (and out of the case), press and hold down the Multi Function Button for ten seconds and until the indicator light flashes red and blue for a second. This flashing light indicates that the earbuds are reset and then powered off. To then pair the buds back together, power both earbuds on by pressing down the Multi Function Button for three seconds and then hold both earbuds next to each other until the light on one of the earbuds alternately flashes red and blue.




Product features:

Bluetooth version 5.0, which is compatible with over 99% of Bluetooth Devices.

Pairing:

Two headphones pairing:

After powering on, the two earbuds will automatically enter pairing mode and connect to one another. When they are paired together, the light on one of the earbuds will alternately flash red and blue, while the other won't light up.



Mobile phone and Bluetooth headset pairing:

Open the device's list of Bluetooth devices and select 'Series 3'.



BASIC PARAMETERS:

Bluetooth version: V5.0
Chipset: PUA1603
Bluetooth Profile: A2DP/HFP/AVRCP/HSP
Codec: SBC/AAC
Frequency range: 100Hz-10KHz
Earbuds Battery Capacity: 55 mAh
Charging case battery capacity: 500 mAh
Charging Time: 1-2 hours
Charging cable: Type-C
Charging case Indicator light: 4 red lights
Playtime: Up to 7 hours x 4 times
Sensitivity: 95dB/1mW
Wireless Range: more than 10m
Earbuds Size: 47*40*30 mm(+/-0.5mm)
Charging case size: 76*69*42mm(+/-0.5mm)

Notes:


Playtime varies according to volume level, audio content and Bluetooth interference.

Average Playtimes:

100% Volume = Up to 5 Hours
50% Volume = Up to 6 Hours
25% Volume = Up to 7 Hours

Charging:

The Series3 are charged while placed into the portable charging case. A red light on the Series3 indicates that the Series3 are charging. When charging is completed the red light will turn Blue for a short period of time and then turn off.



Charging/discharging of charging box:

To charge up the case, connect one end of the supplied charging cable to the Type-C charging port and the other end to a USB port on your computer or a USB charger.

The lights on the front of the charging case indicate the percentage of charge remaining in the case

Charging status:

When the earbuds are placed into the charging case, the indicator light of the charging box will illuminate to demonstrate the amount of charge in the case. The four lights from left to right correspond to 0-25% 25%-50% 50%-75% 75%-100% of the power level.

GUARANTEE:

Your Series3 are guaranteed for a period of 12 months from date of purchase. Subject to the terms below, the guarantee will provide for the repair or replacement of your Series3 or any components thereof, which is identified as faulty or below standard, or because of inferior workmanship or materials.

The conditions of this guarantee are:


- The guarantee shall only apply to defects that occur within the 12 months guarantee period
- Proof of purchase is required
- The Series3 are returned to ESC Sounds as instructed

This guarantee does not cover any faults or defects caused by accidents, misuse, fair wear and tear, neglect, tampering with the equipment, or any attempt at adjustment or repair other than through approved agents. This product has an IPX7 waterproof rating, which is covered under the manufacturer's warranty. This guarantee does not affect your statutory rights. Please retain this document as it acts as a guarantee certificate.

GENERAL FUNCTION:


Answer a call 📞:

To answer an incoming call, press and then quickly release the Multi Function Button one time.




Reject a call 📞:

To reject an incoming call, press the Multi Function Button for a full second.



Ring off 📞:

To end a phone call, press and then quickly release the Multi Function Button one time.



Power off:

Press and hold down the Multi Function Button on one of the Series3 for five seconds and both buds will power off.

Alternatively, place the Series3 into the charging case and they will automatically power off.

PRODUCT DISPOSAL INSTRUCTIONS:

The symbol shown here and on the product packaging means that the product is classed as Electrical or Electronic Equipment and should not be disposed with other household or commercial waste at the end of its working life. The waste of Electrical or Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using best available recovery and recycling techniques to minimise the impact on the environment, treat any hazardous substances and avoid the increasing landfill.



PRODUCT DISPOSAL INSTRUCTIONS FOR RESIDENTIAL USERS

When you have no further use for it, please dispose of the product as per your local authority's recycling processes. For more information, please contact your local authority.

PRODUCT DISPOSAL INSTRUCTIONS FOR BUSINESS USERS

Business users should contact their suppliers and check the terms and conditions of the purchase contract and ensure that this product is not mixed with other commercial waste for disposal.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

WARNING:

- Listening to earphones with the volume too high can harm your hearing
- Keep this product away from children
- Please do not attempt to make any modifications or attempt to disassemble this product
- Do not expose to extreme temperatures
- Never attempt to use the Series3 while in charging mode
- Never attempt to clean this product when in charging mode
- Always ensure you are aware of your surroundings when using this product
- Great care should be taken if ever handling any heavy objects while using/wearing this product and this is done entirely at the users own risk
- Do not submerge this product under water