


Lovense

**Lush 2**

USER MANUAL





- Indicator Light
- Button: On/Off (hold for 3 seconds)  
& Cycle Through Vibrations (one tap)
- Charging Port

English

## What's Included

- (1) Bluetooth Remote Control Vibrator
- (1) USB Charging Cable
- (1) User Manual
- (1) Quick Setup Guide

## Specifications

Materials	Body Safe Silicone
Weight	62g
Battery	Li-Ion Rechargeable
Charging	90 Minutes
Use Time	up to 245 Minutes
Standby	up to 120 Hours
Waterproof	Waterproof

## Charging

Turn off Lush. The cable can be plugged into any USB port or USB/AC power adapter. It will take approximately 1.5 hours to fully charge. Once it is fully charged, the solid red light will turn off.

**Note:** *Push the pin firmly, but slowly into the charging port. Stop pushing when you see the indicator light glow.*

## Cleaning & Care

- Clean Lush before and after each use.
- Clean with warm water and a mild soap (or sex toy cleaner).
- Dry thoroughly before storing.

## Usage Tips

- It is necessary to properly apply lube to your body and the toy before insertion.
- Be aware of Lush's antenna during insertion. It's extension beyond the body increases the range of control.

## Warning

- Under no circumstances should you use Lush anally.
- DO NOT boil in water (the battery may explode or water could leak into the toy).
- Keep away from extreme heat or cold.
- Make sure your toy is recharged at least once every six months.
- DO NOT use the toy while charging.

## Links

Check out the newest guide/download links here. Our software gets constantly updated.

Online guide: [www.lovense.com/guide](http://www.lovense.com/guide)

App download: [www.lovense.com/download](http://www.lovense.com/download)

If you have any feedback or need any additional assistance, use the contact form at [www.lovense.com/contact](http://www.lovense.com/contact). Someone from the Lovense team will normally reply within 12-24 hours.

## **Warranty Terms & Conditions**

LOVENSE warrants this product for a period of ONE (1) YEAR, after the date of original purchase, against defects due to faulty workmanship or materials. If you discover a defect and notify LOVENSE during the warranty period, LOVENSE will, at its discretion, replace the product free of charge.

Visit [www.lovense.com/warranty](http://www.lovense.com/warranty) for detailed warranty and product return information.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

FCC ID: 2ARUK-LUSH2