

INSIGNIA™

v1
R4

QUICK SETUP GUIDE

5 Watt Wireless Charging Pad

NS-MWPC5K/ NS-MWPC5KTP /
NS-MWPC5K-C

Flat size (W×H): 12 × 2.75 in. (304.8 x 69.85 mm)

Final folded size: 3 × 2.75 in. (76.2 x 69.85 mm)

Before using your new product, please read these instructions to prevent any damage.

PACKAGE CONTENTS

NS-MWPC5K / NS-MWPC5K-C

- 5 W Qi Certified Wireless Charging Pad (1)
- 4 ft. (1.2 m) charging cable (1)
- USB power adapter (1)
- *Quick Setup Guide*

NS-MWPC5KTP

- 5 W Qi Certified Wireless Charging Pad (2)
- 4 ft. (1.2 m) charging cable (2)
- USB power adapter (2)
- *Quick Setup Guide*


FEATURES

- Low-profile design for easy placement and reliable charging
- Wireless design charges without cumbersome cords
- 5 W output provides standard charging speeds to Qi-compatible devices
- Blue LED shows that your device is charging

COMPATIBILITY


Any Qi-enabled devices up to **5 W**, including smartphones, headphones, smart watches. This includes the latest iPhone, Samsung Galaxy, and Note devices.

PRODUCT OVERVIEW



USING YOUR CHARGING PAD

- 1 Connect the micro charging cable to the micro USB port on your charging pad.
- 2 Plug the other end of the USB cable into a USB wall charger, car charger, laptop, or desktop.



- 3 Place your Qi-enabled device on the center of your charging pad with the screen facing up. The LED is blue when your device is charging.

Note: If the LED is red, your device is not charging. See "TROUBLESHOOTING" for more information.

LED INDICATOR STATUS

LED	STATUS
Blinking blue	Standby
Solid blue	Charging
Blinking red	Charging error
Solid red	Insufficient input power

TROUBLESHOOTING

Device not charging/LED is red

- Make sure that your device is Qi-enabled.
- Make sure that your charging pad is connected to a working power outlet.
- Make sure that your device is positioned correctly on your charging pad.
- Make sure that there are no other objects on the charging pad.
- Remove your device's case. It may be blocking the wireless signal.

Device charges slowly

- Your device may charge more slowly with the charging pad than a charging cable. This is normal behavior.
- Make sure that your device is positioned in the center of your charging pad.

CAUTION: Only use the cable with the attached power adapter that came with your charger. Using a different cable and adapter can decrease charging performance or damage your charger.

SPECIFICATIONS

Qi wireless charging pad

Input: Micro USB 5 V/2 A

Wireless output: 5 W

Dimensions: 3.937 x 3.937 x 0.417 in. (95 x 95 x 10.6 mm)

AC power adapter:

Input: 100-240 V 50/60 HZ

Output: DC 5 V/2.4 A

Charging cable: 4 ft. (1.2 m)

LEGAL NOTICES

FCC Information

FCC Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC statement: This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RSS-Gen statement: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement: This equipment complies with radio frequency exposure limits set forth by the FCC for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the device and the user or bystanders. This device must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment complies with radio frequency exposure limits set forth by the Innovation, Science and Economic Development Canada for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm between the device and the user or bystanders. This device must not be co-located or operating in conjunction with any other antenna or transmitter.

SAFETY INFORMATION

- 1 Do not attempt to disassemble the product. It may result in short-circuit or damage.
- 2 The product should be kept in a dry and ventilated environment. Do not store it in an area of high humidity and high temperature.
- 3 Do not use an organic solvent to clean the product.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

1-877-467-4289 (U.S. and Canada)

1-800-926-3000 (Mexico)

www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies

Distributed by Best Buy Purchasing, LLC

7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2020 Best Buy. All rights reserved.