



EXCITRUS™


Wireless EarBuds with Wireless Speaker AW-90



What's in the box?



Wireless Speaker /
Charging Box × 1



TWS Earbuds × 1



String × 1



Micro USB Charging
Cable × 1





Eartips × 3
(L, M, S)



User Guide × 1

Product Sketch



Wireless Earbuds

TWS Earbuds First Pairing

- In first time, please take earbuds out from charging box ,it will be turned on automatically. LED light is in blue flashing.
- Turn on your phone Bluetooth and connect to “AW-90” ,after 5 seconds it will be connected successfully, the LED light is in red and blue flashing alternately with a sound “Pairing” .

Once the first pairing is completed, in next time it can pairing with phone automatically.

Turn off TWS Earbuds

- Put the earbuds into the charging box and it will be turned off automatically.

Charging

- Please put earbuds in charging box ,the charging box will catch up the earbuds and earbuds will be power off automatically, the LED light is in red flashing.
- It takes 1 hour to be fully charged.
- After fully charged, the LED light is in blue flashing for 1 second and extinguished.

Music Play/Pause

- Press either L or R Multifunction Button 1 time to play/pause music.

Next Song

- Double press R earbud Multifunction Button to play next song.

Answer the Call

- Press either L or R earbud Multifunction Button 1 time to answer the call.

Hang Up

- Press either L or R earbud Multifunction Button 1 time to hang up the call.

Reject the Call

- Long press either L or R earbud Multifunction Button for 3 seconds to reject the call.

Last Number Re-dial

- Double press L earbud Multifunction Button to last number re-dial.

Wireless Speaker

Speaker First Pairing

- Please press Multifunction Button for 1 second, the LED light is in Blue flashing with sound “DONG” .
- Turn on your phone Bluetooth and find out “AW-90” PLUS to connect it, in the meanwhile, LED light is in blue flashing.

Once the first pairing is completed, in next time it can pairing with phone automatically.

Turn off Speaker

- Press Multifunction Button for 2 seconds, it will be turned off.

Charging

- Please use Micro USB or Lightning for charging ,the LED light is in red flashing while charging.
- It takes about 4 hours to be fully charged.
- After fully charged , the LED light is in blue flashing for 1 second and extinguished.

Note 1 : Use only the qualified charger to charge the earbuds, if use other device may violate the validation or the maintenance article of this product and may cause danger.

Note 2 : Do not attempt to force open the built-in battery as this could damage the earbuds.

Last Song

- Short press Prev Button.

Next Song

- Short press Next Button.

Maximum Volume

- Long press Volume+ Button.

Minimum Volume

- Long press Volume- Button.

Music Play/Pause

- Press the Multifunction Button 1 time to play /pause music.

Product Specification

Product Name	Audioboy
Model Number	AW-90
TWS EarBuds Bluetooth	Bluetooth 5.0+EDR
Speaker Bluetooth	Bluetooth 4.2+EDR
Speaker (Charging Box) Battery	1100mAh
Ear bud Battery	45mAh * 2
Charging Connector	Apple Lightning & Micro USB
Speaker Charging Time	3~4 hours
Ear Buds Charging Time	Less than 1 hour
Speaker IP Rating	IP65
Ear Buds IP Rating	IP67

WARNING

- Please do not leave it under the water for long time.
- Do not use abrasive solvent to clean the product.
- Do not place the product at extremely high or low temperature, the best storage environment is -10°C to +60°C. Otherwise it will affect the life of product.
- Do not expose the product to fire to avoid the risk of explosion.
- Do not attempt to disassemble the product.
- Please do not use power adapter over 2A charge for the product, excessive current will cause damage to the battery, affecting the life of product.
- Keep the accessories away from children under 6 years old to prevent children from eating them.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.