



85mm

115mm


Wear and Fit
Func1 Pro offers 4 sets of earbuds, please choose the suitable pair to fit ears. Please distinguish the left and right earbuds.




How to wear
Please adjust your earbuds and ear hooks to fit ear.




Wearing the glasses
If you wear the glasses, the bracket will stir and the headphones will collide to produce abnormal sound, which will affect the music listening experience. The solutions are as follows:
a. Isolate glasses holder and headphones to avoid direct contact and collision.
b. Avoid wearing glasses during exercise. c. Tighten the glasses so they don't jump during exercise.
c. Tighten the glasses so they don't jump during exercise.




How to Pair
1. First time use
Take out the Earbuds from charging case. Remove the insulation films and put the earbuds back into charging case.




2. Power on & connect
Take out both earbuds from charging case. After few seconds, the white LED on left earbuds will flash quickly, while the LED on right earbuds pulses. The left earbud will automatically enter pairing mode.




3. Pair it with your device
Choose "Func1 Pro" to connect.




4. Play music and fit.
If you hear something abnormal, turn the ear hooks and adjust the earbuds in ear canal to get the best sound.




Mono Mode
For mono channel pairing, please follow the steps below.
1. Turn it on
Put the left and right earbuds into the charging case, take out the right earbud. The right earbud will enter to pairing mode automatically.




2. Pair it with your device
Choose "Func1 Pro(R)" to connect.



Happy ?
We're glad to learn that you're happy. Connect with us on func1.com, Facebook, Twitter and Instagram.




For products more information, please visit:
func1.com



FUNCL Product Number Func1 Pro Wireless Headphones 23-FC1102-000B1

Quick Troubleshooting
If you have troubles below, PLEASE PUT EARBUDS INTO THE CHARGING CASE AND TAKE THEM OUT. If troubles still exist, please check the user manual to reset to Factory Settings.
1. Both earbuds cannot pair with each other
2. Earbuds not able to connect to device
3. No sounds from left or right earbud



Tips
1. When using your earbuds at subway, airport and strong electromagnetic interference environment. Bluetooth signal might interrupt. It is due to too many 2.4G signal interferences in these areas.
2. Due to low version Bluetooth profiles of some devices may have audio and video asynchronism. Television and other non-mobile devices are more obvious.
3. If the earbuds cannot be turned on, please put them into charging case and charge the case at the same time.

FCC Statement (FCC ID: 2ARZ4F1 01)
This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. CAN ICES-3(B)/NMB-3(B).

FCC/IC Radiation Exposure Statement
This equipment complies with FCC/IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

Federal Communication Commission Interference Statement
Federal Communication Commission Interference Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Customer Service
Enjoy 18 months of peace of mind when you register FUNCL CARE for Headphones.

- 18 months limited warranty
- Lifetime technical support
- Express replacement service

Our customer service team will work hard to put a smile back on your face. Here's how we can connect:
support.amazon@func1.com

QUICK START GUIDE
PRO

English

封底

封面

Printing process 印刷工艺

 Cutting Line
切割线

 Fold Line
折叠线

- 1.材质:128g哑粉
- 2.成品尺寸:85X115mm
- 3.公差:±1mm;
- 4.内容文字颜色均匀,深浅一致、字体轮廓清晰;
- 5.尺寸正确,边缘裁剪整齐,无黑点、污渍、褶皱等缺陷,不得漏印。
- 6.折叠方法:单折

科甲技术		包材工程图	
产品名称	Func1 Pro	单位	mm
零件名称	快速指南	比例	1:1
物料编码	23-FC1102-000B1		
材 质	128g 哑粉		

■	AA		Emma	20191231		
标记	版本	变更内容	制作人	年/月/日		