



Changes or modifications not expressly approved by the party responsible or compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.


If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
  -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- from that to which the receiver is connected.

   Consult the dealer or an experienced radio/TV technician for help.
  The device has been evaluated to meet general RF exposure requirement.

FOLLOW US ON 🎾 🚹 📵 #myalteclansing





## Earbud Controls

## Left Earbud

Press & Hold 3 sec: ON/OFF Press: Play/Pause/Answer & End call

End call Press 2X: Next Track Press 3X: Increase Volume Press & Hold 2 sec: Reject call/Just Ask\*

## Right Earbud

Press & Hold 3 sec: ON/OFF Press: Play/Pause/Answer & End call

Press 2X: Previous Track Press 3X: Decrease Volume Press & Hold 2 sec: Reject call/Just Ask\*



\*To use Siri or Google Assistant, you must have a phone that is compatible with one of the two voice assistants (iOS or Android, respectively).

\*Your Wireless Earbuds will not work with Siri or Google Assistant if the assistant is not first enabled within the settings on the phone. For more information, see your phone's user manual.

\*You must be within Bluetooth® range to use Siri or Google Assistant via your Wireless Earbuds.

## **Reset Function:**

- 1. Turn off Bluetooth device and turn off bluetooth Earbuds.
- 2. Take out one earbud from charging case, the indicator light flashes red and blue alternately, and then click the button four times quickly to turn off the earbud.
- 3. Take out the other earbud and repeat the step 2

For additional user materials and warranty information, please visit alteclansing.com