1 제품사양

제품명: RIIZE OFFICIAL FANLIGHT

크기: 약 95 X 95 X 250 (MM)

무게 : 약 350a

채질 : ARS PC NYLON PAPER

구성품: 응원봉, 스트랩, 사용자 설명서, 스티커

건전지: 알카라인 AAA 건전지 3개

작동시간 : 약 4시간 동작은도:-20℃~50℃

기획 및 판매 : SM ENTERTAINMENT Co., Ltd.

제조사 : BEATRO Co., Ltd.

제조국가 : 중국

모델명 : SME-RIIZE-OFL01

KC : R-R-BTr-SME-RIIZE01

FCC ID: 2AS3Z-SME-RIIZE01

2 주의사항 🗥

- 강한 충격이나 물이 닿으면 고장의 원인이 됩니다.
- 임의로 분해 및 조립하지 마세요.
- 정품 알카라인 AAA 건전지를 사용하세요.
- 사용하지 않을 시에는 건전지를 제거해 주세요.
- 건전지는 영/유아의 손이 닿지 않는 곳에 보관하세요.
- 수명이 다 된 건전지는 지정된 폐기 장소에 버려주세요. - 반드시 건전지의 +, - 극성을 잘 확인하여 올바른 극성 방향으로 장착하세요.
- 건전지의 잘못된 장착은 제품 고장의 원인이 되며 화재 및 화상의 위험이 있습니다.
- 본 제품은 무선 운용 중 혼선의 가능성이 있습니다.

3 사용 모드 설명



모드설정

- · 전원 ON/OFF (버튼 콩클릭)
- 버튼을 3초 정도 길게 누르면 전원이 ON/OFF 됩니다.
- · 일반 모드 (버튼 원클릭)

전원 ON 상태에서 버튼을 짧게 누르면 LED 모드가 변경됩니다.


- . 모션 센서
- 응원봉에 모션 센서가 내장되어 있습니다.
- ⚠ 응원봉 바디에서 딸그락 소리가 나는 건 불량이 아닙니다.
- ·블루투스 모드 (버튼 더블클릭)
- 블루투스 모드는 SMTOWN APP과 응원봉을 연결 하여 다양한 콘텐츠를 즐길 수 있는 모드 입니다. 버튼을 더블클릭하면 블루투스 모드로 전환됩니다.(파란색 회전) 다시 버튼을 더블클릭하면 일반 모드로 돌아옵니다.

⚠ 블루투스 모드 시 15초 이내에 APP과 연결이 없으면 일반 모드로 자동 전환됩니다. ▲ 블루투스 모드 시 컬러 변경 작동이 되지 않으며 불량이 아닙니다.

> ※ 일반 모드에서 공연장 무선 연출이 가능합니다. 공연장에서는 반드시 일반 모드로 변경 후 관람 부탁드립니다.

4 건전지 삽입 및 교체

※ 건전지의 전압이 낮을 경우 전원이 자동으로 차단되오니 새건전지로 교체 바랍니다.



⚠ 건전지 주의사항

- (-) 극부터 (+) 극 순으로 바르게 넣으세요. (소켓의 스프링 부분이 (-)극 입니다.) 역 삽입 시 발열로 인한 파열 및 누액의 위험이 있습니다.
- 응원봉의 거전지 부분이 갑자기 뜨거워졌을 때에는 즉시 소켓을 부리해 주세요. (화상의 위험이 있으니 분리한 소켓과 건전지를 손으로 잡지 마세요.)
- 정품 알카라인 AAA 건전지를 사용해 주세요.
- (정품이 아닐 경우 제품에 손상이 있을 수 있습니다. 꼭 정품 건전지를 사용해 주세요.)
- 충전, 분해, 단락, 가열하지 마세요. 폭발 또는 누액으로 인해 상해를 입을 위험이 있습니다.
- 누액의 가능성이 있으니 사용이 끝난 건전지는 소켓에서 분리해 주세요.
- 매회 공연 시 새로운 건전지를 사용해 주시기 바랍니다.
- 새 건전지와 사용한 건전지, 그리고 서로 다른 건전지와 혼용하지 마세요.
- 건전지의 포장을 벗긴 채로 주머니나 해드백 등에 보관하지 마세요.

5 A/S 처리 규정

- 제품 구매 후 확인되는 불량/교환은 판매처에 문의 바랍니다.
- 무산 보증 기간은 구인하 낙로보터 3개월이며, 보증 기간 이내라도 고객 과식 및 파소에 의한 유상 A/S 대상으로 판단되는 경우 별도 수리비가 청구되오니 이점 반드시 숙지해 주시기 바랍니다.
- 제품 A/S 접수비(왕복 배송비)는 제조사 부담 후 유상 수리 대상일 시 고객 부담입니다.
- 메일로 선접수 및 상담된 내용에 한해서 A/S 서비스가 가능합니다. 메일 발송 시, 구매 영수증(구매 날짜 포함 필수)과 자세한 불량 증빙 내역을 포함하여
- 발송 바랍니다. 상담 및 접수가 완료된 후에 택배 발송하여 주시기 바랍니다.
- 무상 보증 기간: 무상 보증 기간(3개월) 아내에 아래의 현상이 발생할 시 제품 교환 서비스를 받을 수 있으나, 제품 A/S 접수비(양복 배송비)는 제조사 부담 후 유상 수리 대상일 시 고객 부담입니다.

※ 제품 교환 대상

- LED 동작 불량 전원 버튼 오작동에 따른 동작 불량 동봉된 배터리 소켓 불량 - 패키지 손상은 불량 및 교환 사유가 되지 않습니다.
- 유상 A/S : 유상 A/S 기간은 구입 후 최대 1년 이내 입니다. 무상 보증 내용에 해당하지 않는 제품 이상의 경우 유상으로 A/S를 받을 수 있습니다. 제품 A/S 접수비(왕복 배송비)는 고객 부담입니다.

※ 유상 A/S 대상

- -제품 구입한 날로부터 3개월이 경과한 경우
- 사용 중 고객 과실에 의한 기구물 및 회로물의 파손 - 임의 개조로 인해 제품이 파손된 경우
- 비인증 배터리 사용 등으로 인한 회로부의 파손
- 전원을 넣은 상태에서 침수, 우천 시 사용 등에 따라 발생된 회로부의 파손

6 A/S 신청 접수처

제품 문의 및 고객상담

주식회사 비트로 TEL: 02) 783-1945 MAIL: beatroas@beatro.co.kr 품질보증기간: 구매일로부터 3개월

정상적으로 사용한 제품의 경우 전화/이메일을 통한 고객상담 후, 제품 수리 및 교환 영영적으로 사용한 제품의 영후 전화/이메일을 통한 고객영품 후, 제품 구. 절차를 안내드립니다. 고객 과실의 경우 상담 시, 수리 비용과 택배 비용을 포함하여 안내드립니다.

RIIZE OFFICIAL FANLIGHT

1 Specification

PRODUCT: RIIZE OFFICIAL FANLIGHT

SIZE: ABOUT 95 X 95 X 250 (MM)

WEIGHT: ABOUT 350q POWER: AAA BATTERY 3EA

MATERIAL: ABS, PC, NYLON, PAPER

COMPONENTS: FANLIGHT, STRAP, USER MANUAL, STICKER OPERATING TIME: 4 HOURS

OPERATING TEMPERATURE: -20°C ~ 50°C

PLANNING & SALES: SM ENTERTAINMENT Co., Ltd. MANUFACTURER: BEATRO Co., Ltd.

COUNTRY OF MANUFACTURE : CHINA CERTIFICATION MODEL: SME-RIJZE-OFL01

KC : R-R-BTr-SME-RIIZE01

FCC ID: 2AS3Z-SME-RIIZE01

2 Caution <u>∧</u>

- Be careful not to give strong impact to the product or contact with water
- Do not disassemble or modify the product.
- Please use a genuine alkaline AAA battery.
- Please remove the batteries when they are not used for a long time
- Keep batteries out of the reach of children.
- Please dispose of used batteries at the designated disposal location. - Be sure to check the positive(+) and negative(-) polarity of the batteries to ensure proper installation.
- Incorrect installation of batteries may be the reason for product damage. as well as the danger of fire and burns.
- There may be a confusion while operating the bluetooth function.

3 How to use




MODE

- · POWER ON/OFF (Button Long Click)
- Press and hold the button for about 3 seconds to turn on or off the product.
- Normal Mode (Button One Click)
- With the power on, briefly press the button to change between LED modes. Motion Sensor The FANLIGHT is equipped with a motion sensor.
- ⚠ The clicking sound when shaking the light stick body is not a defect.
- Bluetooth Mode (Button Double Click) Bluetooth mode connects SMTOWN applications and fanlight to enjoy vareity of content Double-click the button to switch to Bluetooth mode (blue blinking), and double-click the button again to return to normal mode.
- ⚠ If there is no connection with the app within 15 seconds of Bluetooth mode, it automatically switches to normal mode.
- $\underline{\wedge}$ The color change is not functioning in Bluetooth MODE, and it is not a product defect.
 - The Fanlight can be controlled wirelessly only in normal mode.

4 Replacing Batteries

* If the battery voltage is low, the power will automatically shut off, so please replace it with a new battery



▲ Battery caution

- Please insert the batteries properly from the (-) to the (+) pole in order.
- There may be a risk of rupture and leak due to heat in the reverse insertion.
- Remove the batteries immediately if it suddenly heats up. (Don't hold by hands as there may be a risk of burns.)
- (If it is not genuine, there may be a damage to the p
- Do not charge, disassemble, short circuit, or heat, There may be a risk of injury due to explosion or leakage.
- Remove the batteries from the product after use it as the batteries may be leaked.
- Please use a new battery for each performance. - Do not mix the batteries with new and used one.

- Please use genuine alkaline AAA batteries.

- Do not store batteries in a pocket or bag without any package.

5 Warranty Period and Repair Service

- Any defect, replacement, or refund of the product, please contact your dealer. -The free warranty period is three months from the date of purchase at no additional cost. Even within the warranty period, repair costs may be charged if the defects of the product occur due to the customer's fault.
- -If the product is subject to repair it with cost, the shipping cost may be charged.
- Repair service is only provided after requesting the service through an email. When sending an email, please include the purchase receipt (including the date of purchase) and details of the faulty evide
- # Free Warranty Period: Product can be replaced within the free warranty period (3 months after the purchase date) for the following reasons.
- Defects of operation of LED and Wireless, Malfunction of the power button,
- Package damage is not eligible for a refund or replacement
- Paid repair service: Within the one (1) year after the date of purchase
- the product can be repaired for following reasons.
- After the free warranty (3 months after the date of purchase)
- Damages on the product or the circuit caused by customer's fault.
 Disassemble the product for any modification.
 Damages on the circuit by using non-certified battery.
- Damage on the circuits by water (i.e. using the product in the rain, soaked in water as powered on.

6 Customer Service Center

Product inquiry and customer service

BEATRO Co., Ltd.

TEL: +82) 2-783-1945 MAIL: beatroas@beatro.co.kr Warranty: 3 months from date of Purchase

How to apply for the repair service

In the case of proper use, we will provide information on how to repair or replace the product after consulting with the customer via phone call or email. In the event of improper use caused by the customer, we will provide a repair cost estimate that includes logistics costs for customer service.

FCC Notice

two conditions:

(i) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesire

FCC Caution ness or modifications to the equipment not expressly approved by the party

responsible for compliance could void user's authority to operate the equipment This equipment has been tested and found to comply with the limits for a Class B continued to the control of th

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into a cudist on a cloud different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

Radiation Exposure Statement The device has been evaluated to meet general RF exposure requirement in portable exposure







© SM ENTERTAINMENT Co., Ltd. All Rights Reserved.