# (Fold Inward)— — — ▶

# (Back Cover)

## (Front Cover)

## Compliance Information

FCC Information
This device complies with Part 15 of the FCC Rules.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure requirement.

## Rating Label Definitions





Bluetooth This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.

## Warranty Information

## 90-Day Limited Warranty

LIMITED WARRANTY TO ORIGINAL CONSUMER

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc.

This product as supplied and the Inc.

This product

To obtain warranty service:

• Visit our customer support portal: www.customersupport123.com and select "Support".

• Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request.

Warranty service not provided
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR REPAIR. REPLACEMENT, OR REPUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTORS SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMERS RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXCED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

# **ART+SOUND**



All product names, trademarks, and registered trademarks are pro their respective owners. All company, product, and service names this document are for identification purposes only. Use of these na trademarks, and brands does not imply endorsement.

**Getting Started** 

# **ART+SOUND**

Instruction Manual

**ART + SOUND BT HEADPHONE** 

EBP-22055

## Before You Begin...

## Customer Support For any questions or problems with your product, please visit our website at customersupport123.com

o ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories,

and supplies.

- THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device.
- Do not disassemble, modify, or repair the device.
- Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions.
- · Do not submerge in water.
- Low power may cause poor Bluetooth connection or sound distortion.
- Do not overcharge battery.
- If using with a USB adapter, make sure the adapter is not damaged. Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any

conductive materials such as liquids, metallic powders, etc.

• The headphones contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device.

## In the Box

- ARBT258 Dynamix Over-Ear Headphones (x1)
- Charging Cable (x1)
   Instruction Manual (x1)

# Location of Controls [- Increase Volume • Previous Track **∫•** Play/Pause L. Power On/Off □ Decrease Volume Bottom of Earcup Next Track – LED Indicator AUX Port 0 USB Charging Port -

## Charging the Headphones

Insert the small connector of the supplied USB charging cable into the USB charging port on the headphones. Insert the large connector into a USB power source, such as the USB port on a computer, or into a 5VUSB adapter (not included) and plug into a wall socket.


## Powering ON/Off

Long-press (2s) the Play/Pause button to power ON. Long-press (3s) the Play/Pause button to power OFF.

## Bluetooth Pairing

- 1. Power the headphones ON. A tone will be heard and the LED indicator will flash RED and Blue.
- 2. Set your mobile device to search for Bluetooth devices. When it
- appears, select ARBT258 from the list of found devices.

  3. Once successfully paired, a tone will be heard and the LED indicator
- will slowly flash BLUE.



## Playback

- Press the Play/Pause button to Play/Pause playback
- Press the button to skip to the PREVIOUS track
  Press the + button to skip to the NEXT track
- Press and hold the button to DECREASE the volume
   Press and hold the + button to INCREASE the volume

- Press the Play/Pause button to ANSWER/HANG UP a call
- Long-press (1.5s) the Play/Pause button to REJECT an incoming call • 3x Press the Play/Pause button to call back the most recent number

To connect directly to an external device, insert a 3.5 mm AUX cable (not included) to the AUX Port on the bottom of the earcup. Connect the other end of the cable to your external device.