Model: EBP-E-C130 Paper: Writing Paper ; Paper Weight: 0.15 Lbs

User Manual WARNING: LED LIGHT UP SPORT EARBUD Charging Your Bluetooth LED Earbud FCC statement: NEXT/V+ Use the micro USB cable provided with this earbud. This device complies with Part 15 of the FCC Rules. Operation is subject to the PREV/V- Charge and operate only as indicated in this manual, as improper use may Connect the micro USB plug to micro USB charging port on the earbud, then connect following two conditions: result in damage to the product or injury. the USB plug to a USB port on a computer or wall adapter to begin charging. LED Indicator (1) this device may not cause harmful interference, and (2) this device To avoid risk of shock or injury, do not dismantle the device or insert any The LED indicator will turn red and the light wire will light up while charging and will must accept any interference received, including interference that may cause objects into the earburds. turn blue once fully charged. undesired operation. To avoid electronic interference and/or compatible conflicts, turn off the NOTE: product in any facilities where posted notices instruct you to do so. Earbud will not charge while playing music. Only charge when erabud is not in use. Do not pull the earbuds charging cable. Damage may result to the cable. You must select a qualified charger from a regular manufacturer. Keep out of reach of children. This is not a tov. You must charge the bluetooth earbud if it has been not used for more than 3 months. Avoid exposure to moisture, liquids, heat, flame and high voltage equipment. NOTE Lower earbud power and / or low audio device power may cause poor operation and / o ON/OF Retain these instructions as they contain important information. This equipment has been tested and found to comply with the limits for a no Bluetooth connection. Do not short circuit the input terminals of the Bluetooth earbuds. Micro USB Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are Do not drop, place heavy weight or allow heavy impact to the earbuds. Charging Port designed to provide reasonable protection against harmful interference in a Do not heat or apply heat or dispose of the in fire. residential installation. This equipment generates, uses and can radiate radio Micro USB Plug Do not use the product while driving or crossing the road. frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Package Contents Technical Specifications RF warning statement: However, there is no guarantee that interference will not occur in a particular The device has been evaluated to meet general RF exposure requirement. installation. If this equipment does cause harmful interference to radio or television • LED Light Up Sport Earbud x1 The device can be used in portable exposure condition without restriction. reception, which can be determined by turning the equipment off and on, the user is Micro USB Charging Cable x1 · Bluetooth Version: 4.0 encouraged to try to correct the interference by one or more of the following measures User Manual x1 Frequency Response: 20Hz~20KHz Reorient or relocate the receiving antenna. Playing Time: 1.5hours Increase the separation between the equipment and receiver. Charge Time: 1.5hours · Connect the equipment into an outlet on a circuit different from that to which the Power On/Off Input: 5V === 150mA receiver is connected. Maximum Bluetooth Distance: 10m Consult the dealer or an experienced radio/TV technician for help. • ON/OFF Short press for pause or play / long press for on or off. · Built-in Rechargeable: 80mAh USB Cable: 30cm NEXT/V+ Short press for next song / long press increase volume. • PREV/V- Short press for previous song / long press reduce volume. Weight In Grams: 20g Led Light Cable: 40cm Keep All Relevant Information For Future Reference **!** WARNING: Changes or modifications to this unit not expressly Pair Bluetooth Earbud With Your Mobile Device approved by the party responsible for compliance could void the user's If the Bluetooth Earbud cannot be paired with your device please try the following: authority to operate the equipment. • Press the on/off button for 3-5 seconds, the LED indicator will flash to blue & red to Ensure that your Bluetooth Earbud is in pairing mode or reconnection mode. activate the bluetooth function. Ensure that Bluetooth search function of your mobile device is activated. · Activate the bluetooth function on your phone within range and select "SERIES8 BT BUD" from the list shown. If the Bluetooth Earbud will not be turned on: • The blue light will be flashing slowly and you will hear a "beep" sound when pairing Make sure the Earbud is fully charged. successful. The lighting wire will follow bluetooth LED light flashing as well. Can I change the battery for the Earbud? Long press on / off button for 3 seconds can change the light mode (light up mode / flashing mode). Bluetooth Earbud uses a built-in non-detachable battery which cannot be removed. · The bluetooth earbud will automatically connect with the last successfully paired device when power on. If the Bluetooth Earbud cannot be recharged: Maximum volume warning voice prompts "du du". If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the Note: Use the mobile phone to answer a phone call, the bluetooth earbud has NO USB port is powered. answer incoming call function.