

FCC Disclaimer:

This device Complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1- This device may not cause harmful interference, and
- 2- This device must accept any interference received, including Interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or on experienced radio/TV technician for help or assistance.

This equipment complies with FCC radiation exposure requirement set forth for an uncontrolled environment
The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment.
Such modifications or change could void the user's authority to operate the equipment.

Electronic and electrical devices disposal

This symbol indicates that electrical and electronic device is to be collected separately.



- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- If the device use batteries, they must be removed from the device and disposed in a appropriate collection center.
- If the batteries cannot be removed, do not attempt to do it yourself since it must be done by a qualified professional.
- Separate collection and recycling helps conserve natural resources and prevent negative consequence for human health and the environment that might result from incorrect disposal.

PARAMETERS

- Bluetooth version: v5.0
- Frequency: 100Hz - 16kHz
- Total playtime*: 10 hours
- Total standby time: 120 hours
- Charging time: 1-1.5 hour
- Bluetooth range: Up to 30ft
- Impedance: 16 Ohm ± 10%

CHARGING CASE

- Battery capacity: 250mAh
- Charging time: 1- 2 hours
- Universal micro-USB charging

*Depends on individual use
Warning: To prevent possible hearing damage, do not listen at high volume levels for long periods.



INSTRUCTION MANUAL: EBP-E-LHS023
TRUE WIRELESS STEREO EARBUDS WITH CHARGING CASE

TURN ON

Take the two earbuds out of the charging case. They will automatically turn on. Once the earbuds have powered up, you should hear a sound indicating that they have automatically connected with one another.

TURN OFF

There are two ways to turn off the earbuds. Once the earbuds have powered down, you will hear a sound indicating that they are turned off.

Method 1: Put the earbuds into the charging cradle. The earbuds will turn off and go into charging mode automatically.

Method 2: You can press and hold the control buttons on the earbuds for three seconds to turn them off.

To turn off case press on/off button.



- 1- Control Button
- 2- On/Off Button
- 3- LED Indicator
- 4- Charging Case

BLUETOOTH CONNECT

- 1 . Power the device on. The earbuds will pair with one another automatically when they are turned on. One of the earbuds will become the master earbud.
- 2 . Turn on your device's Bluetooth from the Bluetooth menu and select "MV_EBO206".
- 3 . When paired successfully the device will make a tone to confirm the connection has been made to your device.
- 4 . Remember to turn the earbuds off after each use to ensure longest play time.

Note: The earbuds will reconnect automatically if your device has been paired previously. Depending on your device's type and configuration, manual reconnection may be required each time.

CHARGING

- 1 . **EARBUDS:** Just place the earbuds into the charging cradle. The earbuds will automatically enter charging mode if the cradle is charged or connected to the power supply. The earbuds will display a red LED light while they are charging, and this will turn off when they are fully charged.
- 2 . **CASE:** Use the cable provided to connect the charging cradle to the power supply. The charging cradle's blue LEDs will flash while it is charging. When charging is complete all four LED lights will be on.

FUNCTION KEYS

- 1 . **PLAY/STOP MUSIC:** When playing music, quickly press either earbud's control button.
- 2 . **NEXT SONG:** When playing music, press and hold earbud's control button for 1.5 seconds*.
- 3 . **ANSWERING CALL:** When a call is received, briefly press either earbud's control button.
- 4 . **HANGING UP:** During a phone call, briefly press earbud's control button to end call.
- 5 . **REDIAL:** Press either earbud's control button twice quickly to dial last number on your call list.
- 6 . **DECLINING CALL:** When playing music, press and hold control button for 1.5 seconds*.

Note: If you hold control button for 3 seconds earbuds will power down.



©2020 Argento SC, All Rights Reserved.
Distributed by Argento SC, New York, NY 10018.
Designed in New York. Made in China.
MVMT and MVMT logo are registered trademarks of Argento SC. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Argento SC is under license.
www.argentosc.com
support@argentosc.com

▲ WARNING: The artwork and design of this package are protected by United States Copyright law and may not be reproduced, distributed, displayed, published, or used for any purpose without prior written permission. You may not alter or remove any trademark or copyright notice from this package. Because of continuous improvements, images and product specifications on packaging may differ slightly from actual product.