


Prelude SE MagSafe
Portable Wireless Charger X Stand

User Guide



MagSafe Wireless Charging Area

Power Indicator

Charging Indicator

USB-C Port

Power Button

Fold-Out Stand

Welcome to Prelude SE


Press and hold the Power button for about a second and the Power Indicators will light up. Prelude SE will go into standby mode for 2 minutes. Your Prelude SE is ready to go!

Prelude SE will turn off if there is no action for 2 minutes; or press the Power Button for 3 seconds - all LED indicators will turn off.

If the battery power is too low for the output, the 1st Power Indicator will blink. Please charge it fully.

Prelude SE as a Stand


The fold-out stand can be unfolded, and used as a phone stand.



Charging Prelude SE

Fully charge Prelude SE before using for the first time. Plug USB-C end of cable into Prelude SE USB-C port. Plug USB-A end of cable into power adapter (not included).

Use PPS/PD3.0/PD2.0/AFC/FCP/SFCP/PE2.0/PE1.1 USB adapter for improved fast recharging experience.



○ ○ ○ ○ ○	0% - 25%
○ ● ○ ○ ○	25% - 50%
○ ● ● ○ ○	50% - 75%
○ ● ● ● ○	75% - 100%
● ● ● ● ●	Fast Charging
○ ● ● ● ●	Standard Charging


Charging Your Device with Prelude SE

After the Prelude SE is fully charged, you can use it to charge your wireless or non-wireless devices.


Wireless Charging

- Press the Power button for 1 second, the Power Indicators will light up. Prelude SE is ready to go.
- Gently attach Prelude SE onto your iPhone MagSafe wireless charging area.

* MagSafe compatible wireless charging for iPhone MagSafe series.




- The Charging Indicator lights up red.
- Wireless charging, on the go.



Wired Charging

- Press the Power button for 1 second, the Power Indicators will light up. Prelude SE is ready to go.
- Connect the Prelude SE to your phone with a USB-C cable (not included).



● ● ● ● ● Fast Charging
○ ● ● ● ● Standard Charging

* Prelude SE supports PPS/PD3.0/PD2.0/QC4+ / QC3.0/QC2.0/AFC/FCP/SFCP/PE2.0/PE1.1 fast charging output.

Safety & Handling

- Keep wireless charging unit dry and away from liquids. Do not use on wet surfaces.
- Do not attempt to disassemble or modify charger.
- Always disconnect power supply before cleaning charger.
- Keep away from high heat. Use in the temperature range between -5 and 45 degrees Celsius (23 and 113 degrees Fahrenheit).
- Prelude SE is designed for faster and more efficient charging with iPhone MagSafe series and Apple MagSafe accessories.
- When charging a non-MagSafe Qi-compatible device with Prelude SE, power is reduced and charge times may be slower than on a typical Qi charger.
- Don't place credit cards, security badges, passports, or key fobs between your iPhone and Prelude SE, this may damage magnetic strips or RFID chips in those items.
- If you have a case that holds any of these sensitive items, remove them before charging or make sure that they aren't between the back of your device and Prelude SE.
- Your iPhone or Prelude SE might get slightly warmer while your iPhone charges. To extend the lifespan of your battery, if the battery gets too warm, software might limit charging above 80 percent.
- If you keep your iPhone in a leather case while charging with your Prelude SE, the case might show circular imprints from compression of the leather. This is normal, but if you're concerned about this, we suggest using a non-leather case.

Specifications

Battery Capacity 5000 mAh / 18.5Wh
 USB-C Input 5V = 3A, 9V = 2.2A
 Wireless Output 5W / 7.5W / 10W / 15W
 USB-C Output 5V = 3A, 9V = 2.2A

Package Contents

Prelude SE MagSafe Portable Wireless Charger X Stand X1
 USB-C Cable X1
 User Manual X1

The wireless charging function can only be realized when charging with an adapter.

FC CE RoHS REACH V E1.4

THANK YOU FOR YOUR ORDER!

Learn more about BEZALEL and our full line of wireless charging products at bezalel.co
 Contact us at support@bezalel.co



Prelude SE MagSafe
Portable Wireless Charger X Stand

Prelude SE MagSafe
立式磁吸無線行動電源

使用說明書



MagSafe 無線充電區域

電量指示燈

充電指示燈

USB-C 端口

電源按鍵

摺疊支架

歡迎使用 Prelude SE

短按電源按鍵1秒，電量指示燈會亮起，此時 Prelude SE 已開機，即可為設備進行充電。

若開機後2分鐘內，Prelude SE 未進行充/放電，電源將自動關閉，所有指示燈熄滅。長按電源鍵3秒，亦可手動開機。

電量指示燈LED1閃爍，表示低電量，需為Prelude SE 充電。

Prelude SE 作為支架

將Prelude SE 背面摺疊支架展開，可形成一種固的手機支架。



對 Prelude SE 充電

第一次使用之前，請為 Prelude SE 充滿電。

將充電線的 USB-C 端插入 Prelude SE 端口，USB-A 端接上 USB 電源供應器 (需另購) 進行充電。

使用 PPS/PD3.0/PD2.0/AFC/FCP/SFCP/PE2.0/PE1.1 快充技術的 USB 電源供應器 (需另購) 以得更好的充電體驗。



○ ○ ○ ○ ○	0% - 25%
○ ● ○ ○ ○	25% - 50%
○ ● ● ○ ○	50% - 75%
○ ● ● ● ○	75% - 100%
● ● ● ● ●	快速充電
○ ● ● ● ●	普通充電

使用 Prelude SE 對設備充電

當 Prelude SE 已充滿電後，即可對您的設備進行無線或有線充電。

無線充電

- 短按電源按鍵1秒，電量指示燈會亮起，此時 Prelude SE 已開機，即可為設備進行充電。
- 將 MagSafe 磁吸區域對準 iPhone 的無線充電區域即可將 Prelude SE 吸附在 iPhone 上。

* MagSafe 磁吸充電僅支援 iPhone MagSafe 系列手機。



- 當無線充電時，充電指示燈顯示為紅色。
- 開始享受隨時隨地充電的便利!



有線充電

- 短按電源按鍵1秒，電量指示燈會亮起，此時 Prelude SE 已開機，即可為設備進行充電。
- 使用 USB-C 充電線 (需另購) 連接 Prelude SE 與您的設備，即可開始為設備充電。



● ● ● ● ● 快速充電
○ ● ● ● ● 普通充電

* Prelude SE 支援 PPS/PD3.0/PD2.0/QC4+ / QC3.0 / QC2.0/AFC/FCP/SFCP/PE2.0/PE1.1 快充技術為其他設備充電。

注意事項

- 本產品為可充式鋰聚合物電池，額定容量因環境溫度、測試條件及測試方法而有所異，另因電池特性，其可用電量隨使用次數增加而減少。
- 使用時充電器本身發熱屬正常現象。
- 請在以下環境中使用本產品：溫度 -5 ~ 45 °C，當環境溫度超過45 °C時，請停止使用本產品。
- 請勿將本產品於高溫、高濕度或多塵的環境下保存、使用。
- 請勿摔、丟、強烈撞擊、施壓、拆解或擅自修復本產品。
- 請勿火燒、泡水、沖洗、冰凍、重摔、拆解、微波等任何對本產品產生不良影響之動作。
- 充電時，請勿將本產品放置於易燃物質上。
- 幼童使用本商品時，請監護人指導正確使用方式。
- 電池長時間處於充電狀態將有爆炸危險，於電池充滿時應停止充電。
- 本產品內含鋰電池，廢棄時應回收。
- 本產品是以理快且最有效的方式，為 iPhone MagSafe 系列手機和 Apple MagSafe 配件充電。
- 本產品為非 MagSafe 的 Qi 裝置充電時，功率會下降，且充電時間將比一般 Qi 充電器更久。
- 請勿將含有磁條或 RFID 晶片的物品放置於 iPhone 與本產品之間，若保護殼上有任何這類物品，請在充電前取下，或確保這些物品不在裝置與本產品之間。
- 透過本產品充電時，皮革保護殼可能會留下圓形痕跡，這是正常現象，建議使用非皮革保護殼。

規格說明

型號 BZ1PSE15
 電池容量 5000 mAh / 18.5 Wh
 額定容量 3000 mAh
 USB-C 輸入 5V = 3A, 9V = 2.2A
 無線輸出 5W / 7.5W / 10W / 15W
 USB-C 輸出 5V = 3A, 9V = 2.2A

盒內內容

Prelude SE MagSafe 立式磁吸無線行動電源 X1
 USB-C 充電線 X1
 User 使用說明書 X1

FC CE RoHS REACH V TC.1.4

感謝您的購買！

欲了解更多資訊請至 tw.bezalel.co
 或來信 info.tw@bezalel.co

7## † o
#

" u h 7## k u

u

=

@

- - k

- - @

- - #

- - #

ut

u 7## k \ two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter