


正面



包装清单 / Packing list

主机一台, USB 充电线一条, 中英文使用说明书一份。
One host, one USB charging cable, one instruction Manual.

使用说明 / Instructions for use

- ①第一次使用本产品前请充满电, 充电电压 5V, 可使用移动电源或电脑充电, 充电时间约 2~3 小时, 充电指示灯灭表示充满电。
- ②短按一次开关, 风扇一档启动; 短按第二次, 风扇二档; 短按三次, 风扇三档; 短按 4 次关机。
- ③满电状态下, 根据不同风速可使用 3-6 小时不等。
- ④短按一次背面开关打开蓝牙音箱, 继续短按一次关闭。
- ⑤长按蓝牙开关 5 秒打开蓝牙, 指示灯进入闪烁状态即可进行蓝牙配对, 蓝牙名称为 “LY999”。

- ①Please fully charge the battery before using it for the first time. The charging voltage is 5V. It can be charged by mobile power or computer. The charging time is about 2-3 hours. When the charging indicator is off, it means full charge.
- ②Short press once, the fan starts first; short press the second time, the second gear of the fan; Short press three times, the third gear of the fan; Short press 4 times to shut down.
- ③At full power, it can be used for 3 to 6 hours depending on the wind speed
- ④Press the back switch once to turn on the Bluetooth speaker and continue to press it once to turn it off.
- ⑤Long press the Bluetooth switch for 5 seconds to turn on the Bluetooth indicator light flashes to perform Bluetooth pairing the Bluetooth name is “LY999” .

安全守则 / Safety regulations

为确保安全, 请先仔细阅读及遵守以下的安全守则:

- 任何边缘切割位、不平滑的表面、金属零件、配件或包装均有可能因意外而引致流血或受伤, 请务必小心使用。不可将本产品置于口中。
- 请勿擅自改装、修理或拆除本产品。不适当的处理可能导致电线短路、产品损坏甚至火灾。曾被擅自改动的产品, 均会失去保修效力。
- 请在 0-40℃ 温度环境下使用本产品, 不得暴露在诸如高温日照、火烤或类似的过热环境中。
- 请勿在潮湿环境中(如浴室)使用本产品, 接触水可能会导致产品故障或损坏。
- 请尽量避免本产品跌落、碰撞或挤压。
- 不可将本产品放在有强烈磁场或是电场的环境, 否则可能导致产品发生故障。
- 本产品弃置在明火中可能会引起爆炸。
- 请勿使用超过规定电压充电本产品。
- 当产品充电完成, 请确保及时拔出充电线。
- 请勿在地毯, 被子等易燃性物体表面对产品充电。
- 10 岁以下小孩使用请告知不要将手伸进风扇内, 以免划伤。
- 风扇工作时风叶会高速旋转, 严禁将异物伸进风扇内, 否则可能会损害机器。
- 若有漏液情况发生, 身体不慎接触到液体, 请冲洗干净或寻求医生帮助。请勿继续使用产品。

For security, please read and observe the following safety codes:

- Any cutting edge , uneven surface, metal parts, accessories or packaging may cause bleeding or injury due to accidents, so please be careful. Do not place this product in mouth.
- Do not refit, repair or disassemble this product. Improper handling may cause short circuit, product damage or even fire. Products that have been arbitrarily altered will lose the warranty.
- Please use the product in the temperature of 0-40 °C, and should not be exposed in high temperature sunshine, fire roasted or similar overheated environment.
- Please don't use this product in damp environment (such as bathroom). Touching with water may cause the product to malfunction or damage.
- Please try to avoid dropping, colliding or squeezing the product.
- Please don't place this product in a strong magnetic field or electric field environment, otherwise it may cause the product to malfunction.
- Disposing of this product in open flame may cause explosion.
- Please don't charge the product beyond the specified voltage.
- When the product is fully charged, please ensure that the charging cable is pulled out in time.
- Please don't charge the product on the surface of flammable objects such as carpet, quilt.
- Children under 10 years old Please advise not to put their hand into the fan to avoid scratching.
- When the fan is working, the blades will rotate at a high speed. Please don't put foreign objects into the fan. Otherwise, the machine may be damaged.
- If leakage occurs, the body inadvertently touches the liquid, Please rinse or seek medical help. Do not continue to use the product.



背面

保修卡 / Warranty Card

型号 / Model.:
产品名称 / Product name:
购买日期 / Date of purchase:
销售商 / Dealer:

客户名称 / Customer name:
地址 / Address:
联系方式 / Tel:

感谢您购买本产品。本产品的保修期为购买之日起 12 个月。请务必妥善填写并保存此保修卡以备保修使用。

Thank you for purchasing this stylepie product. Our product' s warranty period is 12 months starting from the day of purchase. Please complete the warranty card and use for any future warranty service.

(如需保修, 请沿虚线剪下。 / For warranty, please cut along the dotted line.)

保修及支持服务 / Warranty and support services

承蒙惠购本公司产品, 谨致谢意! 本公司为了切实保护消费者放心使用本公司优质的产品, 将严格遵守国家颁布的有关法律遵照《中国消费者权益保护法》《中国产品质量法》的具体条款以及“三包”的相关规定, 规范我司售后服务制度。现对您所享受的保修权益作以下说明:


- 1) 购买下单时, 请留下您的真实信息, 如因联系方式不准确导致本公司无法实际履行免费保修的服务义务, 购买者自行承担。
- 2) 若在正常使用情况下, 由于产品本身质量问题引起的故障, 在保修期内, 我司将承担免费的维修服务。自购买本产品之日起, 享有一年的免费保修服务。
- 3) 下列情况不属于保修范围:
 - 因使用不当或缺乏合理的保养造成的产品损坏(如使用错误的电流电压, 将产品插入不合格的插座, 其他人为破坏等)。
 - 因火灾、地震、水灾、雷击、其他自然灾害、公害或电源、电压异常等造成的产品故障或损坏。
- 4) 保修期内终止保修的情况:
 - 产品经非本公司授权人员的修理或拆装。
 - 产品使用非本公司的零件。
 - 产品非家庭使用(如工业用、商业用等)引起的损坏。在保修期内替换零件或整机。
 - 在保修期内、对于因材料或生产引起的各种瑕疵, 公司予以更换零件或产品。申请保修时请务必将瑕疵产品以及能够证明购买日期的单据(购买发票)一并送至本公司授权的客服中心。
- 6) 在保修期内所替换的零件或整机为本公司所有。

Thank you for purchasing our products. In order to effectively protect consumers to use quality products of our company, we will strictly abide by the relevant laws issued by the state and comply with the specific provisions of China consumer rights and interests protection law and China product quality law. Here is a description of your warranty rights:

- 1) Please leave your true information when placing the order. If the company cannot actually perform the service obligation of free warranty due to the inaccurate contact information, the buyer shall bear the responsibility.
- 2) In case of failure caused by product quality problems under normal use, our company will undertake the maintenance service for free within the warranty period. From the date of purchase of this product, enjoy one year of free warranty service.
- 3) The following situations are not covered by warranty:
 - Caused by improper use or lack of reasonable maintenance of product damage (such as using the wrong current voltage, insert the products unqualified socket, other man-made destruction, etc.
 - Due to fire, earthquake, flood, lightning and other natural disasters, public nuisance or power supply, such as abnormal voltage caused by the product failure or damage.
- 4) Termination of the warranty period:
 - Products are not authorized by the company to repair or disassemble
 - Product use non-company components.
- 5) During the warranty period, the company will replace the parts or products for various defects caused by materials or production. When applying for the warranty, please be sure to send the defective product together with the purchase date (purchase invoice) to the customer service center authorized by the company.
- 6) The replacement parts or complete machines within the warranty period are owned by the company.

产品参数 / Specifications

产品名称 / Product name:	甜朵朵音乐风扇 / Music Fan
材质 / Material:	ABS
产品重量 / Product weight:	175g
额定输入 / Rated input:	DC 5V ==
使用功率 / Power:	4W
产品尺寸 / Product size:	201*100*60mm
执行标准 / Products Execution Standard:	GB 4706.1-2005/GB 4706.27-2008/GB 8898-2011
产地 / Origin:	中国深圳 / Shenzhen, China



甜朵朵音乐风扇使用说明书

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction