

FCC ID:2ASBG-YH8203G

* When reclining the chair be sure there is no one behind or front of the chair .Be sure there are NO obstructions around the chair .

* Do not put fingers , hands or limbs in the cracks of the chair or armrest or backrest or the back of the chair .

* Children should NOT use this product.

* Do not modify or alter this product in any way .

This may cause serious injury.

* After using the chair please turn "off" the power from the back of chair and unplug from the wall. This will prevent power surges from damaging the chair.

