

MINISO

PRODUCT MANUAL 使用說明書

時尚簡約藍牙頭戴式耳機 WIRELESS HEADPHONES

Model: V4

使用產品前請仔細閱讀本使用說明書，並請妥善保管。

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT IN A SAFE PLACE.

產品介紹

感謝您購買和使用V4藍牙耳機。

此手冊將指引您如何使用您的藍牙耳機，在使用藍牙耳機之前，您必須先瞭解和熟悉您手機的藍牙功能或其他藍牙主動設備的藍牙功能，如電腦藍牙功能。

安全規則：

- 為確保安全，敬請遵守此手冊中提到的規則，在使用藍牙耳機之前我們強烈建議您閱讀此手冊。
- 請注重提防鋒利的邊緣，不平的表面，金屬件，配件和包裝，以避免出現任何可能的傷害。
- 請不要私自拆除、維修此產品，否則可能會導致起火，電子擊穿甚至徹底損壞本產品，這些都不在保修之列。
- 請不要油及其他揮發性液體擦拭本產品。
- 請不要在有危險的地方使用本產品。

附件清單

藍牙耳機X1 USB充電線X1

結構介紹

- 可折疊便攜設計
- ▶ 音量+ / 上一首
- ▶ 多功能按鍵(詳見功能介紹)
- ▶ 音量- / 下一首
- Ⓜ 充電插口
- Ⓜ 有線插口
- Ⓜ 麥克風
- Ⓜ 提示燈

技術參數

藍牙版本: V5.0
支援藍牙協定: HSP HFP A2DP AVRCP
無線傳輸範圍: 10m
靈敏度: -80dB \pm 0.1%BER
頻率範圍: 20HZ-20KHZ
播放音樂時間: 7-9 HOURS
通話時間: 8-11 HOURS
待機時間: 400-500 HOURS
電池: DC3.7V 鋰電池 250mAh
充電輸入/時間: DC5V / 210mA 3.5~4.5HOURS
音訊輸入: 3.5mm

功能介紹

1. 開機: 在開機的狀態下按住 **▶** 鍵3秒, (紅藍色的LED燈交替閃爍, 同時有“開機 進入配對模式”語音提示) 自動進入配對模式;
2. 配對: 使用藍牙功能的手機或主動設備的藍牙功能匹配(詳情參考後面的配對章節)。
3. 播放/暫停: 當在播放的時候, 按 **▶** 鍵實現暫停播放, 在暫停時按此鍵繼續播放。
4. 音量加: 按 **▶** 鍵增加音量。
5. 音量減: 按 **▶** 鍵降低音量。
6. 長按 **▶** 播放下一首曲目。
7. 長按 **▶** 播放上一首曲目。
8. 接聽電話: 按 **▶** 鍵。
9. 結束通話: 按 **▶** 鍵。
10. 拒絕來電: 來電狀態下長按 **▶** 鍵2秒;
11. 關機: 待機或者工作狀態下按 **▶** 鍵3秒關機(發出語音提示“關機”同時LED燈亮2秒)。

12. 充電: 將充電器插入充電的埠(紅色燈常亮), 充滿為紅燈熄滅;
13. 連接藍牙設備: 按照配對方法, 藍牙耳機與手機配對成功後, 手機來電時, 按 **▶** 接聽電話進行通話。
14. 重播最近電話: 待機模式或播放音樂模式下, 按兩下 **▶** 鍵。
15. 語音助手: 長按 **▶** 鍵2秒聽到提示音後鬆手。

與手機匹配

首先必須讓藍牙耳機與手機或其他設備進行配對, 如果藍牙耳機和該設備配對過, 在有效的範圍內, 設備和藍牙耳機會自動連接;

- 藍牙耳機開機並進入配對模式;
- 開啟手機藍牙功能並進行搜索藍牙耳機;
- 從手機找到的藍牙設備清單中選擇該耳機: “MINISO-V4”;
- 若系統提示, 請輸入“0000”作為配對碼, 從而將手機配對並連接到手機上;
- 手機提示您確認此配對, 請按OK或YES;
- 手機與藍牙耳機已經連接好, 至此連接完成。

與電腦匹配

如果您的電腦沒有藍牙功能, 您可以插上一個USB介面的藍牙適配器並按該設備的操作說明啟動適配器;
打開您的電腦上的藍牙控制軟體或作業系統自帶的軟體, 如IVT軟體, 選擇搜索藍牙設備;
搜索到藍牙耳機後, “MINISO-V4”將顯示在搜索到的裝置清單裡, 選擇此裝置, 點擊滑鼠右鍵, 選擇“匹配此裝置”選項, 再次選擇此裝置, 點擊滑鼠右鍵, 選擇“連接音訊裝置”選項;
至此, 您的藍牙耳機已與電腦建立連接, 然後打開您電腦的媒體播放或播放音樂, 或看電影, 或玩遊戲, 所有聲音將會從藍牙耳機傳出。

對耳機進行充電

1. 將充電器連接至耳機上的充電埠;
2. 充電期間, 指示燈會變成紅色;
3. 耳機充滿時, 紅色指示燈會熄滅, 從電源插座上拔下充電器;
4. 請使用本產品配套的充電線, 否則有可能會導致損壞耳機, 或在極端環境下導致爆炸。
5. 重複對耳機進行充電和放電將會隨時間推移而導致電池效能下降, 這對所有可再充電電池來說為正常現象。

安全規則

1. 本產品並非玩具, 兒童請在成人監護下使用耳機。
2. 請勿將設備至於過高或過低(0°C以下45°C以上)的環境下。
3. 請避免兒童或者動物的眼睛靠近設備指示燈。
4. 在高音量使用下, 請勿長時間佩戴。避免對您的聽力造成損傷。
5. 為了出行安全, 請您在開車或者行走中使用耳機時注意交通安全。
6. 為了保證您的人身安全, 請勿將耳機佩戴或放置離心臟起搏器過近的地方(小於10CM)。
7. 請勿在雷暴天氣下使用藍牙設備, 雷暴可導致設備工作不正常, 並增加觸電的危險。

MADE IN CHINA
FABRIQUÉ EN CHINE
صنع في الصين
HECHO EN CHINA
www.miniso.jp



PRODUCT INTRODUCTION

Thank you for purchasing V4 Wireless Headphones.

In order to better understand this product, read the user manual carefully before using it.

Important Safety Instructions:

- To ensure safety, please follow the instructions mentioned in this manual and your reading this manual before using the wireless headphones is recommended.
- Beware of sharp edges, uneven surfaces, metal objects, accessories and packaging to avoid any possible damage.
- Please do not dismantle or repair this product. Otherwise, it may cause fire, electronic breakdown or even complete damage to the product, which are not covered by the warranty.
- Do not wipe the product with oil or other volatile liquids.
- Do not use this product in place of potential danger.

PRODUCT AND ACCESSORIES

Wireless Headphones x1 USB charging cable x1

STRUCTURE

Foldable design

- ▶ Volume + / Previous track
- ▶ Multifunctional Button (Refer to Functions for details)
- ▶ Volume - / Next track
- Ⓜ Charging port
- Ⓜ Wire port
- Ⓜ Microphone
- Ⓜ Indicator light

SPECIFICATIONS

BT version: V5.0
BT protocol: HSP HFP A2DP AVRCP
Transmission distance: 10m
Sensitivity: -80dB \pm 0.1%BER
Frequency range: 20Hz-20KHz
Play time: 7-9 Hours
Call time: 8-11 Hours
Standby time: 400-500 Hours
Battery: DC3.7V lithium battery 250mAh
Input/Charging time: DC5V / 210mA, 3.5~4.5hours
Audio input: 3.5mm

FUNCTIONS

1. Turning on: press **▶** button for 3 seconds, (red and blue LED lights flash alternatively and “turn on, enter pairing mode” voice prompt can be heard), and the headphones enter pairing mode automatically.
2. Pairing: use the BT function of mobile phones or other device.
3. Play/Pause: press the **▶** to play or pause.
4. Volume up: press **▶** to increase the volume.
5. Volume down: press **▶** button to decrease the volume.
6. Long press **▶** to play the next track.
7. Long press **▶** to play the previous track.
8. Answering a call: press **▶** button.
9. Ending a call: press **▶** button.
10. Rejecting a call: long press **▶** button for 2 seconds.
11. Turning off: long press **▶** button for 3 seconds to turn the device off (voice prompt “turn off” can be heard and the LED light will be on for 2 seconds).

12. Charging: connect the charger to the charging port(red light will be on).The red light will dim out when charging is completed.
13. Connecting to a BT device: according to the pairing method, when the headphones are successfully paired with a mobile phone, phone calls can be answered by pressing the Answering button.
14. Redial the last call: Press **▶** button twice in ready mode or playing mode.
15. Voice assistant: long press **▶** for two seconds until hearing the voice prompt.

PAIRING WITH A MOBILE PHONE

Firstly, the headphones should pair with a cellphone or other device. If the headphones were successfully paired with the device before, the headphones will pair with the device automatically within the effective range.

- Turn on the headphone and it will enter pairing mode.
- Turn on the phone's BT function and search for the wireless headphones (refer to the user manual of the mobile phone for details);
- Choose “MINISO-V4” in the BT device list of the mobile phone
- If prompted, please type “0000” as the pairing code to pair and connect the headphones to the phone;
- If you are prompted to confirm the pairing, please press OK or YES.
- Pairing between the phone and the headphones is now completed.

PAIRING WITH A COMPUTER

If your computer is not equipped with the BT function, you can insert a BT adapter and start the adapter according to the operating instructions of the device.

Open the BT control software on your computer or the software that comes with the operating system, such as IVT software, and search for BT devices;
After searching for the headphones, “MINISO-V4” will be in the searched device list, select this device, click the right mouse button, select the “match this device” option, select the device again, click the right button and select “ Connect to audio device” option;
At this point, your headphone is connected to your computer, and all sounds from your computer's media player, music, movie or game will be heard from the headphones.

CHARGING THE HEADPHONES

1. Connect the charger to the charging port on the headphones;
2. The indicator light will turn red during charging;
3. When fully charged, the red light will dim out. Remove the charger from the power source.
4. Please charge with the charging cable provided with the product, otherwise it may cause damage to the headphones or even explosion in extreme events.
5. Repeated charging and discharging of the headphones will cause a decrease in battery capacity over time. This is a normal phenomenon for all rechargeable batteries.

SAFETY INSTRUCTIONS

1. The product is not a toy. Children should use the headphones under the supervision of adults.
2. Do not use the product at too high or too low a temperature (below 0°C or above 45°C).

3. Please keep children or animals' eyes away from the indicator light.
4. Do not wear for a long time at high volume to avoid damaging your hearing.
5. To travel safely, please pay attention to the traffic when using headphones while driving or walking.
6. To ensure your safety, do not wear or place the headphones too close to the cardiac pacemaker(less than 10cm).
7. Do not use the device during thunderstorms. Thunderstorms can cause the device to malfunction and increase the risk of electric shock.

FCC Warning:
This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation.
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:—Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

MADE IN CHINA
FABRIQUÉ EN CHINE
صنع في الصين
HECHO EN CHINA
www.miniso.jp

