


PHOTOGRAPHS OF THE TEST CONFIGURATION

Set UUT as Client mode (Radar injected into Master)



Reference No.: BCKS-WTW-P21050677_TSup_DFS Page No. 1 / 1