


 wireless watchdock duo

1

Remove the gray silicone bottom from the **watchdock**.

Enlevez le socle en silicone gris du poste **watchdock**.

Quite el fondo gris de silicona del **watchdock**.

Rimuovere la base in silicone grigio dal **watchdock**.

Den grauen Silikonsockel vom **watchdock** entfernen.

2

Plug your Apple watch charging cable (not included) into the "watch" opening on the underside of the **watchdock**. Plug the included Type-C cable into the "input" on the underside of the **watchdock**.

Branchez le câble de charge de votre montre Apple Watch (non fourni) dans l'ouverture marquée « watch » du dessous du **watchdock**. Branchez le câble de Type-C fourni dans le port marqué « input » (entrée) du dessous du **watchdock**.

Enchufe el cable de carga de su Apple Watch (no incluido) en el orificio "watch" de la parte inferior del **watchdock**. Enchufe el cable Type-C incluido en el orificio "input" de la parte inferior del **watchdock**.

Collegare il cavo di ricarica dell'Apple Watch (non incluso) all'apertura "watch" sul lato inferiore del **watchdock**. Collegare il cavo di Type-C in dotazione nell'"input" sul lato inferiore del **watchdock**.

Das Ladekabel Ihrer Apple-Watch (nicht im Lieferumfang inbegriffen) in den Anschluss „watch“ an der Unterseite des **watchdock** einstecken. Das mitgelieferte Type-C-Kabel in den Anschluss „input“ an der Unterseite des **watchdock** einstecken.

3

Pull the interior channel of the **watchdock** out. Wrap your Apple watch charging cable around it, keeping the Type-C charging cable hanging freely (do not tangle it).




Tirez sur la gouttière intérieure du **watchdock** pour la dégager. Enroulez le câble de charge Apple Watch autour, en laissant le câble de charge de Type-C pendre librement (ne pas l'emmêler).

Tire el perfil interior del **watchdock** hacia fuera. Envuelva el cable de carga de su Apple Watch alrededor del perfil, dejando que el cable Type-C penda libremente (no lo enrede).

Estrarre il canale interno del **watchdock**. Avvolgere il cavo di ricarica intorno all'Apple Watch, lasciando pendere liberamente il cavo di ricarica di Type-C (senza aggrovigliarlo).

Die innere Kabelführung des **watchdock** herausziehen. Das Ladekabel Ihrer Apple-Watch um die Kabelführung wickeln, wobei das Type-C-Ladekabel weiterhin frei herunter hängt (nicht miteinander verheddern).

Ventev
11126 McCormick Rd
Hunt Valley, MD 21031
(800) 759-9996

4

Insert your Apple watch charging cable head into the front slot of the **watchdock**.

Introduisez la tête du câble de charge Apple Watch dans la fente avant du **watchdock**.

Insere la cabeza del cable de carga de Apple Watch en la ranura delantera del **watchdock**.

Inserire la testa del cavo di ricarica dell'Apple Watch nello slot anteriore del **watchdock**.

Das Ladekabelende Ihrer Apple-Watch in den vorderen Schlitz des **watchdock** einführen.

5

Pull your Type-C charging cable through the bottom channel of the gray silicone bottom and set your **watchdock** into the silicone bottom.

Tirez sur le câble de charge de Type-C pour le faire passer par la gouttière inférieure du socle en silicone gris et introduire le poste **watchdock** dans ce socle.

Tire el cable de carga Type-C a través del perfil inferior del fondo gris de silicona y coloque el **watchdock** en el fondo de silicona.

Inserire il cavo di ricarica di Type-C nel canale inferiore della base in silicone grigio e montare il **watchdock** nella base stessa.

Das Type-C-Ladekabel durch die untere Kabelführung des grauen Silikonsockels ziehen und das **watchdock** in den Silikonsockel platzieren.

This device complies with Part 18 of the FCC Rules.

NOTE: This equipment has been tested and found to comply with the limits for a wireless power charger, pursuant to Part 18 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

JANSY Ventev / Wireless Watchdock Instructions
job number: 32510 date: 1.11.18

die line: recommended: 97mm x 114mm (38x48.5mm folded)
file name: VEN-32510_WirelessWatchdock_Manual_L5lang_AW_V4


final die line
final concept

version: 04

designed by: ---
amended by: Nicole Meehling
project manager: Cody Cooke

final approval: name _____ date _____
materials used: C2S paper

finishes: specials:

inks:


notes: please confirm that suggested dimensions will fit in the fulfilled product packaging.

This drawing is the exclusive intellectual property of Jansy Packaging, LLC. No part of this drawing may be reproduced or published, without the express written consent of Jansy Packaging, LLC.