## Free music

Warm I tps.

J in order to svoid damage to your hearing and prolong the speaker's use-life, please don't listen to music for long power switch, unplug the USB plug, prevent speaker and power switch, unplug the USB plug, prevent speaker and power switch, unplug the USB plug, prevent speaker and other components damaged.

S. Over use of battery will affect the Bluetooth distance and use-life, please charge in time.

7. Restore to factory settings in Bluetooth connection mode, long press "M"key for 3 seconds, the blue light will blink rapidly, restoring the speaker to factory settings.

6. Charging

Connect the Micro &P charging cable to speaker's Micro
USB port, insert the other end to the USB port of a 5V
charger. A red light is illuminated when charging, and will
switch off when full charge is reached.

B. Mode Switch(Bluetooth-TF Card-AUX-FM)
When speaker is on with TF Card in nearled, click "M" key to swit
Ch to swirch through different modes one by one in this order:
Bluetooth-TF Card - FM - AUX - Bluetooth.
(FM Modes:Connecting the USB cable to be FM Antenna,long
press "play / pause" automatic search platform.Some items do
press "play / pause" automatic search platform.Some items do
not have AUX, FM modes).

4. Hands tree phone call operation

1. When a phone call is incoming, the blue light remains on.

3. When on an active call, short press "Play/Pause/Phone" key to reject the call.

3. When on an active call, short press "Play/Pause/Phone" to hang up.

3. When the Speaker is in standby /music mode, doublepress the "Play/Pause/Phone" to hang up.

4. long press"Vol-/Previous song", reduces speaker volume; 5. long press"Vol+/Next song", increase speaker volume and you will hear a prompt when maximum volume is reached.

song:

3. Short press "Vol+/Next song", the speaker will play the next

previous song:

pause music to answer a call. A second short press second will resume playing music again;
2. Short press "Vol-/Previous song", the speaker will play the


3. When you play music

When pairing, the blue light will blink quickly; use cell phone or computer or other device search device name "A10", click to connect, blue light turn off when connection successful; blue light blink durckly when connection out of range.

. Ellectooff Connection
Follow the operating instructions of your Bluetooth device
for pairing with fits e speaker. Typically this is done by going to
the "Bluetooth", "Set Up" or "Connect" menu and selecting the
option to search for Bluetooth devices.

7.ON/OFF Switch to the right to power on. The blue light will blink end on. Slide ON/OFF switch to the left; the blue light will blink and the unit will power off.

1.Mic 2.0H/OFF 3.7T Card Slot 6.0H/OFF 5.0H/OFF 7.0H/Vext song 7.0H/Vext song 7.0H-Vext song 9.0H-Vext song 9.0



Enuction Keys:

# Minimalist Style Reflective Light BT-Speaker Owe Tower

### Dear customer:

Thank you for purchasing A10 Mini Wireless Speaker. Please read this user guide carefully before operation and save these instructions for future reference.

# Packaging included:

rackaging niciuded.	
I. Portable Speaker	1 p
2. Usb line (FM Antenna) 1	рс
3. User manual	1 00

### Features:


Active Suspension Lighting Effect Minimal Art Aluminum Anode Captivating sound. Glowing design Designed for modern life











Opening Option Colors

· Speaker Output frequency range:150Hz-20KHz

# Features:







Hands Free

Specifications:
Output Power: 3W
Discharge Current: 5V/0.5A
Battery: 300mah 3.7V
Charging Current: 200mA

# FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

# **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.