

**maxwest**

**ASTRO A63**

**User Manual**

### Overview

- 1 Front Camera
- 2 Volume Keys
- 3 Power Key
- 4 Recent
- 5 Home
- 6 Back
- 7 Rear Camera
- 8 Flash
- 9 Google Assistant

### SIM Card Installation

A SIM card contains your phone number and other necessary data. Your device has SIM1&2 slot that supports 4G (LTE).

**To Install the SIM Card**

- Make sure the device is turned off and the front facing down. Hold the firmly and use the notch at the bottom corner to loosen the cover. Use the notch with a hard, thin edge such as your fingernail or a credit card to carefully run along the seam to loosen, then lift the cover until it detaches completely.
- Locate the SIM card slot and insert the proper SIM card into the proper slot. For more information on SIM card installation check out the Included SIM Card & Micro SD Card Installation Guide.
- To turn on/off a SIM card go to Settings > SIM management, then slide the SIM card slides to turn on/off a SIM card & data connection, go to Settings > SIM management, click on the "Data connection" option, and select a SIM card that has 4G capability.

**Keys/Touch Points**

**Power Key** [ ]: To power on/off it, press and hold power key for a few seconds. When it's ON, press the power key once to activate or deactivate the screen.

**Options key** [ ]: In home screen, touch the key to set wallpaper, manage apps, and to access system settings. Touch it to view menu options.

**Back key** [ ]: Touch to go back to the previous menu.

### Charging battery

New batteries are shipped partially charged. Before using your device, install and charge the battery. Batteries perform best after several full charge/discharge cycles.

**Charging Your Battery**

Please charge the battery using the following method:

- Charge the phone by connecting it to a computer via the USB cable.
- Connect the USB cable to the phone and the AC adapter. Plug the AC adapter into an electrical outlet to start charging.

As the battery charges, an icon will appear in the status bar of the home screen. When the battery is fully charged, a full battery icon appears on screen.

**Warning:**

- Do not remove the battery while the device is charging.
- Use only the AC adapter & USB cables provided with your device.
- Note: For safety, the battery will stop charging if in danger of overheating.

### Audio Profile/Sleep Mode

**Intelligent keyboard**

From the home screen, swipe up to open APP Drawer & select "Settings". Go to "Sound" and change the audio settings by changing sound levels and change your ring tones.

**Sleep Mode**

Turn on sleep mode to save your battery power.

- On the home screen, touch "App Menu" & select "Settings".
- Select "Display".
- Select "Sleep" and choose a time interval from the list.

**Screen Lock**

- On the home screen, touch the "APP Menu" & select "Settings".
- Select "Security and lock" > then select "Screen lock".
- Select the desired type of lock & follow the prompts to set up.

### Phone Features

**Description Icons**

Icon	Description	Icon	Description
	Show the phone's network signal strength.		Show the phone's battery capacity.
	Speaker has been deactivated.		You have unread SMS.
	Call on hold.		USB storage turned on.
	The ringing type is set on vibration.		Flight Mode.
	4G network is on.		3G network is on.
	You have missed calls.		A clock alarm is active.
	In call.		Bluetooth ON.

**Main Menu & Its Functions**

Select to enter the main menu. Allow you to view a list of features available in your phone.

- Clock**  
Allow you to set the Alarm from Clock.
- Browser**  
Browse the Internet. Search engine default set to Google.
- Calculator**  
Allow you to make tedious calculations quickly.
- Calendar**  
View the calendar & add events.
- Camera**  
Allow you to click pictures anytime you want. Your astro A63 has 5 MP High Definition camera with LED flash supporting many special features like Face Detection which enables you to take good quality pictures and store them in the Gallery. In Camera, easily choose Comma/Order triggered video.
- Contact**  
Take you to list of Contacts. Access your digital phonebook through this function.
- Email**  
Allow you to set up your PDF/MAP email accounts.

### Phone Features

- Gallery**  
Swipe it right, fast and easy to use offline gallery.
- Google Play**  
Google Play is your entertainment hubland. It brings together all of the entertainment you love and helps you explore it in new ways, anytime, anywhere.

Note:

To use this app please connect to an Internet connection.

- Messaging**  
Allow you to view messages sent & received as a thread.
- YouTube Music**  
The music streaming app. Made by YouTube. Discover all the music on YouTube that you can't find anywhere else, organized in one new app and web player.

- Phone Manager**  
Allow you to make phone calls.
- Phone Manager**  
You could browse, view, modify and install your files.
- Phone Manager**  
The service is provided by the operator. It provides phone plan information.
- Secure Recorder**  
Allow you to record sounds.
- Video**  
View from list of videos.

**maxwest**

**ASTRO A63**

### Phone calls/Texting

**To Make Phone Calls**

- Touch the phone icon.
- Click on a contact from your contact list to make a call.

**Composing text messages**

Maxwest automatically corrects and suggests words as you type.

**Cut, Copy and Paste**

Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then choose to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.

### WLAN

**Turn on WLAN**

Maxwest supports WLAN direct which allows Android™ 13 or later devices with the appropriate hardware to connect directly to each other via WiFi without an intermediate access point. Using the API, you can discover and connect to other devices. If each device supports WiFi Direct, then communicate over a speedy connection across distances much longer than a Bluetooth connection. This is useful for applications that share data among users, such as a multiplayer game or the sharing.

**WiFi Direct**

6. Click "OK" and the devices will be connected.

**Compose**

Capture images or record videos and share with family and friends!

Switch to front/rear camera

Take Picture

Picture Review

### Camera

6. Click "OK" and the devices will be connected.

**Compose new:**

- Press MENU & select "Compose".
- Add recipients by typing a name or email address in the "to" field. Matching contacts will appear. Select a recipient or continue typing in the email address to send to multiple contacts.
- Once finished typing the email, select "Send", "Save as draft", or "Discard".
- The reply tab contains "Reply", "Reply all" and "Forward" options.

**Delete message:**

- Go to how to display messages.
- Touch & hold the message you want to delete.
- Select "Delete".

### Connecting to E-mails

**Log into your e-mail accounts.**

You may login to your e-mail accounts from the phone to access your e-mail.

From the Home screen, select Application "Email, Go" and then Enter your email address, password and tap "Next". Select which type of email account you are setting up and enter the proper settings. (POP3 / IMAP / Microsoft Exchange Accounts).

You will need to enter your user name, password, and server information depending on the type of email account or you can change the settings by tapping "Manual setup", at the top right corner screen. Tap "Next" and select "OK" to accept.

**Compose new:**

- Press MENU & select "Compose".
- Add recipients by typing a name or email address in the "to" field. Matching contacts will appear. Select a recipient or continue typing in the email address to send to multiple contacts.
- Once finished typing the email, select "Send", "Save as draft", or "Discard".
- The reply tab contains "Reply", "Reply all" and "Forward" options.

**Delete message:**

- Go to how to display messages.
- Touch & hold the message you want to delete.
- Select "Delete".

### File Transfer

**Connecting Smartphone to PC**

Connect the USB cable to your smartphone and computer. Once connected successfully, on your phone slide the top menu down and click on "Android System" > then, press "Transfer files" button.

A new storage named astro A63 will appear on your PC file "My Computer". Click on it to review files in the smartphone and for to transfer documents between devices. When finished, press Disconnect device from PC.

Note: Photos taken with the camera will be saved under the "DCIM" folder. Screenshots captured will be saved under "Pictures" folder. Full music files in the "Music" folder for the files to played properly.

**Screen Capture**

Press volume and power button at the same time to capture "Screenshot". All captured screenshot will be saved under gallery.

### Warning

■ Any changes or modifications not expressly approved by this party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC Rules and Industry Canada license-exempt RSS (domestic).

[1] This device may not cause interference

[2] This device must accept any interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

■ FAR tests are conducted using standard operating conditions accepted by the FCC/ISED, with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level. The actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

■ Before a new device is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the exposure limit established by the FCC/ISED. Tests for each device are performed in positions and locations as required by the FCC/ISED.

■ For body worn operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory that is designed for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 5 mm from the body.

■ Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Power: 3.7V

Le fabricant/distributeur de 5130-5230-3035 est une entreprise canadienne.