

User Manual

Overview



SIM Card Installation

Back key (): Touch to go back to the previous menu.

Warning:

- Do not remove the battery while the device is charging.
- Use only the AC adapter & USB cable provided with your device.

Note: For safety, the battery will stop charging if in danger of overheating.

Audio Profile/Sleep Mode

1. On the home screen, touch the "APP Menu" & select "Settings".
2. Select "Security and location" then select "Screen lock".
3. Select the desired type of lock & follow the prompts to set up.

Phone Features

1. **Clock**
Allow you to set the Alarm from Clock.
2. **Browser**
Browse the internet. Search engine- default set as Google.
3. **Calculator**
Allow you to do tedious calculations quickly.
4. **Calendar**
View the calendar & add events.
5. **Camera**
Allow you to click pictures among you want. Your Nitro 55 High Definition camera with LED Flash supporting many social media like Facebook which ensures you to take good photos and stores them in the Gallery. In Camera, easily choose to record Video.
6. **Contact**
To see your list of Contacts. Access your digital phonebook function.
7. **Email**
Allows you to set your POP/IMAP email accounts.


Phone Features

12. **Phone**
Allow you to make phone calls.
13. **File Manager**
You could browse, view, modify and install your files.
14. **MAX SIM KIT**
This service is provided by the operator. It provides phone plan information.
15. **Sound Recorder**
Allows you to record sounds.
16. **Videos**
View from list of videos.

Phone calls/Texting

© 2020 Maxwest and the Maxwest Logo are registered trademarks Google, Android, Google Play, Gmail and other marks are trademarks of Google LLC. The Android robot is reproduced or modified from work created and shared by Google and used according to terms described in the Creative Commons 3.0 Attribution Licence.

WLAN



Connecting to E-mails

1. Go to Inbox to display messages.
2. Touch & hold the message you want to delete.
3. Select "Delete".

File Transfer

Warning

- SAR tests are conducted using standard operating positions accepted by the FCC/ISED with the device transmitting at its maximum power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the FCC/ISED limits. The SAR level of a mobile phone is not a wireless base station antenna, the lower the power output.
- Before a new device is available for sale to the public, it must be tested and certified to the FCC/ISED that it does not exceed the FCC/ISED SAR limits. The SAR testing is done in a laboratory and is performed in positions and locations as required by the FCC/ISED.
- For body worn exposure, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory designed for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 15 cm from the body.
- Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Avertissement

Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler l'approbation de l'appareil à utiliser l'émission. Cet appareil est conforme à la réglementation de la Commission canadienne des télécommunications de l'industrie Canada. Son utilisation est soumise aux deux conditions suivantes:

- (1) Il ne doit pas causer d'interférences.
- (2) Il ne doit accepter toutes les interférences, y compris celles qui pourraient provoquer un fonctionnement non souhaité de l'appareil.

Remarque: cet équipement a été testé et déclaré conforme aux limites imposées aux appareils numériques de classe B, conformément à la réglementation de la Commission canadienne des télécommunications, pour une protection raisonnable contre les interférences nuisibles dans une installation résidentielle. Cet équipement génère, utilise et peut émettre des ondes électromagnétiques susceptibles d'interférer avec les appareils électroniques. Suivez les instructions, pour causer des interférences nuisibles aux communications radio. Cependant, rien ne garantit que de telles interférences se produiront pas dans une installation particulière. Si cet équipement provoque des interférences nuisibles à la réception de la télévision réception de, ce qui peut être déterminé en éteignant et en rallumant l'équipement, l'utilisateur est invité à tenter de corriger les interférences en prenant l'une des mesures suivantes:

- Réorienter ou déplacer l'antenne réception.
- Augmenter la séparation entre l'équipement et le récepteur.
- Débrancher l'équipement de la prise d'un circuit différent de celui auquel le récepteur est connecté.
- Consulter le revendeur ou un technicien expérimenté en radio / télévision pertinent de l'installation.

Les tests SAR sont effectués à l'aide de positions de fonctionnement simulées pour la FCC / ISDEC, l'appareil transmet à un niveau de puissance certifié le plus élevé dans toutes les bandes de fréquences testées, bien que le SAR soit déterminé au niveau de la puissance certifiée. Les tests SAR sont effectués conformément à une procédure inférieure à la valeur maximale. En général, plus vous êtes proche d'une antenne de station de base sans fil, plus la puissance émise est faible.

Avant qu'un nouveau dispositif ne soit disponible à la vente au public, il doit être testé et certifié par la FCC / ISDEC. Des tests ne dépassent pas la limite d'exposition fixée par la FCC / ISDEC. Des tests sont effectués pour chaque disposition dans des requêtes par la FCC / ISDEC.

Ne touchez pas aux réglages du SAR. Les utilisateurs doivent respecter les directives de l'organisme RF de la FCC / ISDEC lorsqu'il est utilisé avec un accessoire conçu pour cet produit ou avec un accessoire ne contenant pas de métal et positionné le dessus à moins de 10 mm. corps.

La non-respect des restrictions ci-dessus peut entraîner une violation de la réglementation de la FCC / ISDEC.