



NITRO N62 User Manual

Overview



- 1 Front Camera
- 2 Volume Keys
- 3 Power Key
- 4 Menu
- 5 Home
- 6 Back
- 7 Rear Camera
- 8 Flash

SIM Card Installation

A SIM card contains your phone number and other necessary data. Your device has SIM slot that supports 4G (LTE).

To Install the SIM Card

1. Make sure the device is turned off and the front facing down. Hold the flange and use the notch at the bottom corner to loosen the cover. Use material with a hard, thin edge such as your fingernail or a credit card to carefully run along the seam to loosen, then lift the cover until it detaches completely.



2. Remove the battery if it is in. Locate the SIM card slot and insert the proper SIM card into the proper slot. For more information on SIM card installation check out the included SIM Card & Micro SD Card Installation Guide.

3. To turn on/off a SIM card go to Settings > SIM management, then slide the SIM card sliders. To turn on/off a SIM card's data connection, go to Settings > SIM management, click on the "Data connection" option, and select a SIM card that has 4G capability.

Keys/Touch Points

Power Key: To power on/off it, press and hold power key for a few seconds. When it is ON, press the power key once to activate or deactivate the screen.

Home key [O]: Touch the key to return to the home screen. In side screen, touch and hold the key to view recently opened apps.

Options key [□]: In home screen, touch the key to set wallpaper, manage apps, and to access system settings. Touch it to view menu options.

Back key [◀]: Touch to go back to the previous menu.

Charging battery


New batteries are shipped partially charged. Before using your device, install and charge the battery. Batteries perform best after several full charge / discharge cycles.

Charging Your battery

Please charge the battery using the following methods:

1. Charge the phone by connecting it to a computer via the USB cable.
2. Connect the USB cable to the phone and the AC adapter. Plug the AC adapter into an electrical outlet to start charging.

As the battery charges, an icon will appear in the status bar of the home screen. When the battery is fully charged, a full battery icon appears on screen.



Warning:

- Do not remove the battery while the device is charging.
 - Use only the AC adapter & USB cable provided with your device.
- Note: For safety, the battery will stop charging if in danger of overheating.

Audio Profile/Sleep Mode

Intelligent keyboard

From the home screen, swipe up to open APP Drawer & select "Settings". Go to "Sound" and change the audio settings by changing sound levels and change your ring tones.



Sleep Mode

Turn on sleep mode to save your battery power.

1. On the home screen, touch "APP Menu" & select "Settings".
2. Select "Display".
3. Select "Sleep" and choose a time interval from the list.

Screen Lock

1. On the home screen, touch the "APP Menu" & select "Settings".
2. Select "Security and location" then select "Screen lock".
3. Select the desired type of lock & follow the prompts to set up.

Phone Features

Description Icons

Icons	Descriptions	Icons	Descriptions
	Shows the phone's network signal strength.		Shows the phone's battery capacity.
	Speaker has been activated.		You have unread SMS.
	Call on hold.		USB storage Turned on.
	The ringing type is set on vibration.		Night Mode.
	4G network in use.		3G network in use.
	You have missed calls.		A clock alarm is active.
	In-call.		Bluetooth ON.

Main Menu & Its Functions


Select to enter the main menu.

Allow you to view a list of features available in your phone.

1. Clock Allow you to set the Alarm from Clock.
2. Browser Browse the internet. Search engine, default set as Google.
3. Calculator Allow you to make tedious calculations quickly.
4. Calendar View the calendar & add events.
5. Camera Allow you to click pictures anytime you want. Your NITRO N62 has a 10.0 MP High Definition camera with LED Flash supporting many special features like Face Detection which ensures you to take good quality of pictures and stores them in the Gallery. In Camera, easily choose Camcorder to record Video.
6. Contact To see your list of Contacts. Access your digital phonebook through this function.
7. Email Allows you set up your POP/IMAP email accounts.

Phone Features

8. Gallery Gallery is a light, fast and easy to use photo gallery.
 9. Google Play Google Play is your entertainment rebound. It brings together all of the entertainment you love and helps you explore it in new ways, anytime, anywhere.
- Note:
To use this app please connect to an internet connection.
10. Messaging Allow you to view messages sent & received as a thread.
 11. YouTube Music The music streaming app. Made by YouTube. Discover all the music on YouTube that you can't find anywhere else, organized in one new app and web player.



12. Phone Allow you to make phone calls.
13. File Manager You could browse, view, modify and install your files.
14. MAX SIMKIT This service is provided by the operator. It provides phone plan information.
15. Sound Recorder Allows you to record sounds.
16. Videos View from list of videos.



NITRO N62

Android, Google Play, YouTube and other marks are trademarks of Google LLC.

Phone calls/Texting


To Make Phone Calls

1. Touch the phone icon.
2. Click on a contact from your contact list to make a call.



Composing text messages

Maxwest automatically corrects and suggests words as you type.



Cut, Copy and Paste

Touch and hold text content to bring up the magnifying glass, and then slide your finger to move the insertion points. Then choose to cut, copy, or paste. It is very easy to copy text from web pages, email, or text messages.

WLAN


Turn on WLAN

Maxwest supports WLAN Direct which allows Android™ 12 (or earlier) or later devices with the appropriate hardware to connect directly to each other via WiFi without an intermediate access point. Using the APs, you can discover and connect to other devices, if each device supports WiFi Direct, then communicate over a speedy connection across distances much larger than a Bluetooth connection. This is useful for applications that share data among users, such as a multiplayer game or file sharing.



- a. Enter "Settings" >> Click "NETWORKS & internet" >> Select "WiFi" >> Select "WiFi Preference" >> Select "Advanced" >> Then click "WiFi Direct" to access WiFi Direct feature.
- b. After click "Search" at the bottom and it will display the available devices.
- c. Click "DIRECT 75-HP M252 Low Latency" (in this case specifically) and it will give you option to connect.
- d. Click "Connect" to connect and it will pop up an interface to confirm like below.


Camera



e. Click "OK" and the devices will be connected

Camera

Capture images or record videos and share with family and friends!



- Take Picture
- Picture Review
- Switch to front/rear camera
- Video Mode

Connecting to E-mails

Log into your e-mail accounts.

You may log in to your e-mail accounts from the phone to access your e-mails. From the Home screen select Application "Email Go" and then enter your email address, password and tap "Next". Select which type of email account you are setting up and enter the proper settings. (POP3 / IMAP / Microsoft Exchange Account). You will need to enter your user name, password, and server information depending on the type of email account or you can change the settings by tapping "Manual Setup" at the top right corner screen. Tap "Next" and select "OK" to accept.

Compose new:

1. Press MENU & select "Compose".
2. Add recipients by typing a name or email address in the "To" field. Matching contacts will appear. Select a recipient or continue typing in the email address to send to multiple contacts.
3. Once finished typing the mail, select "Send", "Save as draft", or "Discard".
4. The reply tab contains "Reply", "Reply all" and "Forward" options.



Delete message:

1. Go to Inbox to display messages.
2. Touch & hold the message you want to delete.
3. Select "Delete".

File Transfer

Connecting Smartphone to PC

Connect the USB cable to your smartphone and computer. Once connected successfully, on your phone, slide the top menu down and click on "Android System", then, press "Transfer Files" button. A new storage named nitro N62 will appear on your PC file "My Computer", click on it to review files in the smartphone and/or to transfer documents between devices. When finished, press "Disconnected device from PC". Note: Photos taken with the camera will be saved under "Pictures" folder, but music files in the "music" folder for the files to be played properly.



Screen Capture

Press VolumeUp and power button at the same time to capture "Screenshot". All captured screens will be saved under gallery.



Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with part 15 of the FCC/ISED/IC Rules and Industry Canada license-exempt RSS (Canadian). Operation is subject to the following two conditions:

- (1) This device may not cause interference
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC/ISED/IC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

EMF/ELF tests are conducted using standard operating conditions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

Before a new device is available for sale to the public, it must be tested and certified to the FCC/ISED, that it does not exceed the exposure limit established by the FCC/ISED. Tests for each device are performed in positions and locations as required by the FCC/ISED.

For body worn operation, this device has been tested and meets the FCC/ISED RF exposure guidelines when used with an accessory designated for this product or when used with an accessory that contains no metal and that positions the handset a minimum of 50 mm from the body.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.

Hearing-Aid Compatibility HAC Statement

Your phone is compliant with the FCC Hearing Aid Compatibility requirements.

The FCC has adapted HAC rules for digital wireless phones. These rules require certain phones to be tested and rated under the American National Standard Institute (ANSI) C63.19-2011 hearing aid compatibility standards. The ANSI standard for hearing aid compatibility contains two types of ratings:

- M-Ratings: Rating for less radio frequency interference to enable acoustic coupling with hearing aids.
- T-Ratings: Rating for inductive coupling with hearing aids in telecoil mode.

Not all phones have been rated. A phone is considered hearing aid compatible under FCC rules if it is rated M3 or M4 for acoustic coupling and T3 or T4 for inductive coupling. These ratings are given on a scale from one to four, where four is the most compatible.

The tested M-Rating and T-Rating for this device is M4 and T3.