


# U Buds manual 20190429




**U Buds**  
Your life. Your sound.  
User Manual

**Welcome!**  
Thank you for choosing our U Buds. Get ready to experience superior sound! Please read this manual carefully before use.


**Features**

- Auto power on/off and pair
- Cool free fit with flexible wearing options
- U Buds case provides instant charge
- Ultra-light experience with winglets for secure fit
- High quality stereo sound
- Noise reduction for better call clarity
- Can be used as two individual headsets
- Voice assistant activation

**Overview**




**What's Included**



**Charging The U Buds Case**

The U Buds come with a portable charging case that includes a built-in rechargeable battery.


To charge the case, connect the micro-USB cable to the micro-USB port on the back of the U Buds case, and the standard USB connector to a USB power source such as a computer or 5V USB adapter (not included). The charging indicator lights up when the case is charging. When charging is complete, the lights will turn off. On a full charge, the case will provide an extra 3-4 full charges.




**Charging The U Buds**

Place the U Buds inside their carrying case and they will begin to charge automatically. The charging indicators will light up when the ear buds are charging and turn off when the charge is complete.

Please note: The left LED indicator indicates the charging state of the left U Bud and the right LED indicator indicates the charging state of the right U Bud. Additionally, the LED indicators on the U Buds case will flash slowly when the battery level of the U Buds case is low.



**How to Wear**



Place the winglet into your ear and push it in gently. Adjust the winglet to make sure it fits up with your ear canal and feels secure in your ear.

The U Buds come with 3 ear tips of different size options and 2 second-fit winglets that are easily interchangeable for optimum performance.

**How to Pair**

The U Buds can work separately as single headsets (mono mode) or can be used together as a pair of stereo ear buds (stereo mode).

1. Begin with both U Buds powered off (in the case) and fully charged.
2. The U Buds will power on and pair with each other automatically when taken out of their case.
3. Place the U Buds in your ears and you will hear voice prompts in the following order: "Power On", "Stereo", "Connected", "Left Channel" for the left U Bud and "Right Channel" for the right U Bud.
4. Enable your smartphone's Bluetooth function and select "U Buds" on your mobile device to connect the U Buds to your smartphone. You will hear a voice prompt that says, "second device connected".

**NOTE 1:** Your U Buds must be paired to each other before they can pair to your mobile device.  
**NOTE 2:** Short temporary cut-outs between the U Buds connection may happen occasionally. This is normal for wireless ear buds. However, if the connection cuts out repeatedly, please try to stay away from nearby radio or Wi-Fi interference.

**Power On/Off Directly From The U Buds**

The U Buds will power off automatically when placed inside of their carrying case and power on automatically when they are taken out.

To manually turn the U Buds on/off, follow these steps:  
To power the U Buds on, press and hold the multifunction button on BOTH U Buds for about 3 seconds. To power the U Buds off, press and hold the multifunction button on EITHER ONE of the U Buds for about 4 seconds.

**More Headset Mode**

1. Select one U Bud to pair with your smartphone.
2. Take the U Bud out of the case and wear it. It will power on automatically. You will hear the earbud announce "Pairing".
3. Enable your smartphone's Bluetooth pairing function and select "U Buds" in the Bluetooth device list to pair.
4. Once the earbud is successfully paired, you will hear voice prompt announces "connected".

**NOTE:** It may be necessary to turn the second earbud off by holding the multifunction button for about 4 seconds if you choose to use only one U Bud in mono headset mode.

**Left U Bud - Button operations**

Power On	Press & hold the multifunction button for 3 seconds
Power Off	Press & hold the multifunction button for 4 seconds
Volume Up	Press the multifunction button twice in 1 second
Volume Down	Press the multifunction button 3 times in 1 second
Call Answer	Press the multifunction button once
Call Reject	Press the multifunction button 2 times in 1 second
Call Transfer	Press the multifunction button 3 times in 1 second
Call Hold	Press the multifunction button 4 times in 1 second
Call End	Press the multifunction button 5 times in 1 second

**Activate Voice Assistant**

Some mobile devices have voice assistant feature. Your U Buds may activate voice assistant on your mobile device. To activate, make sure the U Bud is paired. Then press and hold the multifunction button for 1 second and release. The U Buds will activate voice assistant.

**Auto Power Off**

U Buds will automatically power off if they are not connected for 10 minutes.

**LED Indicators**

Indicator	Indication
Stereo Pairing	Blue light on left bud and right bud blink
Pair with Bluetooth device	Blue light on left bud and right bud blink on the case
No connection	Red light flashes 4 times
Charging U Buds	Front charging indicators light up
U Buds case low battery	Red light on the case flash 4 times
Charging U Buds case	Back charging indicator lights up

\* Please note that the positions of the LED indicators on the two U Buds are located differently. Please check Overview on page 2.

**Specifications**

Model	U Buds
Wireless connection	Bluetooth 4.2
Max transmission distance	100m (328ft)
Supported profiles	A2DP, HFP, HSP
Talk time	3-6hrs
Music time	2-3hrs
Input voltage	Charged by DC 5V USB
Micro-USB	BuBn Lockmaster battery
Battery	BuBn Lockmaster battery
Size	7*11*11 (Earbud), 20*42*14 (Charging case)

**Maintenance**

- Keep this product away from heat and humidity.
- Do not put this product under direct sunlight or hot areas. High temperatures will shorten lifespan of the product.
- Change this product if it is not used for more than 2 weeks.
- To avoid risk of electrical shock, do not disassemble the product at any time.
- Do not dip or knock this product on hard surfaces.
- Do not use chemicals or detergents to clean the product.
- Do not expose this product to rain or liquid.


**Cautions**

- To avoid accidental ingestion, keep the earbuds away from small children and pets. The earbuds contain a lithium battery, and may be hazardous if swallowed. When not in use, store the earbuds in the charging case with the lid closed.
- Use caution and follow applicable laws regarding mobile phone and headphone use. If using the earbuds for phone calls while driving.
- Do NOT use the earbuds at a high volume for any extended period.
- Focus on your safety and that of others if you use the earbuds while engaging in any activity requiring your attention, e.g., while riding a bicycle or walking in or near traffic.

**Troubleshooting**

- Earbuds don't power on → Place the earbuds in the charging case to initiate charging.
- Earbuds are not paired after taking out from the charging case. Place the earbuds back in the case and take them out to try again. If the sound is not as expected, please check the volume on your mobile device and make sure it is not muted.
- Earbuds don't connect with mobile device. Move your mobile device closer to the earbuds and away from any interference or obstructions.
- Charging case doesn't charge the earbuds → Make sure the earbuds are properly closed in the charging case.
- The charging case maybe out of battery. Please charge the case.
- Earbuds powered on themselves inside the case. Happens when the battery of the charging case died causing the current mode to stop and triggered the earbuds to power on. Please charge the charging case.


**IPX4 Water resistance rating**



The U Buds are protected from water splashes, no matter the direction.

**NOTE 1:** Don't expose to water jets or sink in water.  
**NOTE 2:** IPX4 is not a permanent condition and resistance might decrease as a result of normal wear.

**Security Wearing Positioning Option: Find Your Best Fit**



Option 1: No security wings attached  
Option 2  
Option 3  
Option 4

**FCC STATEMENT**

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. (1) This device may not cause harmful interference, and (2) the device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

**FCC Radiation Exposure Statement:**

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

FCC ID: 2A0512L-701