## **USER MANUAL**

GX-201

- Do not open the housing under any circumstances. Do not introduce any objects into the interior of the housing.
- Do not cover the ventilation openings of the appliance.
- Plug the appliance into an easily accessible socket, so that you can disconnect it

quickly from the mains, in the event of an emergency. Unplug the appliance from the power socket to switch it off completely. Use the mains plug as a disconnecting appliance. Always switch the appliance to OFF before unplugging it.


If the appliance malfunctions due to electrostatic discharge or short-term

- overvoltage, disconnect it from the power supply and connect it once again.
- · Unplug the appliance during lightning storms or when unused for a long period.

#### PARTS

Lighting BT Speaker X 1 Mini Stand X 3 Handle x 1 USB Cable X 1 User Manual X 1

- Power ON/OFF Button
- Previous / Volume down button
- Next / Volume up button 3. Play/Pause button
- Lighting button
- 6. TWS button
- Bluetooth button
- 8. DC 5V charging port 9. 3.5mm line-in port
- 10.Mini Stand
- 11.Handle



attention to the Safety section.

Dear Customer,

FCC Warning Statement Changes or modifications not expressly approved by the party responsible forcompliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful are designed to provide reasonable protection against narmul interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: the interference by one or more of the following measures: Reorient or relocate the receiving antenna.

Thank you for choosing the Lighting Bluetooth Speaker. For correct operation and maintenance of this appliance, please read this User Manual carefully. Please pay

Consult the dealer or an experienced radio/TV technician for help.

Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

## BEFORE FIRST USE

- Unpack the appliance and check if all parts are there and undamaged.
- Danger of suffocation! Keep all packaging materials away from children. Dispose of the packaging materials properly. Inform yourself at the local authorities regarding collection points or garbage separation.

  Remove all protective foils and packaging material prior to use.

#### **BATTERY CHARGING**

- The unit has a built-in rechargeable battery, recharge it as below. Connect the Micro USB plug the Micro USB port on the bottom of the unit
- Connect the USB plug to a USB port of computer or USB wall charger with DC 5V, 1A output.
- During charging, the red indicator on the top of unit will illuminate. When charging finish, it will turn off.

## **GENERAL OPERATION**

- Power on the unit by Long press Power ON/OFF button
  Press once the "+" or" "button to adjust volume level.
  Press and hold the " +" or" "button to go to previous or next song
  Press once the " ⊃ "to play/pause music
  Press once " \*" "to yellow color lighting
  Press and hold" \* "to RGB lighting
  Press once" ® "to TWS function
  Press once" \$ "to Bluetooth

### **BLUETOOTH OPERATION**

The first time you use the unit or pair it to a new Bluetooth device, please follow this instruction

Pairing a Bluetooth Device for the first time

- Power on the unit pressing Power button
   The unit will enter to Bluetooth mode automatically and blue light flash slowly.
- Search the Bluetooth speaker on your Bluetooth device, select "GX-201" to pair
- When successfully paired and connected, there are signal sound and blue light will

Push Bluetooth button when Bluetooth paired will become blue light flash slowly and disconnect current pairing, so allow pair to other cell phone or other device.

NOTE: Should your device become unpaired or you are not able to connect it, repeat the above steps.

#### LIGHTING OPERATION

- Power on the unit pressing Power button Short press the light button will be the yellow color for lighting; It will be middle brightness light, the most brightness light, small brightness light and circular breathing light.
- breatining nym.
  Long press lighting button will be in RGB color for lighting. Once long press lighting button, it will be one color exchange, there will be 7 colors and last long press will be 7 colors circular breathing light.

## **AUX OPERATION**

- Plug in the 3.5mm mini jack to replace Bluetooth mode to AUX mode to play back music. It will be AUX mode as long as min jack plug in
- Must plug out the mini jack to back to Bluetooth mode.

#### TWS OPERATION

- Two speakers must be same model ( same Bluetooth device name ) and MUST connect TWS successfully before pair to Bluetooth.
- 2. If Two speakers are same model, you can easily to pair for 2 speakers play as,
- Turn on both two speakers and Bluetooth light will flash quickly (do not pair to cell phone first )
- Press any one speaker of TWS button, both of Bluetooth light flash quickly then Bluetooth light will become flash slowly (as main speaker) and another speaker Bluetooth light will on still (as companion speaker), means two speaker ("TWS") connected successfully. When it TWS mode, the way of show the lighting and music are all synchronized for both speakers.

# TECHNICAL DATA

Power: 5W RMS Built-in Lithium battery: 3.7V/2200mAh Input: DC 5V 1A by Micro USB port Bluetooth Version: V 4.2 AUX IN: 3.5mm line-in Working Distant: Approx. 10m

Caution: Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like