



Appendix II

Internal Photographs

MODEL NUMBER: S11US0A00




Open View of EUT




Internal View of EUT-1

Internal View of EUT-2




Internal View of EUT-3






Internal View of EUT-4



Internal View of EUT-5






Internal View of EUT-6




Internal View of EUT-7







Internal View of EUT-8



Internal View of EUT-9



Internal View of EUT-10



Internal View of EUT-11






Internal View of EUT-12




Internal View of EUT-13





Internal View of EUT-14



Internal View of EUT-15




Internal View of EUT-16



Internal View of EUT-17



Internal View of EUT-18



Antenna location and RF Module location

