

## USER MANUAL


T15

TRUE WIRELESS STEREO EARBUDS


**Dear Valued Customer**

Thanks for choosing this product!  
In order to make full use of this item and avoid misuse, please read the manual carefully before using it.


**What's in the Box**




Charging case \*1 piece



TWS earbuds \*1 pair




Manual \*1 piece



Type-C charging cable \*1 piece


( The above pictures of accessories are for reference only )

**Structure of T15**



**Instruction for wearing**

Wearing earbuds and adjust the right angle as the picture shows. It's OK when we feel comfortable and stable.



Closer microphone makes a crystal clear phone calls


**Power on**

Open the charging case, the earbuds will power on automatically and re-connect to the phone that has been connected before.

**Connecting Bluetooth of mobile phone**

The first step: The earbuds in the pairing mode  
Method 1: For first use, open the charging case, the earbuds will power on automatically and enter the pairing mode.

Method 2: When earbuds in charging case, long press the multi-function button of charging case for 3 seconds until its nearby indicator flashes white slowly, the earbuds go to pairing mode.(a. during pairing mode, please keep the charging case open until pairing successfully;b. the charging case white light will be off after 10 seconds, but it will not affect pairing).  
The second step: phone searching and connecting  
Turn on Bluetooth function of phone to search T15 and then connect. It will show connected successfully.



**Notice:**

- After earbuds are connected with mobile phone, when you open charging case, earbuds will connect to the last connected mobile phone automatically. If the last connected mobile phone is out of connection range or Bluetooth function is not on, earbuds will get into searching status.

- The pairing mode lasts 10 minutes at most. Earbuds will power off automatically if they are not connected with any bluetooth-enabled device during this period. If need to be connected again, please operate as "Power on" and "Connecting bluetooth of mobile phone" steps.
- If out of the bluetooth range, earbuds will disconnect with Bluetooth-enabled device and will re-connect if back to the right distance within 10 minutes.

**Power off**

Method 1: Put the earbuds into the charging case, and close the upper lid, the earbuds will be powered off automatically after 3 seconds(But if the charging case runs out of power, earbuds will fail to turn off and you need to recharge promptly);  
Method 2: Earbuds will turn off when they run out of power.

Method 3: Earbuds will power off automatically if they are not connected with any bluetooth-enabled device within 10 minutes.

**Siri Function**

Triple click will activate Siri function and exit with same operation. (this function is limited to IOS system)

**Answering a Call**

Double click either earbuds at touching area

**Ending a Call**

Double click either earbuds at touching area

**Rejecting a Call**

Keep touching either earbuds for 2S

**Switching Phone Call between Earbuds and Mobile Phone**

Keep touching either earbuds for 2S

**Music Playing**

Play/Pause: Double click either earbuds at touching area  
Previous track: Keep touching the left earbud for 2S  
Next track: Keep touching the right earbud for 2S

**Notice:**

- If a phone call comes during music play, the earbuds will play music automatically after the call ends.
- Music will pause if using Siri , and will re-play music automatically after exit Siri.
- If using only one earbud, the earbud can go next track only, cannot go previous track by this operation.

**Master-Slave Switch**

Take out either earbud from the charging case, it can connect with Bluetooth-enabled device and be used as a wireless earbud independently. And the other can be paired with it quickly anytime when taking out of the charging case.  
When the master earbud runs out of the power, or place the master into the charging case, the slave will switch to the master automatically and keep working.

**Charging the Charging Case**


When earbuds is not fully charged, put earbuds into charging case and it will charge automatically. The

charging case indicator will be orange. When fully charged, the indicator will be green, and it will be off after 10 seconds without any operation.  
When charging case is full of power, taking out earbuds or putting earbuds into charging case, the indicator flashes green once. When charging case with low battery, taking out earbuds or putting earbuds into charging case, the indicator will flash orange once.  
When earbuds are not in charging case, the indicator will show charging case battery status when opening upper cover. 50%-100%, green light for 10 seconds. 10%-50%, orange light for 10 seconds.<10%, orange light flashes for 10 seconds.  
When earbuds are recharging, short press charging case button, the indicator will show charging case battery level. 50%-100%: green light for 10 seconds. 10%-50%: orange light for 10 seconds.<10%, orange light flashes for 10 seconds.  
Plug in suitable power supply for charging case, the indicator will be solid orange. And it will be solid green when fully charged.

50%-100%  
green light for 10 seconds

10%-50%  
orange light for 10 seconds

<10%  
orange light flashes for 10 seconds



**Product Specification**

Model #:	T15
Dimensions:	16.56*41.77*17.49mm (earbuds) 73*39.19*27mm (charging case)
Bluetooth version:	V5.0
Transmission distance:	15 meter
Input Voltage:	DC 5V/1A
Battery capacity:	3.7V/35mAh (earbuds) 3.7V/500mAh (charging case)
Working time:	4H
Charging time:	2.5H
Waterproof level:	IPX5

**Factory Resetting**

Step 1. Put earbuds into charging case and keep the case open.  
Step 2. Press and hold charging case button for 10 seconds until the indicator flashes green for 5 times, factory resetting is finished. All the pairing history will be cleared off.

**Safety Notifications**

- Please use the products according to user manual. And please do not disassemble or modify the device for any reason. Or the earbuds may breakdown or burn.
- Do not drop the product to any liquid or wash it.
- Do not charge the earbuds with charger which is over-voltage. Use the charger with rated voltage and current of 5V/1A. Or it will damage the battery.
- Do not use or store the earbuds in an environment where the temperature is too high or too low (Below 0 degrees or above 45 degrees)
- Do not block the earbuds, such as charging interface, LED indicator or microphone.
- Do not use the earbuds overtime and over-volume. This may make you dizzy or be harmful to your hearing.
- Do not use the equipment under thunderstorm environment. Thunderstorm may cause abnormal operation of the equipment, signal interruption, etc.

**FQAs:**

Entry	Handling method
Match two unpaired earbuds?	Put two earbuds into the same charging case, click charging case button 3 times until the indicator flashes white for 5 seconds, the two are paired successfully.
Connect earbuds to other mobile phone?	Put earbuds into charging case, long press charging case button for 3 seconds, the indicator will flash white for 10 seconds, then the earbuds go to pairing mode, capable of connecting with other phone.
The earbuds has no any action or shut down.	Put earbuds into charging case and close charging case for 10 seconds. Re-open charging case and earbuds can work properly.
Distinguish master and slave.	The device supports master-slave switching. The first earbud which turn on will be the master.

THANK YOU!

## FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.