Chinese Version

NOBLE

www.nobleaudio.com

⊠ 图 210-241709

Noble FoKus Rex5
真无线立体声耳机
使用说明书

105mm

包装清单

充电盒 x1   耳机   USB充电线 x1

耳套 x10   说明书 x1   收纳袋 x1

01

外观图示

多功能传感器(FMS)
麦克风
复位键
麦克风
LED 指示灯
LED 指示灯
LED 指示灯
USB Type C 充电接口

02

充电

❗ 说明：首次使用前请确保耳机和充电盒已充满电。
充电前和充电过程中，耳机和充电盒需要保持干净和干燥。

充电步骤：
1.耳机放回充电盒且关闭充电盒时会自动关机。
打开或关闭充电盒盖子时，LED指示灯会显示电量状态。
2.插入USB Type C 充电线，将充电盒与电源连接。

⚡ 充电中：白灯慢闪
○ 充满电：白灯常亮

03

开机 / 关机

打开充电盒时，耳机会自动开机。
将耳机放回充电盒并合上盒盖，耳机将自动关机。

ON   OFF

⚡ 在充电：白灯闪烁
○ 充满电：白灯常亮

• 要手动打开开机，请长按MFS按钮3秒钟。
• 要手动关闭耳机，请长按MFS按钮5秒钟。
两侧耳机都会自动断电。

04

佩戴

1.选择适合您耳道的耳塞尺寸，然后将其推到耳机顶端。
2.将耳机插入耳道并调整至舒适的位置，确保耳塞密贴合。

05

配对/取消配对程序

使用前，Noble FoKus Rex5 需要与您的设备配对。配对后，每次激活它们都会自动连接。

配对
1.打开充电盒盖子，耳机将自动开机并进入配对模式。红白指示灯交替闪烁。
2.在智能手机上启用蓝牙并在可用的蓝牙设备中搜索"Noble FoKus Rex5"。找到后，选择"Noble FoKus Rex5"开始配对，你会听到"连接成功的提示音"，耳机就可以使用了。

配对新设备
1.打开充电盒盖子，耳机将自动开机并连接到您当前的设备。
2.通过从智能手机的蓝牙设备列表中"断开连接"或删除"Noble FoKus Rex5"来取消与当前连接的智能手机的配对。
3.断开连接后，耳机将自动进入配对模式，红白指示灯交替闪烁。
4.在新设备上启用蓝牙，并在可用的蓝牙设备中搜索"Noble FoKus Rex5"。找到后，选择"Noble FoKus Rex5"开始配对。你会听到"连接成功的提示音"，耳机就可以使用了。

06

控制

⏯	播放/暂停	单击 MFS(L/R)
🔊	提高音量+	三击 MFS(L)
🔉	音量减小-	双击 MFS(L)
⏮	上一曲	三击 MFS(R)
⏭	下一曲	双击 MFS(R)
📞	接听/挂断电话	单击 MFS(L/R)
📞	拒接来电	长按 MFS 2秒 (L/R)
🎤	语音助手功能- Siri / Google	长按 MFS 2秒 (R)
🎚	降噪模式	长按 MFS 2秒 (L)

07

LED指示灯

使用场景	LED指示灯状态
开机	白色灯闪一秒
关机	红色灯闪一秒
配对	红白交替闪烁
配对成功	白灯亮2秒
接听音乐或通话	LED 灯关闭 或 灯关闭
耳机电量低	红色灯每5秒闪烁两次
将耳机放入充电盒中	红色灯常亮
耳机放入充电盒满电后	红色灯关闭
充电盒充电中	白色灯慢闪
充电盒满电后	白色灯常亮

• 单声道模式：蓝牙成功连接后，只要把任意一只耳机放回充电盒并合上盖子，另一只耳机将独立工作。
• 开机并连接后，如果任一只耳机电量耗尽并关机，另一只耳机可继续使用。
• 超距离范围：当耳机超出手机连接范围时，3分钟内智能有效距离自动回连手机；若超时3分钟未回连接，耳机将自动关机。

08

模式切换   在待机模式或播放音乐时

开启降噪模式	长按 2 秒
长按左耳塞触摸传感器2秒钟，听到降噪开的提示音，将进给外界噪音。

开启通透模式	长按 2 秒
长按左耳塞触摸传感器2秒钟，听到通透模式的提示音

返回普通模式	长按 2 秒
长按左耳塞触摸传感器2秒钟，听到普通模式的提示音

现在共三，这里"降噪开"、"通透开"和"普通模式"循环。长按左耳塞2秒

长按2秒

09

重置程序

*如果耳机无法相互配对或者无法与其他设备配对，请重置耳机。

1.将耳机放回充电内
2.按下复位按钮10秒，直到两个耳机上的红白灯同时闪烁3次，重置完成。所有先前配对的设备都将被清除。
如果不小心只重置了一个只耳机，到需要重置两只耳机才能再次作为一对耳机使用。

声明和警告
在配对新设备之前请断开当前设备。

⚠️ **警告！**

长期暴露在高噪音环境中可能会导致永久性听力损伤。
请勿在禁止使用电子设备的场所使用 Noble FoKus Rex5 耳机。
如果您有心脏起搏器或其他电子设备，请在使用您 Noble FoKus Rex5 耳机前咨询您的医生。
此包装包含小零件，可能对小孩造成危险。
请勿擅自拆卸 Noble FoKus Rex5,因为它包含锂电池，拆卸可能会导致触电、火灾或人身伤害的危险。
避免发出高或过低或过低温度环境中使用。
任何未经授权的人员若想要擅自试图维修 Noble FoKus Rex5,都会导致Noble FoKus Rex5 的保修失效。
本产品不适用于在水中或过于潮湿的环境中使用。请勿放入或浸没在水或其它液体中。否则将导致任何保修失效，并可能对产品造成永久性损坏。

10

产品规格

产品型号	Noble FoKus Rex5
蓝牙版本	V 5.4
支持协议	A2DP、AVRCP、HFP
音频传输	SBC、AAC、Aptx Adaptive
驱动单元	10mm Dynamic, 6mm Planar and 3 BA
频率响应	20Hz~40KHz
连接距离	≥10m
耳机电池容量(单个)	45mAh
充电保护盒电池容量	500mAh
播放时间(回音量和内音乐房)	5H (降噪开)，7H (降噪关)
充电时间	耳机:1.5小时;充电盒:2小时
充电接口类型	Type C
电源输入	5V⎓1A

11

12

English Version

NOBLE

www.nobleaudio.com

⊠ 图 210-241709

Noble FoKus Rex5
True Wireless Stereo Earphone
INSTRUCTION MANUAL

105mm

Packing List

Charging Case x1   Earphones   Charging cable x1

Ear Tips x10   Instruction Manual x1   Storage Bag x1

01

Overview

Multifunction Sensor(MFS)
Microphone
Microphone
Reset Button
LED Light Indicators
LED Light Indicators
LED Light Indicators
USB Type C Charging Port

02

Charging

❗ Notes:
Please make sure the earphones and charging case are fully charged prior to first use. The earphones and charging case need to be clean and dry before and during the charging process.

Charging Steps:
1. The earphones will power off automatically when placed back into the charging case and the lid is closed.
The LED light will indicate the power capacity when the lid is opened or closed.
2. Connect the charging case to a power source via the included USB Type C charging cable.

⚡ In charging: white light is flashing
○ Fully charged: white light is on

03

Power On / Off

The earphones will power on automatically when charging lid is opened.
The earphones will power off automatically when put back in the charging case and the charging lid is closed.

ON   OFF

To manually turn the earphones on, hold the MFS button for 3 seconds.
To manually turn off the earphones, hold the MFS button for 5 seconds. Both sides will power off automatically.

04

Fit

1. Select an eartip size suitable for your ear and insert them over the nozzle of the earphone.

2. Insert the earphones into your ear and check for fit and comfort. The ideal eartip size should have a comfortable and secure seal. If there is discomfort, try a smaller eartip size. If the eartips are loose, replace with a larger eartip size.

05

Pairing / Unpairing Procedure

The Noble FoKus Rex5 will need to be paired to your device before use. Once paired, they will connect automatically each time they are activated.

Pairing
1. Open the lid of the charging case. The earphones will power on automatically and enter pairing mode, red and white light flashes alternately.

2. Enable Bluetooth on your smartphone and search for "Noble FoKus Rex5" in available Bluetooth devices Once found,select "Noble FoKus Rex5 " to initiate pairing. You will hear"prompt tone" now the earphones are ready for use.

Pairing a new device
1. Open the lid of your charging case. The earphones will power on automatically and connect to your current device.

2. To unpair the earphones from your last connected smartphone by "disconnecting" or deleting "Noble FoKus Rex5" from your smartphone's Bluetooth device list.

3. Once disconnected, the earphones will automatically enter pairing mode, with red and white indicator lights flashing alternately.

4. Enable Bluetooth on your new device, and search for "Noble FoKus Rex5 " in the available Bluetooth devices. Once found, select "Noble FoKus Rex5 " to initiate pairing. You will hear " prompt tone ", now the earphones are ready for use.

06

Operation

⏯	Play/Pause	Single Click MFS (L/R)
🔊	Volume Up+	Triple Click MFS (L)
🔉	Volume Down-	Double Click MFS (L)
⏮	Previous Track	Triple Click MFS (R)
⏭	Next Track	Double Click MFS (R)
📞	Answer Call/Hang Up	Single Click MFS (L/R)
📞	Reject Call	Press the MFS for 2 seconds (L/R)
🎤	Voice Assistant function- Siri/Google	Press the MFS for 2 seconds (R)
🎚	ANC mode	Press the MFS for 2 seconds (L)

07

LED Indicator Lights

Usage Scenario	LED Indicator Status
Power On	White LED light flashes for one second
Power Off	Red LED light flashes for one second
Pairing	Red and white light flashes alternately
Pairing succeeds	White LED remains on for 2 seconds
Playing music or on calling	LED light off
Low Power	Red LED light flashes twice every 5 seconds
Earphones inserted into charging case	Red LED light on
Earphones fully charged in the charging case	LED light off
Case is charging	White light is flashing slowly
Case full charged	White LED light on

Single Pairing mode: Insert one side back into the charging case and the other earphone will work independently.
One side will continue working even when the other side is powered off.
Pairing after being taken out of range: The earphones will automatically pair to the smartphone within 3 minutes if they are close to the smartphone again after being taken out of range. If they are not brought within range within three minutes, the earphones will automatically power off.

08

Mode Switch   In standby mode or when playing music

ANC On	Press and hold for 2 secs
Press and hold the left earbud touch sensor for 2 seconds with voice prompt.

Ambient Mode On	Press and hold for 2 secs
Press and hold the left earbud touch sensor for 2 seconds with voice prompt.

Normal mode on	Press and hold for 2 secs
Press and hold the left earbud touch sensor for 2 seconds with voice prompt.

There are three modes available. "ANC on. ", Ambient mode" and "Normal mode". To switch between modes, press and hold the left earbud for two seconds. The voice prompt will confirm current selected mode.

Press and hold for 2 secs

09

Reset Procedure

* If the earphones cannot pair to each other or to your bluetooth devices, please reset them.

1. Put both earphones into the charging case
2. Hold the reset button for 10 seconds, the red and white LED lights will flash in sequence 3 times on both earbuds. All previously paired devices will be removed. The reset process is completed.

In the case that only one earphone is accidently reset, both earphones will need to be reset to function as a pair again.

10

Specification

Product Model	Noble FoKus Rex5
Bluetooth Version	V5.4
Bluetooth Profile	A2DP、AVRCP、HFP
Audio Codec	SBC、AAC、Aptx Adaptive
Driver Architecture	10mm Dynamic, 6mm Planar and 3 BA
Frequency Response	20Hz~40KHz
Connection Distance	≥10m
Earphone Battery Capacity	45mAh
Charging Case Battery Capacity	500mAh
Play Time	Up to 5 hours with ANC on and 7 hours with ANC off
Charging Time	Earbuds = 1.5 hours, Charging case = 2 hours
Charging Port	Type C
Power Input	5V⎓1A

Declarations and Warnings
Disconnect previous devices before pairing a new device.

⚠️ WARNING!

Long-term exposure to high noise volumes may cause permanent hearing loss.
Do not use the Noble FoKus Rex5 earphones in locations prohibiting the use of electronic equipment.
Consult your physician prior to using your Noble FoKus Rex5 earphones if you have a pacemaker or other electrical medical devices.
This package contains small parts, which may pose a hazard to small children.
Do not disassemble the Noble FoKus Rex5 as it contains lithium batteries, and disassembly could result in electric shock or fire or serious injury.
Any disassembly of the Noble FoKus Rex5, or attempt to replace or repair the Noble FoKus Rex5 by an unauthorized person, will void the Noble FoKus Rex5 warranty.
This product is not designed for use in water or wet environments. Keep product away from water and liquids.
Failure to do so will void any warranty and may cause permanent damage to the product.
Dispose of the product if it becomes swollen or cracked as it may be an indication that the battery is degraded and may burst and cause a fire.

11   12