

M11A4 User Manual




1. Know your team:



- 1 Integrated camera
- 2 Screen
- 3 System status indicators
- 4 Power button
- 5 Keyboard
- 6 Touchpad

1. Left side view



3 1 2 2 4 5 6

1 AC adapter connector

2 USB 3.0 port


3 Mini-HDMI port

4 TYPE-C

5 headset

6 microSD card slot

2. Bottom view



7


7

7 Built-in speakers

3. Switched on

Pressing the power button to turn on the computer.

4. Off

To turn off the computer, click followed  Select the  option to turn off

5. How to use the AC adapter and the battery.

- 5.1 Connect the charger to the connector found on the device, then connect the power cable to the power socket
- 5.2 The operating system will visually indicate the percentage of remaining charge; at that moment it is necessary to connect the charger.

6. How to activate the numeric keypad:

Pressing the "Fn" + "Del" function key activates a system status indicator

FCC statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.