Access product tutorials and manuals from











YouTube

Having issues of using the product? Please contact us before returning.

xupport@ibroadlink.com


We are always be ready to help until you smile:)

STEP 5 Control Groups



- You can tap "Batch Control" for temporary grouped control or "Room Control" for controlling all lights in the room.
- For fixed group control, please use "+" > "Create Group".

STEP 6 Control Preset



- The App and devices are designed with preset scenes in each room for out-of-box use. · lust switch to "Scene" tab and
- choose a room to activate scenes.

STEP 7 Edit Scenes



- Most of time you can just activate a scene and do some small tune-ups on devices as you wish. Then tap the ":" to enter scene detail and tap "Save current status" to override the default scene.
- You can also add/delete devices or set device status on scene detail page.

STEP 1 Install APP

STEP 8 Music Sync



- You can switch to "Music" tab and select music from default list or phone (only support Android) to play. The lights will change effects according to the music.
- You can also switch to "Mic" to let the App sense the rhythm of sound in your environment and change the effects.


Important Notices

- · A compatible BLE gateway/hub is required if you want to enable remote control (outside home), voice control and timer function to devices.
- The devices support mesh networking up to 255 devices to extend signal range and sync actions. The more device you add, the more stable the network will be.
- The use of App doesn't require creation of account for simplest experience. We still highly recommend users to create account so when you change a phone and log in with same account, everything will be automatically synced without setting up again.

■ FCC Radiation Exposure Statement

- FCC ID: 2ATEV-LB4D6US
- This device complies with Part 15 of the FCC Rules, Operation is subject. to the following two conditions:
- This device may not cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.

Overview





User Manual

Smart Downlight | LB4D6US





Specifications

Model	LB4D6US
Dimensions	Ф187х75
Rated Voltage	AC 110-130V 60Hz
Rated Power	12W
Luminous Flux	1100lm
Dimming	Wirelessly Dimmable
Color Temp	2700K-6500K
Multi-Color	RGB Full Colors

■ Product Features


No Account

Required

Batch Device

Pairing

Preset Scenes



Easy Automation Change

access.

Auto Room Music Sync

What's Required



 A smart phone or tablet running. Scan the OR code or search iOS 11.0 / Android 5.1 or higher "BroadLink BLE" in App Store or with Bluetooth turned on. Google Play to download and NOTE: For remote control from install the free App. Account creation is not mandatory

Alexa/Google voice control, a to use the App, However, as an option, you can go to "Me" tab to create your account for syncing data between different mobile devices.

STEP 2 Add Device



You can add multiple devices at same time.

- Tap "Add Device" > "Light" > "Add Devices".
- · Power the devices off and on twice and wait them to flash. Tap "Add Device" > "Light" > "Add Devices" to discover devices (pairing mode lasts for 1 min).

STEP 3 Complete Adding



- devices and assign rooms before
- you are editing if you are trying add temp, brightness and effects. multiple devices at the same time.
- Tap "Done" to finish the setup.

adding them.

STEP 4 Use & Manage Devices



- You can tap "

 " to edit the name of

 Now you can tap "ON" or "OFF" button in device list for quick control or enter device page for • Try to tap "o" to identify which one detailed control of color, color
 - Tap "Detail" to rename the device or re-assign a room. To manage multiple devices in rooms, tap "≡" at the end of room names or go to "Me" > "Room management".

■ FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.