

封面

45mm

45mm
45mm
45mm
45mm
45mm
45mm
45mm
45mm

BroadLink

Access product tutorials and manuals from

Facebook YouTube Twitter

Having issues of using the product?
Please contact us before returning.

support@ibroadlink.com

Works with Alexa/Google

- Refer to the manual of gateway/hub to link to Alexa/Google service (Google supports both temperature and humidity while Alexa only supports temperature).
- After the device is discovered, you can ask for instance "Alexa, what's the temperature of [Device Name]?" or "Hey Google, what's the humidity of [Device Name]?"

Place Device

The device can be placed either way for use:

- Desktop standing** Put the product standing on any flat surface (ex. desktop or bookshelf)
- Wall mounting** Use the sticker to stick the device on flat wall

FAQs

How can I do if I can't find device during adding?

- Make sure you keep a close distance between phone and device
- If you missed the pairing time (2min from power-up), please reset it (refer to "Add device").

What factors may affect the device communication?

- Walls, glasses, or metal materials attenuate the signal significantly between device and phone/hub. It is highly recommended to keep clear range between them for better communication.

Important Notices

- This device is NOT designed for use in environment under 0°C.
- Keep the device away from severe environment with high temperature or high humidity

FCC Radiation Exposure Statement

- FCC ID: 2ATEV-SR4T
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Product Specifications

Model	SR4T
Battery	CR2032
Connectivity	Bluetooth
Rated Voltage	3V
Low Battery Indication	Yes
Temp Measurement	0 ~ 60°C
Humidity Measurement	0 ~ 99%RH
Net Weight	24g
Dimensions	44.5*44.5*13mm

BroadLink | **FastCon**

User Manual

Temperature and Humidity Sensor | SR4T

正面

360mm

45mm

45mm
45mm
45mm
45mm
45mm
45mm
45mm

Overview-Front

Top Vent: Do not cover in use

Screen

Battery Insulator: Remove for first use

Overview-Back

Back Vent: Do not cover in use

Sticking Area

Sticker

Open cover here

Indications

Screen Display

Temperature Unit

Temperature

Comfort Indication

Humidity

Low Battery Indication

Switch Temperature Unit

- Take out the battery from device and put it back. Every time the device is re-powered, it will switch the display of temperature unit between Celsius and Fahrenheit.

Comfort Indication

Temp	<19°C	19-27°C	>27°C
Humidity	<20%	20%-85%	>85%
	(°C)	(°C)	(°C)
	(°F)	(°F)	(°F)

Low Battery Indication

- If the "⚡" sign appears, sign appears, please change a new battery as soon as possible.

What's Required

Internet

Phone

Wi-Fi Router

BLE Hub

- A smartphone or tablet running iOS 11.0 / Android 5.1.
- A 2.4GHz Wi-Fi network with Internet connection.
- Refer to the user manual of BLE hub/gateway to set it up in App and make sure it's accessible. The sensor won't work without BLE hub/gateway.

STEP 1 Install APP

- Scan the QR code or search "BroadLink BLE" in App Store or Google Play to download and install the free App.
- Account creation is not mandatory to use the App. However, as an option, you can go to "Me" tab to create your account for syncing data between different mobile devices.

STEP 2 Add Device

- Tap "Add Device" > "Sensor". Remove battery insulator for first use and the device will be in pairing mode for 2 min.
- Then click "Add Devices" to discover the device. If it is not for first use, take out the battery and put it back to switch the device to pairing mode again (reset).
- NOTE:** You may need to reset twice as the reset will also switch the temperature unit.

STEP 3 View Data on APP

- Click the device icon to view the current temperature and humidity as well as data curve.
- Click "History data" to choose specific day to view history data.
- NOTE:** The data will be refreshed instantly if the temperature is changed by 1°C or humidity is changed by 5%, otherwise the data will be synced every 4 hours.

版本	物料编码	替代物料编码	变更者	变更时间	版本升级原因描述
1.0		/	黄绯菲	2022.5	原始版本
2.0					

工艺说明		客户 	物料名称	SR4T-BLE-说明书-BL-EN-V1.0-2205	产品名称	温湿度传感器	产品经理	王影
纸张材质	105g金东太空梭		物料编号		产品型号	SR4T	业务审核	钱敏
印刷工艺	四色印刷		设计编码	SR4T.BLE.SMS4ZY.BL.EN.1			时间	2022.5
其他	风琴7折页							