

Charging Instructions

The Bluetooth Earbuds come with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully (approx. 2 hours).

- Only use the supplied USB Cord to charge the Bluetooth Earbuds.
- Connect the USB charging cable to a computer USB port and the Micro USB plug to the charging port of the device. (see below)

The Red LED light turns on while the device is charging. It takes two hours for the unit to fully charge. When the battery is fully charged, the LED light will turn off.

Powering Device

Press and hold the Multi-Function (**MF**) button for 2-3 seconds to turn ON/OFF the device.


Basic Button Functions:

Plus Button (Up button)
--- Short press – Volume up
---- Press and Hold – Previous Track

Multi-Function (Middle Button)
- Quick press – Play/Pause
Answer call/End call
- Quick press – Answer call
- Long press – Deny call

Minus Button (Down button)
--- Short press – Volume down
---- Press and Hold – Next Track

More functions on the back of this manual.



Pairing Device with Bluetooth Devices (*phone or music device*)

Ensure the device is turned off, then press and hold the **MF** button for 2-3 seconds to turn on. An indication tone will be heard, and the LED flashes blue and red. Place the Bluetooth Earbuds and Bluetooth device (phone or music device) so that they are no further than 3 feet apart.

Once you have activated Bluetooth on your device, select the **"#09190"** from the list of available Bluetooth devices.

Once paired successfully, an indication tone will be heard, and the blue LED will flash slowly. You can now start to use the device.

If pairing is unsuccessful, turn off the device first and then re-pair following the above steps. Once you have paired the Bluetooth Earbuds with a device, the Earbuds will remember this device and will pair automatically when the device's Bluetooth is activated and in range. You do not need to re-pair any previously connected devices.

The Bluetooth Earbuds will attempt to automatically connect to the last device it was paired with when switched on. If you want to pair it with a new device, please follow the steps outlined above.

Once the Bluetooth Earbuds is paired with your device the music will transmit through the Bluetooth Earbuds. Please refer to your device's user manual for further information.

Listening to Music

Once the Earbuds are paired with your device, you can stream music wirelessly through the Bluetooth Earbuds. Should you encounter any problems while streaming, please refer your device's user manual for further information.

Control Functions - Music

Function	Operation	Button
Increase Volume	Playing Music	Press & hold the + button will increase the volume
Decrease Volume	Playing Music	Press & hold the - button will decrease the volume
Pause	Playing Music	Short press on the MF button will pause the music
Play	Pausing	Short press on the MF button will restart the music
Previous Track	Playing Music	Short press on the - button will return you to the previous track
Next Track	Playing Music	Short press on the + button will return you to the next track

An indication tone will alert you when the volume is adjusted to the maximum level.

Control Functions - Making a call with your Bluetooth Device

Function	Operation	Button
Answer a call	Incoming Call	Press the Phone button once to answer an incoming call
Reject a call	Incoming Call	Press and hold the Phone button 1 second
End a call	Incoming Call	After your phone conversation, short press the Phone Button
Increase Volume	During Call	Long press the + button once will increase the volume
Decrease Volume	During Call	Long press on the - button once will decrease the volume
Redial last number	Standby mode and connected to a device	Short press the Phone button twice

QUICK START GUIDE

Bluetooth®
Wireless Earbuds
MANUAL



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2ATF5-E09190
