
SPECIFICATIONS COLOURS AND CONTENTS MAY VARY FROM ILLUSTRATIONS

USB

BATTERY INSTALLATION AND CHARGING INSTRUCTION MANUAL



7.4V




CAUTION: POSSIBLE HEAT HAZARD


- If the battery needs to recharge, please wait 10-15 minutes to let the battery cool down before charging.
 Do not overcharge the battery. The battery should be removed from charger immediately
- 2) Do not overcharge the battery. The battery should be removed from charger immediately and cooled down if the battery is in the high temperature. Otherwise, the battery may become damaged. Always pat attention to when you are charging the battery. Do not disassemble or reconstruct the battery. Do not connect the battery with an electrical outlet

Operation manual of radio control

Open the caps to drain the water

after the car landed on ground





The Amphibious will malfunction if it submerged underwater.









FCC ID. 2ATHLJM3060R-27-1

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received,

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment the receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help

Conforms to ASTM F963-17

▲ WARNING: TO AVOID BATTERY LEAKAGE

- Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions.
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- 3) Always remove weak or dead batteries from the product.
- 4) Remove the battery if the product is is left unused for a long period of time.

Distributed by JM Manufacturing Ltd., Unit G, 4/F Kaiser Estate, Phase 2, No. 47-53 Man Yue Street, Hung Hom, Kowloon, Hong Kong

Made in China

